

**DEPARTMENT OF ENVIRONMENTAL PROTECTION**  
**Bureau of Environmental Cleanup and Brownfields**

**DOCUMENT NUMBER:** 261-0300-101

**TITLE:** Land Recycling Program Technical Guidance Manual for Vapor Intrusion into Buildings from Groundwater and Soil under Act 2

**EFFECTIVE DATE:** January 18, 2017

**AUTHORITY:** The Land Recycling and Environmental Remediation Standards Act, 35 P.S. §§6026.101 *et seq.* (Act 2) and the regulations issued pursuant to that legislation at 25 Pa. Code Chapter 250.

**POLICY:** It is the policy of the Department of Environmental Protection (Department or DEP) to implement Act 2 in accordance with the regulations contained in Chapter 250 of the Pa. Code and as described in this guidance manual.

**PURPOSE:** DEP has developed a Technical Guidance Manual (TGM) to assist remediators in satisfying the requirements of Act 2 and the regulations published in Chapter 250 of the Pa. Code. This specific document provides guidance for how to address vapor intrusion (VI) from contaminated soil and groundwater into buildings. This document replaces the “*Land Recycling Program Technical Guidance Manual – Section IV.A.4. Vapor Intrusion into Buildings from Groundwater and Soil under the Act 2 Statewide Health Standard*” dated January 24, 2004, in its entirety.

**APPLICABILITY:** The guidance is applicable to any person or persons conducting a site remediation under Act 2.

**DISCLAIMER:** The policies and procedures outlined in this guidance are intended to supplement existing requirements. Nothing in the policies or procedures shall affect regulatory requirements.

The policies and procedures herein are not an adjudication or a regulation. There is no intent on the part of DEP to give the rules in these policies that weight or deference. This document establishes the framework within which DEP will exercise its administrative discretion in the future. DEP reserves the discretion to deviate from this policy statement if circumstances warrant.

**PAGE LENGTH:** 123 pages

**DEFINITIONS:** Definitions of key terms are provided in the guidance. See 25 Pa. Code Chapter 250 for additional definitions.

## TABLE OF CONTENTS

A.	Introduction.....	1
B.	Definition and Use of Important Terms.....	2
C.	Overview of the VI Evaluation Process.....	6
C.1.	VI Conceptual Site Model.....	6
C.2.	Screening Values and Points of Application (POA).....	8
	Figure 1. VI Screening Value Points of Application and Vertical Petroleum Product Proximity Distances.....	10
C.3.	Guidelines for Evaluating VI Using a Combination of Standards.....	11
D.	Preferential Pathway Evaluation.....	12
D.1.	External Preferential Pathways.....	13
	Figure 2. The Role of an External Preferential Pathway in the VI Evaluation.....	14
D.2.	Significant Foundation Openings.....	17
E.	Use of Proximity Distances.....	18
	Figure 3. Use of Proximity Distances to Evaluate Potential VI Sources.....	20
F.	Soil and Groundwater VI Screening.....	21
F.1.	Soil and Groundwater Screening Values.....	21
F.2.	Soil and Groundwater Screening Methods.....	22
	Figure 4. Effect of Separate Phase Liquid on the Applicability of Screening Values.....	24
G.	Alternative VI Assessment Options.....	25
G.1.	Soil Gas and Indoor Air Screening Values.....	26
G.2.	Soil Gas and Indoor Air Screening Methods.....	27
G.3.	Vapor Intrusion Modeling.....	29
H.	Mitigation and Activity and Use Limitations.....	30
I.	Remediating and Re-Assessing the VI Pathway.....	32
J.	Addressing Chapter 250 Requirements.....	32
K.	Evaluating the VI Pathway under the Site-Specific Standard.....	33
K.1.	Overview.....	33
K.2.	Preferential Pathway Evaluation.....	34
K.3.	Use of Proximity Distances.....	35
K.4.	Site-Specific Standard VI Screening.....	35
K.5.	Performing a VI Risk Assessment and Modeling.....	36
K.6.	Mitigation and Remediation.....	37
K.7.	Using an OSHA Program to Address VI.....	38
K.8.	Addressing Chapter 250 Requirements.....	38
	Figure 5. Statewide Health Standard Vapor Intrusion Assessment Process.....	40
	Figure 6. Site-Specific Standard Vapor Intrusion Assessment Process.....	41
	Figure 7. Screening Value Use Restrictions.....	42

L. References.....	43
<b>TABLES.....</b>	<b>49</b>
Table 1. Groundwater Statewide Health Standard Vapor Intrusion Screening Values ( $SV_{GW}$ ).....	50
Table 2. Soil Statewide Health Standard Vapor Intrusion Screening Values ( $SV_{SOIL}$ ).....	54
Table 3. Near-Source Soil Gas Statewide Health Standard Vapor Intrusion Screening Values ( $SV_{NS}$ ).....	58
Table 4. Sub-Slab Soil Gas Statewide Health Standard Vapor Intrusion Screening Values ( $SV_{SS}$ ).....	62
Table 5. Indoor Air Statewide Health Standard Vapor Intrusion Screening Values ( $SV_{IA}$ ).....	66
Table 6. Collection of Data for Vapor Intrusion Screening.....	70
Table 7. Application of Statewide Health Standard Vapor Intrusion Screening Criteria.....	71
<b>APPENDICES.....</b>	<b>73</b>
Appendix A: Methodology for Developing Statewide Health Standard Vapor Intrusion Screening Values.....	74
Appendix B: Vapor Intrusion Modeling Guidance.....	87
Appendix C: Vapor Intrusion Sampling Methods.....	97
Appendix D: OSHA Program Vapor Intrusion Checklist.....	118

## A. Introduction

Releases of volatile and some semi-volatile regulated substances to soil or groundwater can result in vapor-phase intrusion of these regulated substances into indoor air. The resulting impacts to indoor air may pose a threat to human health in inhabited buildings. For this exposure pathway to exist there must be a source of volatile substances in the unsaturated zone soil or groundwater at the water table, current or future inhabited buildings, and a transport pathway along which vapors may migrate from the source into the inhabited building(s). Inhabited buildings are buildings with enclosed air space that are used or planned to be used for human occupancy. In order to properly address this pathway, the remediator first develops a Conceptual Site Model (CSM) based on the site characterization to guide further assessment and, if necessary, mitigation or remediation.

This document provides guidance for addressing potential vapor intrusion (VI) of volatile organic compounds (VOCs) and certain semi-volatile organic compounds (SVOCs) from soil and/or groundwater sources, including those impacted by separate phase liquid (SPL), into inhabited buildings at sites using the Statewide health standard and the site-specific standard. As such, this guidance establishes screening values and assessment options that can be used under the Statewide health standard to address VI for existing or potential future inhabited buildings. The potential VI impacts from volatile inorganic substances (e.g., mercury and cyanide) can only be addressed using the site-specific standard or mitigation. **The VI screening value tables in this guidance are not meant to evaluate VI under the site-specific standard except under certain circumstances.** Guidance on VI evaluations under the site-specific standard, including the use of a human health inhalation risk assessment, is provided in Section K.

Title 25 Pa. Code § 250.312 requires an assessment of the VI exposure pathway in a Statewide health standard final report. An exposure pathway assessment that includes VI is required by 25 Pa. Code § 250.404, and a risk assessment is required by 25 Pa. Code § 250.405 under the site-specific standard. VI must be addressed for existing inhabited buildings and undeveloped areas of the property where inhabited buildings are planned to be constructed in the future. The VI pathway must be addressed for Special Industrial Area (SIA) sites and for storage tank corrective action sites because cleanups at these sites ultimately achieve either the Statewide health or the site-specific standards. A VI evaluation is generally not required for the background standard.

**It is important to note that mitigation measures may be used for existing inhabited buildings to eliminate unacceptable risks associated with VI under the Statewide health and site-specific standards at any time in the evaluation process. Mitigation can be used in lieu of a complete evaluation of the VI pathway. When choosing preemptive mitigation, the remediator needs to implement post remediation care to ensure: (1) that potential risks associated with VI will be evaluated and addressed when an inhabited building is constructed in the future or (2) that appropriate mitigation measures will be taken, in lieu of a complete evaluation in buildings that exist or are constructed on the property. It is also important to note that any unplanned change to a property's use that results in a change in the VI exposure pathway will require additional VI evaluation to account for that change in exposure. In order to demonstrate attainment of an Act 2 standard for soil and/or groundwater, current or future planned inhabited buildings need to be evaluated for VI in the final report (FR). If there are no plans for future construction of inhabited**

buildings at the site, the remediator may choose, but is not required, to use an activity and use limitation (AUL) to address possible future VI issues.

If there is a petroleum release to surface or subsurface soil and a full site characterization has not been performed, a remediator may attain the Statewide health standard by following the requirements in § 250.707(b)(1)(iii). Further VI analysis is not needed in these situations for soil if the following conditions are also satisfied: (1) all requirements of § 250.707(b)(1)(iii) have been met; (2) at least one soil sample is collected on the sidewall nearest the inhabited building unless there are substantially higher field instrument readings elsewhere; and (3) contamination has not contacted or penetrated the building foundation based on observations of obvious contamination and the use of appropriate field screening instruments. Evaluation of groundwater for VI potential may still be necessary if groundwater contamination is identified as a potential VI concern.

This guidance should be used to evaluate VI for sites where the remedial investigation or site characterization report is expected to be submitted following the effective date of this guidance. Upon the effective date of this VI guidance, a remediator with a site for which VI was evaluated under the 2004 VI guidance and who has an FR or remedial action completion report (RACR) under review by the Department will not need to update their VI evaluation. If this VI guidance becomes effective prior to the Department receiving an FR or RACR, then the remediator is expected to complete the FR or RACR using this VI guidance. The Department will not require remediators to amend or resubmit reports that have been approved under previous versions of this guidance, where VI can be evaluated under the current version of this guidance in a subsequent report in the cleanup process.

This guidance provides multiple options for addressing VI including soil and groundwater screening values, alternative assessment options, mitigation with an environmental covenant, and remediation. The alternative assessment options consist of screening values for indoor air, sub-slab soil gas, and near-source soil gas in addition to VI modeling. Use of the screening values and other options as well as important terms is described below.

## B. Definition and Use of Important Terms

Several of the terms used in this guidance may have multiple meanings within the context of the Land Recycling Program (LRP) or other DEP programs. Therefore, it is important that their intended use in this guidance be well-defined. The following definitions and uses are provided only for application under this VI guidance. They are presented in the order that allows the reader to make the best sense of each definition as opposed to alphabetical order.

- **Hydrogeologic Zones:**

- **Definition** - When used in this guidance, the following hydrogeologic terms are related to one another as shown in Figure 1. In the *saturated zone* all interconnected voids are filled with water. In practice, the top of the saturated zone is identified as the *water table*, which is the water surface at atmospheric pressure in appropriately constructed monitoring wells. *Groundwater* refers to water in the saturated zone, below the water table. The *capillary fringe* is the zone of tension saturation directly above the water table and its thickness is dependent on the soil type in which it occurs. The base of the capillary fringe is

saturated, and soil pore space becomes progressively less filled with water upward from the water table. In the *vadose zone* above the capillary fringe the pores are not filled with water. The capillary fringe and the vadose zone are not readily distinguished in the field. The *unsaturated zone* is defined here as the zone above the water table, including both the capillary fringe and the vadose zone.

- *Use* - These terms are used to define points of application for various screening values as shown in Figure 1 and applicable sampling intervals for soil, groundwater and near-source soil gas. They also pertain to the sources, fate, and transport of vapors in the subsurface.
- **Point of Application (POA):**
  - *Definition* - The locations in an inhabited building, the unsaturated zone, and the saturated zone where screening values are applied to evaluate vapor intrusion.
  - *Use* - POAs guide the selection of indoor air, sub-slab soil gas, near-source soil gas, soil, and groundwater sampling locations. See Section C.2. The relationship of the POAs to the building, the hydrogeologic zones, and the contamination are displayed in Figure 1. Sampling guidance for each POA is provided in Table 6 and Appendix C.
- **Acceptable Soil or Soil-like Material:**
  - *Definition* - Any unconsolidated material containing some amount of organic material that occurs in the vadose zone above a potential vapor intrusion source (soil and/or groundwater) that does not exceed the saturated hydraulic conductivity of sand or the net air-filled porosity of silt at residual water content, both as derived from Tables 5 and 3 in U.S. EPA (2004). Natural soils and fill (including gravel) coarser than sand or with air-filled porosity greater than silt may not constitute acceptable soil. Conversely, fill material that is otherwise soil-like and does not exceed the characteristics described above may constitute acceptable soil-like material (e.g., mixtures of granular material comprised predominantly of sand, silt and clay with brick, block and concrete fragments where the granular material occupies virtually all of the interstitial space between the fragments).
  - *Use* - A minimum of five feet of acceptable soil or soil-like material needs to be present between a potential VI source and foundation level to permit the use of the calculated groundwater screening values. The presence of acceptable soil or soil-like material is also a condition for using vertical proximity distances and applying separation distances for preferential pathways. Acceptable soil or soil-like material should NOT exhibit any of the following characteristics:
    - obvious contamination by a regulated substance of VI concern (e.g., staining or odors);
    - readings from an appropriate field screening instrument in the headspace above soil samples that are greater than 100 ppmv;

- evidence of separate phase liquids (SPL); and
- exceedances of soil screening values.

Material that is suspected to be contaminated (via observation or from field equipment readings) may be sampled to determine if the soil screening values are exceeded. If screening values are not exceeded, then that soil can be regarded as an acceptable soil or soil-like material. Soil does not need to be sampled in areas beyond where soil has been directly impacted by a release of regulated substances to demonstrate an acceptable soil or soil-like material. For the purposes of the petroleum substance vertical proximity distances described below, the Department further defines acceptable soil or soil-like material as exhibiting greater than 2% oxygen in soil gas near the building slab.

- **Preferential Pathway:**

- **Definition** - A natural or man-made feature that enhances vapor migration from a potential VI source to or into an inhabited building. An *external preferential pathway* is a channel or conduit that allows for a greater vapor flux than ordinary diffusion through vadose zone soil. A *significant foundation opening* is a breach in a building foundation or basement wall that may amplify the entry of subsurface vapors.
- **Use** - A feature must be proximal to both the contamination and a building and have sufficient volume to be a preferential pathway. A significant opening in a building foundation, such as a dirt basement floor, can also act as a preferential pathway. A suspected preferential pathway should be investigated to determine if it results in an excess VI risk. The presence of a preferential pathway may preclude the use of proximity distances or certain screening values. Significant foundation openings may be sealed to inhibit vapor entry. Additional information regarding how to identify and evaluate preferential pathways is provided in Section D and an example is shown in Figure 2.

- **Proximity Distance:**

- **Definition** - The minimum distance, in the absence of a preferential pathway, which a potential VI source (see definition below) must be from a building or where a future inhabited building is planned to be constructed, to not pose a potential unacceptable VI risk.
- **Use** - The presence of separate phase liquid or exceedances of soil or groundwater VI screening values within a proximity distance constitute a potential VI source. For petroleum substances, the horizontal proximity distance is 30 feet. The vertical proximity distance for petroleum hydrocarbons is five feet for adsorbed- or dissolved-phase contamination and 15 feet for SPL. The use of the vertical proximity distances requires the presence of acceptable soil or soil-like material. The horizontal proximity distance for non-petroleum contamination is 100 feet. There is no vertical proximity distance for non-petroleum contamination. Refer to

Section E for further guidance on proximity distances, and see Figure 3 for an example.

- **Separate Phase Liquid:**

- **Definition** - That component of a regulated substance present in some portion of the void space in a contaminated environmental medium (i.e., soil or bedrock) that is comprised of non-aqueous phase liquid (NAPL). As such, SPL is distinct from the mass of a regulated substance in the contaminated environmental medium that is adsorbed onto or diffused into the soil or rock matrix, or dissolved in water or diffused into air that may also occupy a portion of that void space.
- **Use** - SPL may be a potential VI source if it contains substances of VI concern. SPL may be analyzed to make this determination (Appendix C, Section 7). The presence of SPL containing substances of VI concern provides one basis for limiting the applicability of screening values and the modeling assessment option. As shown in Figure 4, the presence of an SPL layer on the water table or SPL within a smear zone associated with such a layer precludes the use of the groundwater screening values or the modeling assessment option to evaluate groundwater contamination. This is the case whether the water table occurs in the soil or bedrock beneath a site. These options are available, however, beyond the limits of the SPL. In the unsaturated zone, soil contamination that includes interstitial residual SPL precludes the use of soil screening values and the modeling assessment option to evaluate soil contamination since the model assumes partitioning from adsorbed mass on the soil to pore water and then to soil gas, as opposed to direct evaporation from SPL to soil gas. The same is true for screening values based on the generic soil-to-groundwater numeric values since they also rely on this partitioning equation. However, near-source soil gas screening values may be used provided the sampling is performed above the SPL-impacted soil or groundwater (Figure 4). The soil gas version of the Johnson and Ettinger (J&E) model (U.S. EPA, 2004) may also be used to evaluate near-source soil gas sampling results under the modeling assessment option.

- **Potential VI Source:**

- **Definition** - Contamination by a regulated substance of VI concern under any one of the following conditions constitutes a potential VI source:
  - in the unsaturated zone, soil exceeding Statewide health standard screening values within proximity distances;
  - in the saturated zone, groundwater exceeding Statewide health standard screening values within proximity distances;
  - as separate phase liquid within proximity distances; and
  - associated with a preferential pathway.



- *Use* - Identifies areas of a site where VI must be addressed through alternative assessment options, remediation, mitigation, or restrictions established in an environmental covenant. See Section D and Figure 2 for preferential pathways and Section E and Figure 3 for proximity distances.

## C. Overview of the VI Evaluation Process

This guidance offers a flexible vapor intrusion evaluation process for the Statewide health and site-specific standards that provides multiple alternatives to the remediator. Figures 5 and 6 present flowcharts outlining the process for each standard, which is described in detail in the following sections. It is important to note that the purpose of Figures 5 and 6 is to illustrate how all of the steps in the VI evaluation process fit together. Figures 5 and 6 should not be used as your sole guide for performing a VI evaluation; rather, they should be used in conjunction with the text of this guidance.

The principal steps of a VI evaluation under the Statewide health standard (Figure 5) are:

- Develop the CSM and assess the presence of preferential pathways;
- Identify potential VI sources from exceedances of soil and groundwater screening values within proximity distances and/or the occurrence of SPL;
- Utilize alternative assessment options including screening near-source soil gas, sub-slab soil gas, or indoor air data, or conducting VI modeling;
- Mitigate buildings using activity and use limitations;
- Remediate the soil and/or groundwater contamination and reassess the pathway;
- Address the Chapter 250 Statewide health standard requirements.

In most cases all of the above steps will not be necessary and the remediator is not required to follow the process sequentially. For instance, buildings with a potentially complete VI pathway may be mitigated without the collection of soil gas or indoor air data. (See Section K.1 for an overview of the site-specific standard process.)

**If conditions are identified that pose an immediate threat to human health or safety at any time in the VI evaluation process, prompt interim actions should be taken to protect human health. Such conditions include, but are not limited to, those that may result in injury or death resulting from inaction, such as acute toxicity to sensitive receptors (e.g., fetal cardiac malformations from TCE exposure (U.S. EPA, 2011a)), a fire or explosion hazard, or atmospheres that cause marked discomfort or sickness.**

### C.1. VI Conceptual Site Model

The VI CSM is central to the VI evaluation. The CSM is a representation of contaminant sources, migration pathways, exposure mechanisms, and potential receptors. The CSM drives the design of a sampling plan (Appendix C), and as the CSM is revised, data gaps may be identified that will guide further sampling. The CSM is also a prerequisite for VI

modeling (Appendix B). The source description and contaminants of concern are components of the CSM supported by soil, groundwater, and possibly near-source soil gas data. The CSM development may also rely on sampling the vapor migration pathway (sub-slab soil gas) or receptor exposures (indoor air).

The goal of the VI CSM is to describe how site characteristics, such as subsurface and building conditions, might influence both the distribution of substances of VI concern in soil gas and the potential indoor air quality of structures in the vicinity of a soil or groundwater source of substances of VI concern. Concentrations of substances of VI concern in soil gas attenuate, or decrease, as the substances of VI concern move away from the source, through the soil, through the foundation, and into indoor air. The extent of attenuation is related to site conditions, building characteristics, and chemical properties. The soil vapor attenuation is quantified in terms of an attenuation factor defined as the ratio of indoor air concentration to source vapor concentration (Appendix A).

The level of detail of the CSM should be tailored to the complexity of the site, the available data and the selected Act 2 remedial standard. For the VI pathway, complex relationships exist among the many factors that influence vapor intrusion. Hence, multiple lines of evidence are often used to evaluate risks associated with the vapor pathway. Finally, it should be remembered that the CSM is a dynamic tool to be updated as new information becomes available during site characterization.

Some important elements of the VI CSM are included in the list below (California EPA, 2011a; Massachusetts DEP, 2011; U.S. EPA, 2012a, 2015a; Hawaii DoH, 2014). Some elements may not be known or pertinent to the case, and this does not imply a deficient CSM.

- Sources of contamination—origins, locations, substances, and concentrations; presence of separate phase liquid
- Transport mechanisms—route from source to indoor air, potential preferential pathways
- Subsurface and surface characteristics—soil type, depth to bedrock, heterogeneities; ground cover
- Groundwater and soil moisture—depth to water, water level changes, capillary fringe thickness, perennial clean water lens
- Fate and transport—biodegradation of petroleum hydrocarbons, transformation of substances into regulated daughter products
- Weather—precipitation, barometric pressure changes, wind, frozen ground
- Building construction—basement, slab on grade, or crawl space; a garage that is open to the atmosphere in between the ground surface and the occupied areas
- Foundation openings—cracks, gaps, sumps, French drains, floor drains

- Building heating and ventilation
- Background sources—indoor air contaminants, ambient air pollution
- Receptor types—residential, nonresidential, sensitive receptors; potential future development.

## C.2. Screening Values and Points of Application (POA)

Statewide health standard screening values for regulated substances of VI concern are published in Tables 1 through 5 for soil, groundwater, near-source soil gas, sub-slab soil gas and indoor air. Separate screening values are provided in these tables for residential and nonresidential uses of potentially affected inhabited buildings. In addition, there are two distinct nonresidential building categories: “nonresidential” and “converted residential.” The first category refers to buildings constructed for nonresidential use, and the second category refers to buildings that presently have a purely nonresidential use although they were originally constructed for residential use. An example is a dentist’s office in a converted home. The converted residential screening values are based on attenuation factors representative of residential structures but exposure factors for nonresidential settings. When a building has both residential and nonresidential uses (e.g., apartments over a retail store), the remediator may need to evaluate VI with both residential and nonresidential screening values.

The remediator should determine which structures at a site are inhabited and intended for human occupancy. Structures that are not routinely occupied, such as storage sheds or confined spaces, are not considered inhabited buildings. Structures that are not fully enclosed (e.g., carports, shelters) are also not inhabited buildings. Basements are generally regarded as an occupied space in a building; crawl spaces are not regarded as occupied space.


The POA for each of the screening values is shown on Figure 1. Groundwater screening values ( $SV_{GW}$ ) apply within the zone of groundwater saturation that will exhibit concentrations of regulated substances representative of concentrations at the water table. This is an interval within ten feet or less of the water table. Soil screening values ( $SV_{SOIL}$ ) apply throughout the volume of contaminated soil in the unsaturated zone. Near-source soil gas screening values ( $SV_{NS}$ ) apply just above an unsaturated zone soil VI source and just above the capillary fringe for a groundwater VI source. Near-source soil gas screening is also applicable to a preferential pathway, except in some cases if it penetrates the building foundation (Section D). Sub-slab soil gas screening values ( $SV_{SS}$ ) apply immediately below the slab of a building potentially impacted by VI, whether the building has a basement or is slab-on-grade construction. Finally, indoor air screening values ( $SV_{IA}$ ) apply in the lowest occupied space of a potentially impacted building.

Screening values cannot be calculated for substances that have no inhalation toxicity data (Appendix A). Therefore, Statewide health standard and site-specific standard VI evaluations are not required for substances without screening values. However, the remediator could choose to address the VI pathway by demonstrating that the concentrations for such substances are below practical quantitation limits or by installing

a mitigation system. The remediator could also evaluate VI using the site-specific standard by developing toxicity values or utilizing published information (§ 250.605).

Table 6 summarizes data collection conditions for VI screening and how to apply the POAs. Methods for VI screening are described in Sections F and G and in Table 7. Appendix A describes the methodology for developing the screening values. Site-specific standard screening is explained in Section K.

Figure 1. VI Screening Value Points of Application and Vertical Petroleum Product Proximity Distances



POA = Point of Application SV<sub>SS</sub> = Sub-slab soil gas screening value SV<sub>SOIL</sub> = Soil screening value  
 SV<sub>IA</sub> = Indoor air screening value SV<sub>NS</sub> = Near-surface soil gas screening value SV<sub>GW</sub> = Groundwater screening value

Vapor Intrusion Illustration.dwg / 5-2-2016

### **C.3. Guidelines for Evaluating VI Using a Combination of Standards**

The VI pathway can be evaluated under the Statewide health standard, the site-specific standard or a combination of both standards. When using a combination of standards the VI pathway must be evaluated along with all of the other requirements of each standard being used. The screening values presented in Tables 1 through 5 were designed to be used only when attaining the Statewide health standard. However, under specific circumstances, adjusted Statewide health standard VI screening values can be used when evaluating VI under the site-specific standard. See Section K.4 for additional detail on using screening values under the site-specific standard.

The VI pathway must be assessed to satisfactorily attain the Statewide health standard for soil and groundwater. Under the Statewide health standard a remediator cannot evaluate the VI pathway without also evaluating soil and/or groundwater because Act 2 does not define indoor air or soil gas as environmental media. However, when using a combination of standards a remediator can, for instance, evaluate soil under the Statewide health standard and groundwater under the site-specific standard then separately evaluate VI entirely under the site-specific standard. This is permissible because the site-specific standard evaluates individual exposure pathways and Act 2 considers VI to be an exposure pathway, not an environmental medium. Under the site-specific standard a risk assessment is needed to evaluate the VI pathway if pathway elimination is not being used. The Statewide health standard does not evaluate individual exposure pathways separately so remediators cannot evaluate the VI pathway under the Statewide health standard if soil and groundwater are being evaluated under the site-specific standard. The remediator may also choose to evaluate VI for each substance and medium using the process for the corresponding standard.

When using VI modeling under the Statewide health standard, the desired output is a predicted indoor air concentration (Appendix B). This modeled concentration should be used in the evaluation of VI by comparing it to the associated indoor air screening value. The J&E model (U.S. EPA, 2004) also calculates risk values which should not be used for Statewide health standard evaluations. Use of risk calculations to evaluate VI is considered to be a risk assessment, which is a tool to be used under the site-specific standard and is subject to additional reporting requirements and fees. If calculated risk values are used in the VI analysis, it will be assumed that the site is being remediated under a combination of standards and all associated fees and requirements of both standards will apply.

If the remediator uses the site-specific standard to evaluate the VI pathway, either solely or under a combination of standards, the site-specific standard VI process described in Section K should be used.

The following matrix illustrates the assessment needs for addressing the VI pathway using a combination of standards.

## VI Assessment Needs when Using a Combination of Standards

Act 2 Standard Used to Address Soil and Groundwater	VI Evaluation Tools					
	Use Screening Values in Tables 1–5	Use 1/10 Screening Values in Tables 1–5	Modeling	Risk Assessment	Mitigation with EC (i.e., pathway elimination)	Remediation
Statewide Health Standard (SHS)	✓		✓		✓	✓
Site-Specific Standard (SSS)		✓	✓	✓	✓	✓
Combination of Standards*	✓	✓	✓	✓	✓	✓

\* Some media and/or substances may attain the SHS while others may attain the SSS.

### D. Preferential Pathway Evaluation

A preferential pathway is a feature that increases the rate of vapor migration between a source and an inhabited building (see definition in Section B). DEP defines two classes of preferential pathways. An ***external preferential pathway*** is a channel or conduit that allows for a greater vapor flux than ordinary diffusion through vadose zone soil (Figure 2). ***Significant foundation openings*** are breaches in the building foundation and basement walls that may enhance the entry of subsurface vapors. (Typical cracks, gaps, and utility line penetrations are not generally significant foundation openings; see Section D.2.) The presence and significance of these features should be identified whenever possible during CSM development (Section C.1). When building access is not possible, other preferential pathway assessment and investigation techniques should be used, when available, to complete the CSM. Guidance for assessing and investigating external preferential pathways and significant foundation openings is provided in Sections D.1 and D.2, respectively. Guidance for using screening values when external preferential pathways and significant foundation openings are present is provided in Sections F and G.

Some recognized instances of preferential pathways include the following.

- **An external preferential pathway that does not penetrate the building foundation.** External preferential pathways can impact buildings through VI even if they do not penetrate the building foundation. If the external preferential pathway is not fully enclosed, vapors can migrate into a building via typical cracks and gaps in building foundations. An example is permeable backfill material (e.g., gravel or sand) around a utility line close to a building slab or a basement wall. The vapors can travel through the backfill material and then migrate through soil into the building via typical cracks and gaps in the building foundation. If a utility trench is backfilled with native soil, then it is

unlikely to act as a preferential pathway. Another example is a drain line or cracked sewer pipe (Guo *et al.*, 2015). Water will travel through the line, but vapors can escape through cracks in the pipe and can migrate through soil into a building. Natural features such as open bedrock fractures could also transport vapors near a building.

- **A conduit (external preferential pathway) that enters the building.** This is when a utility line itself, not the backfill material, acts as a conduit for vapors. For example, liquid- and vapor-phase contamination can enter breaks in sewer and drain lines, permitting vapors to pass into buildings through failed plumbing components (Jarvela *et al.*, 2003; Pennell *et al.*, 2013).
- **A significant foundation opening without an external preferential pathway.** In this case, vapors migrate by diffusion through soil from the source to the building. All building foundations have minor cracks and gaps, but if there is a large opening—such as a dirt basement floor—then that opening will amplify the flux of vapors into indoor air. Sealing the opening(s) (e.g., pouring a concrete slab over the dirt floor) can eliminate the preferential pathway.
- **A combination of an external preferential pathway with a significant opening.** For example, vapors may migrate through gravel backfill around a utility line and then flow through a gap where the line penetrates the foundation. Sealing the gap would resolve VI through the significant opening but not the role of the external preferential pathway.

Reasonable effort should be made to determine whether external preferential pathways or significant foundation openings are present. It is recommended that remediators discuss how they plan to evaluate external preferential pathways and significant foundation openings with their Department Project Officer to ensure that all parties agree on the proposed approach.

As described later in this guidance, a preferential pathway may be eliminated by appropriate site remediation or mitigation actions.

#### **D.1. External Preferential Pathways**

Utility corridors and pipes are potential external preferential pathways common to most sites (U.S. EPA, 2015a, Sections 5.4, 6.3.2). When a preferential pathway is external to a building, the proximity distances to a source area (as described in Section E) are insufficient to eliminate the source from consideration because proximity distances are based on the movement of vapors, and associated attenuation, through soil. Therefore, an area of contamination that exceeds screening values beyond a proximity distance from a building may be a potential VI source when an external preferential pathway is present (Figure 2). Heightened attention should be paid to external preferential pathways which may contain separate phase liquids.

For a subsurface feature that is external to a building, the following conditions allow it to be excluded as an external preferential pathway:

- Soil and groundwater contamination exceeding VI screening values is at least 30 horizontal and five vertical feet from the feature, and any SPL is at least 30 horizontal and 15 vertical feet from the feature; OR



- The feature is at least five feet away from the building foundation.

To exclude a feature as a preferential pathway, soil between the subsurface feature and the building foundation within the distances specified above should consist of acceptable soil or soil-like material. (For SPL, a minimum of five vertical feet of acceptable soil or soil-like material should be present within the overall 15-foot minimum separation.) As an example, consider an area of contaminated soil exceeding screening values which is beyond the horizontal proximity distance from a building. If a high-permeability backfilled trench passes through the soil contamination and near the building, but six feet of acceptable soil or soil-like material is present between the trench and the building foundation, then no further VI analysis would be necessary.

**Figure 2. The Role of an External Preferential Pathway in the VI Evaluation**




Figure 2 illustrates the evaluation of a potential external preferential pathway associated with a release from an underground storage tank. (The assessment described here is not limited to underground storage tanks or petroleum hydrocarbons.) As shown in the separate map and side views, the distribution of contamination relative to the preferential pathway is important both horizontally and with depth. Zone A, shown in both views, is the volume of contaminated media identified in the site characterization. In the map view, the contamination in Zones B and C exceeds the soil and/or groundwater screening

values, but these areas are beyond the horizontal proximity distance from the building. However, Zone C represents the portion of contamination that exceeds screening values that is within 30 feet horizontally of the potential preferential pathway.

The side view of Figure 2 shows that some of the contamination is above the water table and some is below it. Zone D represents the contamination that exceeds soil and groundwater screening values but is greater than five feet below the potential preferential pathway, so the groundwater and soil contamination in Zone D is not of concern for vapor migration into the feature. Zone E, which is a portion of Zone C in unsaturated soil, is within five feet vertically of the feature, which means vapors from Zone E could enter the potential preferential pathway. Since the feature is separated by less than five feet from the building foundation, the feature is considered to be a preferential pathway with Zone E as a potential VI source. In this case, further VI assessment is required.

If a utility line trench is backfilled with native, low-permeability soil and the feature is intact (i.e., there is no evidence of the ability of groundwater or soil vapors to enter the pipe) then the feature is not considered to be an external preferential pathway. The Department does not expect remediators to prove that underground features do not have high-permeability backfill or are intact. However, if there is an indication that these conditions exist, then remediators should evaluate the feature further. For example, if the underground feature is the trench for a large diameter water line which is likely to be backfilled with gravel, it should be considered to be a potential external preferential pathway. If the underground feature is a small diameter fiber optic line, it is likely to have native soil backfill and the remediator could work under the assumption that it is not an external preferential pathway.

The Department recommends a progressive approach to evaluating external preferential pathways. The investigation can include sampling at the source (soil, groundwater, SPL, near-source soil gas), within the preferential pathway (soil gas or vapor), under the building (sub-slab soil gas), and within the building (indoor air). If a series of buildings is associated with one underground feature (e.g., a sewer line servicing multiple buildings along a street), then the buildings closest to the vapor source should be evaluated first. If it is determined that there are no VI concerns with the first building along the potential preferential pathway, then it is generally not necessary to evaluate the rest of the buildings along the line since they are increasingly farther away from the source.

Access to buildings is not always necessary for the evaluation of external preferential pathways because much of the pertinent information relates to their condition outside of the building. Examples of non-intrusive investigation techniques include a visual inspection of the exterior of the property for utility line entry points, an inspection of nearby streets and sidewalks for signs of underground utility lines and vaults, a Pennsylvania One Call notification, or a review of building plans.

The following recommendations pertain to assessing and screening external preferential pathways. (See Appendix C, Figure C-2 for an illustration.) The evaluation is described in terms of VI screening, but the remediator may also use the data with appropriate attenuation factors (Appendix A) to carry out a site-specific risk assessment (Section K.5). This is not a checklist of required evaluations; rather, if any of the

following items is satisfied such that screening values or risk thresholds are not exceeded, then other items do not need to be examined.

- **Use of soil and groundwater screening values** – Contamination in the source area may be screened using soil and groundwater screening values unless SPL is present or contaminated groundwater enters the preferential pathway. Groundwater that is within a preferential pathway may be screened with used aquifer MSCs.
- **Use of indoor air modeling** – The default model for predicting indoor air concentrations (see Appendix B) using soil, groundwater, or soil gas data may be used in the absence of an external preferential pathway. The default model should not be used if an external preferential pathway is present because this model is based on the diffusion of vapors through soil.
- **Use of near-source soil gas screening values** – If contaminated groundwater or SPL does not enter the preferential pathway, then near-source soil gas samples may be collected in the source area and the data screened with near-source soil gas screening values. Near-source soil gas data can also be screened against sub-slab soil gas screening values if an external preferential pathway or significant foundation opening is present or if a potential VI source is less than five feet below foundation level (see Section G). This option is not available if the source is less than five feet below grade.
- **Soil gas sampling within a preferential pathway** – Soil gas samples may be collected in the preferential pathway (e.g., within trench backfill) between the source area and the building. These are not near-source soil gas samples (Section G). They should be collected at a depth of at least 5 feet if the area is not paved and satisfy the other soil gas sampling criteria in this guidance (Table 6, Appendix C). The data may be screened with sub-slab screening values.
- **Sampling within a sewer line** – If the preferential pathway is a sewer line or similar enclosed conduit that contains contamination, then the remediator may consider analysis of SPL, water, and vapor in the line. Flows and concentrations are likely to be highly variable, and there can be other sources of contamination in sewer lines. For these reasons, such sampling can be used as an informational line of evidence but not for screening.
- **Sub-slab sampling** – If the preferential pathway does not penetrate the foundation (e.g., trench backfill without a significant opening or a conduit that does not enter the building), then sub-slab samples through the foundation may be obtained (Section G). This data may be screened with sub-slab screening values.
- **Sealed utility penetrations** – If the preferential pathway does penetrate the building, then the remediator should examine potential entry routes to indoor air. The basement or slab should be inspected for significant openings; foundation openings can be sealed (see Section D.2). If vapors travel within a sewer or drain line, then plumbing components could be inspected for integrity and repaired if

necessary. Sampling should be performed to demonstrate that the pathway is incomplete, and this may require indoor air sampling.

- **Indoor air sampling** – Indoor air may be sampled at any time when there is an external preferential pathway, and the data may be screened with indoor air screening values (Section G).

## **D.2. Significant Foundation Openings**

Significant openings internal to a building's structure, such as a dirt basement floor, may enhance vapor entry (U.S. EPA, 2015a, Sections 2.3, 6.5.2). Typical cracks, gaps, and utility line penetrations on their own are generally not considered to be significant openings. In fact, all foundations, even new ones, will have these minor openings which will permit the ingress of some vapors if a potential VI source or an external preferential pathway comes close to a building foundation. Common foundation openings such as sealed sumps, French drains, and floor drains are not necessarily significant openings.

Significant foundation openings will have any one of the following characteristics.

- The combined area of openings in the foundation surface is more than five percent of the total foundation surface area (Appendix A).
- There are direct indications of contaminant entry into the building through openings, such as seepage of SPL or contaminated groundwater, chemical odors, or elevated readings on a field screening instrument.
- An opening is connected directly to an external preferential pathway; for instance, a gap around a utility line penetration permits unimpeded vapor entry from the permeable backfill in the utility line trench.

The most effective way to evaluate a building for significant foundation openings is to gain access to the building and visually inspect the foundation and basement walls for utility penetrations and overall foundation condition. Remediators should try to access buildings whenever possible so that they can get the best possible information when evaluating significant foundation openings. However, visual inspections are not always possible. Sometimes property owners do not grant access to buildings. It is also possible for finished basements to have coverings on walls and floors (e.g., paneling, carpet, etc.) making openings difficult to see. If the remediator cannot gain access to a building to inspect for significant foundation openings, there are several assessment options presented below that do not require building access.

The Department recommends sealing significant foundation openings to inhibit the pathway (U.S. EPA, 2008, Section 3.2). Proper sealing should be done with durable materials as a long-term solution such that the former openings are no more transmissive to vapors than the rest of the foundation. Although sumps, when dry, are not generally considered to be significant openings, if a sump contains contaminated groundwater it may need to be sealed. Sealing openings is a building repair and is therefore not considered an activity and use limitation.

The recommendations listed below concern the assessment and screening of significant foundation openings. (See Appendix C, Figure C-3 for an illustration.) The evaluation is described in terms of VI screening, but the remediator may also use the data with appropriate attenuation factors (Appendix A) to carry out a site-specific standard risk assessment (Section K.5). Unless otherwise noted, the methods below cannot be used if contaminated soil, groundwater, or SPL is present within the building. This is not a checklist of required evaluations; rather, if any of the following items is satisfied such that screening values or risk thresholds are not exceeded, then other items do not need to be examined.

Options to assess significant foundation openings that do not require building access include the following.

- If there is no external preferential pathway, then the horizontal proximity distances discussed in Section E are applicable to the potential VI source. Vertical proximity distances do not apply because they are based on attenuation across an intact slab.
- Soil data may be screened using generic soil-to-groundwater numeric values. Groundwater data may be screened with used aquifer MSCs. These screening values are acceptable even if contaminated soil or groundwater is present inside the building.
- Near-source soil gas samples may be collected in the source area. This data should be screened with sub-slab screening values or modeled.
- Modeling of soil, groundwater, or near-source soil gas data may be performed by assuming that no slab is present as a conservative scenario (as described in Appendix B).

Options to assess significant foundation openings when building access is available and possible include the following.

- Sub-slab soil gas samples may be obtained if the building does not have a dirt floor. Sub-slab data should be screened with indoor air screening values.
- If foundation openings are sealed, then soil and groundwater data may be screened with standard screening values, near-source soil gas data may be screened with near-source soil gas screening values, and sub-slab soil gas data may be screened with sub-slab screening values (Sections F and G).
- Indoor air screening can be used at any time, even when contaminated soil, groundwater, or SPL is present within the building.

## **E. Use of Proximity Distances**

The remediator may use horizontal and vertical proximity distances from existing or planned future inhabited buildings to identify potential VI sources (Figure 5). To accomplish this step, existing and/or future inhabited buildings are located and proximity distances from each of these

buildings are delineated. Then, relying on the results of site characterization and/or post-remediation sampling, any areas of contaminated groundwater at the water table and volumes of contaminated unsaturated zone soil that exceed applicable screening values within a proximity distance from an existing or future inhabited building are identified (Figure 3). Areas of SPL and areas predicted to exceed the screening values in a fate-and-transport analysis are identified. If there is no SPL present or soil or groundwater screening values are not exceeded within these proximity distances, then no VI sources are present to address under the Statewide health standard.

If there is contamination both within a proximity distance (e.g., Figure 3) and near a potential preferential pathway (e.g., Figure 2), then the remediator evaluates each area of contamination separately. There may be potential VI sources in both locations. The process outlined in Figure 5 (page 38) would be repeated for each area of contamination and each potential vapor migration route.

A proximity distance is the distance between an existing or future inhabited building and contaminated groundwater or soil within which VI could pose a risk. Proximity distances are a function of the mobility and persistence of the chemical as well as, in the case of petroleum substances, the depth of the source and the characteristics of the subsurface materials. There are distinct proximity distances for petroleum and non-petroleum regulated substances:

- For contamination associated with non-petroleum substances present in soil and/or groundwater, a horizontal proximity distance of 100 feet applies between the building and SPL or soil or groundwater screening value exceedances; and
- For soil and/or groundwater contamination associated with petroleum substances and related hydrocarbons, a horizontal proximity distance of 30 feet and a vertical proximity distance of five feet apply between the building and soil or groundwater screening value exceedances. For petroleum SPL, a further vertical proximity distance of 15 feet applies between the SPL and foundation level.


Note: The petroleum proximity distances apply to any petroleum substance, not just the substances listed on the Petroleum Short List from the Land Recycling Program Technical Guidance Manual. Petroleum substances are either aliphatic or aromatic compounds. Aliphatic compounds are composed of straight-chained, branched, or cyclic compounds and can be saturated (alkanes) or unsaturated (alkenes, alkynes, and others). Aromatic compounds have one or more conjugated, benzene or heterocyclic rings within their structures.

Petroleum substances are treated differently than non-petroleum substances in setting proximity distances because their high rates of biodegradation play a key role in diminishing the effects of VI (U.S. EPA, 2013, 2015b; ITRC, 2014). Petroleum hydrocarbons typically biodegrade under both anaerobic and aerobic conditions, with aerobic degradation occurring much more rapidly. Since soil oxygen content is generally higher in surface and shallow sub-surface soils, vapors from petroleum hydrocarbons biodegrade rapidly as they migrate upward through the soil column, reducing their concentrations prior to migrating into inhabited buildings. The Department defines an acceptable soil or soil-like material as having greater than 2% oxygen for purposes of applying proximity distances for petroleum substances. Measurement of soil oxygen content is not required unless there is reason to believe the soil is anaerobic (see Appendix C for a recommended methodology). For instance, in the case of a large SPL plume

or a large building overlying SPL, oxygen may be depleted and the 15-foot vertical proximity distance might not be protective for VI.

If only petroleum substances have been detected, the remediator determines the horizontal and vertical distance of the building foundation to the groundwater plume or soil contamination. If a current or future inhabited building is greater than or equal to 30 horizontal feet from an area of petroleum substance SPL or screening value exceedance, then there is adequate distance for aerobic biodegradation to occur to reduce the vapor concentrations to acceptable levels. Likewise, if there is greater than or equal to five feet of acceptable soil or soil-like material vertically between the bottom of a current and/or future inhabited building foundation and the top of the dissolved phase contaminated groundwater plume or unsaturated zone area of soil petroleum screening value exceedance, then there is adequate distance for biodegradation to occur to reduce the vapor concentrations to acceptable levels. The minimum vertical separation distance is 15 feet for petroleum SPL, at least five feet of which should be acceptable soil or soil-like material. Vertical distances are calculated using the maximum groundwater elevation and the top of the measured or inferred SPL (smear zone or residual NAPL). If neither the horizontal nor vertical proximity condition is met, the remediator must evaluate VI further.

**Figure 3. Use of Proximity Distances to Evaluate Potential VI Sources**



An example of the application of proximity distances is shown in Figure 3. (The assessment described here is not limited to underground storage tanks or petroleum hydrocarbons.) Zone A is the area of contamination identified in the site characterization. Zones B and C include groundwater contamination that exceeds screening values, and Zone G represents the horizontal proximity distance from Zones B and C. Zone C is the area within the horizontal proximity distance from the existing building, so it is the only portion of groundwater contamination that could pose a VI problem. Therefore, Zone C is a potential VI source, at least for non-petroleum substances, that requires additional assessment.

The vertical proximity distance can be applied to the petroleum portion of the contamination. If this release contains only petroleum, then the contamination in groundwater is not of VI concern because groundwater is entirely below the vertical proximity distance line. The brown and

orange zones below the tank represent contaminated soil that exceeds screening values, with the brown zone being the portion of contaminated soil that is above the vertical proximity distance. However, the contaminated soil is entirely beyond the horizontal proximity distance from the building. Therefore, if the contamination consists only of petroleum hydrocarbons, then there is no potential VI source and no further VI evaluation would be required for the currently occupied building.

**F. Soil and Groundwater VI Screening**

This section describes the development and application of soil and groundwater screening values to properly collected characterization and attainment data. Remediators may choose from the following soil and groundwater screening options.

<b>Soil or Groundwater Screening</b>	<b>Additional Considerations</b>
<b>Soil concentrations &lt; SV<sub>SOIL</sub></b>	Not available if SPL is present or if there is a significant foundation opening that has not been sealed.
<b>Soil concentrations &lt; generic soil-to-groundwater numeric value</b>	Available with significant foundation openings. Not available if SPL is present.
<b>Groundwater concentrations &lt; SV<sub>GW</sub></b>	Not available if groundwater is less than five feet below foundation level, if SPL is present, if contaminated groundwater enters an external preferential pathway, or if there is a significant foundation opening that has not been sealed.
<b>Groundwater concentrations &lt; used aquifer groundwater MSC</b>	Available if groundwater is less than five feet below foundation level, if contaminated groundwater enters an external preferential pathway, or if there is a significant foundation opening. Not available if SPL is present.

When evaluating VI for the Converted Residential Category using the generic soil-to-groundwater numeric values or the used aquifer groundwater MSCs, the non-residential values should be used since the current use of the property, and therefore the exposure parameters, are non-residential. A summary of screening value restrictions and the reasoning for the restrictions is provided in Figure 7.

**F.1. Soil and Groundwater Screening Values**

There are two sets of groundwater VI screening values: (1) at depths less than five feet below the building foundation they are the Act 2 groundwater MSCs, and (2) at depths greater than or equal to five feet below the foundation they are the values provided in Table 1. The soil VI screening values are provided in Table 2. The derivation of these values is explained in Appendix A. Table 6 describes important conditions for collecting soil and groundwater data to be used for VI screening.



The groundwater VI screening values ( $SV_{GW}$ ) for depths less than five feet below foundation level are the used aquifer groundwater MSCs (Chapter 250, Appendix A, Table 1). The groundwater screening values for depths greater than or equal to five feet below foundation level are the higher of the groundwater MSCs and the calculated groundwater screening values based on empirical attenuation factors. The groundwater MSCs are considered suitable VI screening values because groundwater with concentrations at or below the MSCs is acceptable for use inside buildings (e.g., cooking, showering, cleaning, etc.).

The soil VI screening values ( $SV_{SOIL}$ ) are the higher of the generic soil-to-groundwater numeric values (Chapter 250, Appendix A, Table 3B) and calculated soil screening values. Soil screening values may be applied at any depth below a building foundation. The calculated soil screening values are established using the acceptable risk-based indoor air concentrations and model-derived attenuation factors. The generic soil-to-groundwater numeric values are considered appropriate for VI screening because soil contamination that is unable to impact aquifers in excess of groundwater MSCs is also unlikely to pose an excess inhalation risk. Furthermore, VI sources associated with contaminated soil are typically not directly beneath buildings and they do not have an infinite lateral extent, making the assumptions of the model for calculating soil screening values conservative.

If a preferential pathway or significant foundation opening restricts the use of soil or groundwater screening values (Section D), the remediator may still utilize groundwater MSCs and generic soil-to-groundwater numeric values for VI screening (unless SPL is present). These values may be applied even if contamination is present within the building (e.g., contaminated groundwater in a sump or contaminated soil in a dirt basement floor).

## **F.2. Soil and Groundwater Screening Methods**

The presence of residual SPL in soil or mobile SPL in groundwater prevents the use of soil or groundwater screening values (Figure 4). (Although Figure 4 illustrates a UST, the criteria indicated are not limited to tank cases or petroleum hydrocarbon contaminants.) Screening values for soil and groundwater may be used to address VI for buildings beyond the appropriate horizontal proximity distance from SPL (Figure 5). If there is a preferential pathway or a significant foundation opening, then additional restrictions may apply (Section D). The remainder of this subsection assumes that neither SPL nor preferential pathways prevent the use of soil and groundwater screening values. Potential sampling locations are illustrated in Appendix C, Figures C-1–3.


For purposes of screening soil and groundwater data to evaluate the vapor intrusion pathway using one or a combination of remediation standards, the concentration of a regulated substance is not required to be less than the limits relating to the PQLs for a regulated substance in accordance with § 250.701(c).

Vapor intrusion can be addressed by screening either characterization data or post-remediation data for soil and groundwater. The soil and groundwater sampling results combined with applicable proximity distances are used in the screening analysis to determine if any potential VI sources are present (see Figure 3). Important conditions for

screening are listed in Table 6. Among these are that groundwater must be sampled at or near the water table because it will be the source of vapors that can migrate to buildings.

Proper characterization of soil and groundwater contamination is required at all Act 2 sites and this data alone may be sufficient for the VI assessment. If the site soil and groundwater characterization data are below MSCs without remediation being performed, then the site characterization data may be used for VI screening (Tables 6 and 7). No potential VI source exists if the applicable characterization data does not exceed soil and groundwater VI screening values ( $SV_{SOIL}$ ,  $SV_{GW}$ ). If the characterization data exceed MSCs but the remediator intends to pursue the Statewide health standard (i.e., by means of remediation), then the characterization data should be used to identify potential VI sources. If there are none, then no further VI evaluation is necessary.

Figure 4. Effect of Separate Phase Liquid on the Applicability of Screening Values



POA = Point of Application SV<sub>SS</sub> = Sub-slab soil gas screening value SV<sub>SOIL</sub> = Soil screening value  
 SV<sub>IA</sub> = Indoor air screening value SV<sub>NS</sub> = Near-source soil gas screening value SV<sub>GW</sub> = Groundwater screening value

When a potential VI source is remediated, VI screening may be performed with the soil or groundwater attainment data in accordance with the sampling methodologies and related statistical tests of Chapter 250, Subchapter G (Table 7). Note, however, that the groundwater data evaluated for VI is within the horizontal proximity distance from current or planned future inhabited buildings, not just at the point of compliance. For example, when at least eight consecutive quarters of groundwater attainment data have been collected, the remediator may apply the 75%/10x test to monitoring wells on the property and the 75%/2x test for off-site monitoring wells for VI screening (§ 250.707(b)(2)(i)). Fewer than eight consecutive quarters of data may be screened for no exceedances with Department approval pursuant to § 250.704(d).

For soil remediated *in situ*, the POA is throughout the volume of soil originally determined to exceed the soil screening value(s) (i.e., the potential VI source). For soil excavated and removed from the site, the POA is the margins of the excavation.

The number and locations of groundwater monitoring wells are selected on the basis of their representativeness with respect to water quality in the relevant portion of the plume. For groundwater on developed properties, the POA is throughout the area of a plume that has been identified as a potential VI source prior to VI assessment or remediation. For groundwater on undeveloped properties or in undeveloped portions of properties where future inhabited buildings may be constructed, the POA is throughout the area of a plume that has been identified as a potential VI source prior to VI assessment or remediation and is not within an area subject to an activity and use limitation restricting construction of future inhabited buildings.

## G. Alternative VI Assessment Options

The purpose of the VI assessment options is to gather and evaluate enough information to adequately determine whether a potential VI source is present that must be addressed under the Statewide health standard. Remediators may choose from the following alternative assessment options.

Alternative Assessment Option	Additional Considerations
<p><b>Near-source soil gas concentrations &lt; SV<sub>NS</sub></b></p>	<p>Not available if contaminated groundwater or SPL enters a preferential pathway, if there is a significant foundation opening, if an external preferential pathway penetrates the building foundation, or if a potential VI source is less than five feet below foundation level.</p>
<p><b>Near-source soil gas concentrations &lt; SV<sub>SS</sub></b></p>	<p>Available for preferential pathways and significant foundation openings, and available for a potential VI source less than five feet below foundation level, but not if it is less than five feet below grade.</p>

<b>Alternative Assessment Option</b>	<b>Additional Considerations</b>
<b>Sub-slab soil gas concentrations &lt; SV<sub>SS</sub> for existing buildings</b>	Not available if an external preferential pathway penetrates the building foundation or if there is a significant foundation opening that has not been sealed.
<b>Sub-slab soil gas concentrations &lt; SV<sub>IA</sub> for existing buildings</b>	Available if a preferential pathway penetrates the foundation.
<b>Indoor air concentrations &lt; SV<sub>IA</sub> at existing buildings</b>	No restrictions.
<b>Vapor intrusion modeling using acceptable input parameters</b>	Not available for soil or groundwater where an external preferential pathway or SPL is present. Not available for near-source soil gas if an external preferential pathway is present.

A summary of screening value restrictions and the reasoning for the restrictions is provided in Figure 7.

### **G.1. Soil Gas and Indoor Air Screening Values**

The near-source soil gas screening values (SV<sub>NS</sub>) are provided in Table 3, the sub-slab soil gas screening values (SV<sub>SS</sub>) in Table 4, and the indoor air screening values (SV<sub>IA</sub>) in Table 5. The derivation of these values is explained in Appendix A. Table 6 describes important conditions for collecting soil gas and indoor air data to be used for VI screening. Detailed information on sampling methodologies is provided in Appendix C.

The near-source soil gas screening values are based on attenuation factors derived from modeling and endpoint concentrations equal to the acceptable indoor air screening values. Near-source soil gas is measured within or directly above an unsaturated zone soil source or directly above the capillary fringe for a groundwater source. Screening near-source soil gas data against near-source soil gas screening values is an option when a preferential pathway does not penetrate the building foundation (Section D). Vapor concentrations measured in near-source soil gas are theoretically the highest possible concentrations because they are directly adjacent to the source.

The sub-slab soil gas screening values are based on EPA's empirical attenuation factors and endpoint concentrations equal to the acceptable indoor air screening values. As a result, screening sub-slab soil gas data against sub-slab screening values cannot be done in the presence of a preferential pathway that penetrates the building foundation (Section D). Sub-slab samples are collected immediately below the foundation, and their proximity to the receptor makes them a reliable indicator of potential exposures. Sub-slab sampling may also be done beneath intact paved areas large enough to be representative of future inhabited buildings without basements.

The indoor air screening values (SV<sub>IA</sub>) are calculated using the inhalation risk equations in EPA's risk assessment guidance. Indoor air data represent conditions that are as close to the receptor as possible and, therefore, provide the most accurate representation of

concentrations at the point of exposure. Indoor air can be influenced by other vapor sources inside or outside of the structure not attributable to soil or groundwater contamination. This can lead to false positive indoor air detections which increases uncertainty in VI investigations. The likelihood of false negative indoor air detections is relatively low. If the remediator suspects that there are indoor sources of vapor contamination at the site, indoor air sampling is not recommended.

## **G.2. Soil Gas and Indoor Air Screening Methods**

Near-source soil gas, sub-slab soil gas, and indoor air data may be acquired during the site characterization phase or following soil or groundwater remediation. Vapor intrusion sampling requirements and statistical tests are not specified in Chapter 250. Therefore, the number of sample points for addressing VI is determined based on the CSM, professional judgment, and the guidance in this document. DEP recommends a minimum of two sample locations per building for sub-slab soil gas, and indoor air sampling and at least two near-source soil gas sample locations at the source. Potential sampling locations are illustrated in Appendix C, Figures C-1–3.

The characterization data and CSM are used to determine the size and location of the area of potential VI sources. For most sites, sampling should be biased toward the most contaminated areas or the most appropriate locations for the sample type. When a large number of samples is necessary, the sample locations should be determined by an appropriate randomization method (e.g., systematic random sampling, stratified random sampling, etc.) as described in the RCRA SW-846 manual (U.S. EPA, 2007, Chapter 9). These decisions are made on a case-by-case basis. Other important conditions for collecting data for the VI evaluation are listed in Table 6 and Appendix C.

The presence of SPL does not prevent the use of near-source soil gas or sub-slab soil gas screening values (Figure 4) unless the SPL has entered an external preferential pathway or significant opening. Indoor air screening values are available even in circumstances when SPL, an external preferential pathway, and/or a significant opening are present.

The POA for near-source soil gas is at least five feet below grade (Figure 1). If near-source soil gas samples are collected at least five feet below foundation level, then the data may be screened using near-source soil gas screening values ( $SV_{NS}$ ). If near-source soil gas samples are collected less than five feet below foundation level, then the data may be screened using sub-slab soil gas screening values ( $SV_{SS}$ ). Acceptable soil or soil-like material should be present between the sampling depth and the building foundation.

For near-source soil gas above a groundwater source, the number and locations of soil gas vapor probes are selected on the basis of their representativeness with respect to water quality in the relevant portion of the plume. When the water table occurs in soil, the POA for near-source soil gas is nominally within one foot of the top of the capillary fringe or as close to this interval as sampling can reasonably be performed given typical fluctuations in groundwater levels. Theoretical capillary fringe thicknesses for different soil types are provided in Appendix C, Table C-1. When the water table occurs within bedrock, the POA for near-source soil gas is within one foot of the soil-bedrock interface.

Sub-slab and indoor air samples should be biased toward areas of the building with the greatest expected VI impact. Indoor air samples should be collected in the basement, if present, or the lowest occupied floor. DEP recommends obtaining a concurrent ambient air sample (in addition to at least two indoor samples) to account for potential background contamination from outside the building.

The indoor air data collected for screening purposes should be collected when the daily average outdoor temperature is at least 15°F (8°C) below the minimum indoor temperature in the occupied space and when the heating system is operating normally. Indoor air sampling can be performed during warmer seasons, but that data should be used for informational purposes only and should not be used to screen out the VI pathway. If a building is not heated, then indoor air samples collected at any time of the year may be used for screening.

The remediator may initially characterize VI with a minimum of two rounds of near-source soil gas, sub-slab soil gas, or indoor air sampling (Table 7). This data will normally be collected during the site characterization, but it can also be obtained following soil or groundwater remediation or during attainment monitoring. The two sampling events should occur at least 45 days apart for statistical independence.

When preparing a sampling plan many factors should be considered (Appendix C). Two sample locations and two sampling rounds will not be sufficient at all sites and for all buildings. Spatial and temporal variability of VI data is significant, and small data sets have the potential of under-representing true mean concentrations and inhalation risks. Larger buildings will likely require more sample locations as source concentrations, vapor entry rates, and indoor ventilation rates will vary across the structure. If an as-yet undeveloped area is being evaluated, then there will need to be enough near-source soil gas points to encompass future building construction. Because petroleum hydrocarbons tend to pose a relatively low risk for VI owing to bioattenuation, DEP regards chlorinated VOCs as a greater concern for potential under-sampling.

If the near-source soil gas, sub-slab soil gas, or indoor air characterization data are equal to or less than the screening values ( $SV_{NS}$ ,  $SV_{SS}$ ,  $SV_{IA}$ ), then no potential VI sources are present to address under the Statewide health standard. (However, be aware of potential restrictions associated with preferential pathways, as described above.) If there are screening value exceedances, then the remediator has two options to continue evaluating the VI pathway. One option is to collect sufficient near-source soil gas, sub-slab soil gas, or indoor air data to apply statistical screening tests (Table 7). The other option is to select another assessment or remedial alternative (Figure 5). For example, if sub-slab sample results exceed screening values, then indoor air samples could be collected and screened, a mitigation system could be installed, or a risk assessment could be performed under the site-specific standard. In this case, the remediator should not collect near-source soil gas samples because they are farther from the point of exposure.

To screen near-source soil gas, sub-slab soil gas, and indoor air data using statistical tests, at least eight data points must be obtained at the existing or planned future building. This data can be a combination of sample locations and sampling rounds as long as there are at least two rounds collected at all of the same points (e.g. two rounds of sampling at four locations or four rounds of sampling at two locations). Sample locations should be

biased toward areas with the greatest expected VI impact. The following soil and groundwater statistical tests of § 250.707(b) may be applied to the collective data from the near-source soil gas, sub-slab soil gas, or indoor air sampling at each building:

- Seventy-five percent of all samples shall be equal to or less than the applicable VI screening value with no individual sample exceeding ten times the screening value on the property (75%/10x test) and two times the screening value beyond the property boundary (75%/2x test).
- As applied in accordance with EPA-approved methods on statistical analysis of environmental data, as identified in § 250.707(e), the 95% upper confidence limit of the arithmetic mean shall be at or below the applicable VI screening value (95% UCL test). The minimum number of samples is specified by the method documentation.

As an example, if there are two sub-slab sampling points in an onsite building that have been sampled four times, the 75%/10x test may be applied to those eight sets of analytical results. These tests should not be used for combinations of near-source and sub-slab data or soil gas and indoor air data. Data should be collected concurrently from all sample locations at the building.

Near-source soil gas, sub-slab soil gas, and indoor air sampling rounds should be performed in subsequent quarters or twice per quarter. Samples should be collected at least 45 days apart. DEP may allow alternative sampling frequencies with prior written approval.

### **G.3. Vapor Intrusion Modeling**

VI modeling can be used to predict indoor air concentrations in current or future buildings. Modeling of any kind has an inherent amount of uncertainty involved, but, if acceptable input parameters are used with measured data, it can be a useful tool. The J&E model is currently the most widely used and accepted VI model available (Appendix B). The J&E model does have its limitations, namely it does not account for bioattenuation of petroleum hydrocarbons in its predictions. As a result, other models, such as BioVapor, can be used to predict indoor air concentrations at petroleum VI sites. Each model has its own set of conservative default input parameters that should be used when applicable. However, some parameters such as soil type, depth to the source, and building size can be adjusted to site-specific conditions.

Soil and groundwater data cannot be used for modeling if an external preferential pathway or SPL is present. In addition, near-source soil gas data may not be modeled when there is an external preferential pathway. However, near-source data may be collected above SPL and modeled. The J&E model also may be applied when a building has significant foundation openings, such as a dirt floor, as described in Appendix B.

For sites that are completely or partially undeveloped, many of the modeling input parameters will have to be estimated. The remediator can use information from building plans, if available, and conservative parameter values. A list of input parameters that can



be adjusted based on site conditions is provided in the modeling guidance presented in Appendix B.

Pennsylvania versions of EPA's J&E model spreadsheets are available on DEP's website. They should be used for Act 2 and storage tank corrective action J&E modeling. These versions have DEP default parameter inputs as well as physical/chemical properties and toxicological values from Chapter 250, Appendix A, Table 5A.

It is important to remember that when using VI modeling under the Statewide health standard, the desired output is a predicted indoor air concentration. This modeled concentration should be used in the evaluation of VI by comparing it to the associated indoor air screening value. The J&E model can calculate risk values, but these should not be used for Statewide health standard evaluations. Use of risk calculations to evaluate VI is considered to be a risk assessment, which is a tool to be used under the site-specific standard, and is subject to additional reporting requirements and fees. If calculated risk values are used in the VI analysis, then the site is being remediated under a combination of standards and all associated fees and requirements of both standards will apply.

## **H. Mitigation and Activity and Use Limitations**

Properly installed and maintained mitigation measures eliminate or greatly reduce VI exposure and therefore remain protective regardless of changes in subsurface concentrations or toxicity levels. Many areas of Pennsylvania have high levels of naturally occurring radon gas, which can pose a significant public health threat. VI mitigation systems not only address potential VI concerns associated with the release of regulated substances at remediation sites, but also provide additional public health benefits associated with reducing the significant threat caused by naturally occurring radon gas. However, mitigation systems may not be feasible in all cases. The feasibility of using a mitigation system to address VI impacts for existing buildings and planned future buildings will depend on the specific details of the site, the building, and the design of the system. Mitigation most commonly involves the installation of an active sub-slab depressurization system (similar to a fan-driven radon abatement system) (U.S. EPA, 2008).

For residential buildings, standard radon-type mitigation systems should be installed by individuals or firms certified by DEP for radon mitigation pursuant to Chapter 240 of the regulations (Pennsylvania DEP, 1997). Standard residential systems do not need to be designed or approved by a Licensed Professional Engineer. The remediator is not required to perform indoor air confirmation sampling. Active sub-slab depressurization systems can be tested by measuring pressure differentials to demonstrate depressurization throughout the slab or by collecting one or more indoor air samples that do not exceed screening values. The system should be tested following its installation, if a significant modification or repair is made, after a change in ownership, or upon request by the Department. Performance and testing guidelines for these systems are provided in Appendix C, Section 9.

Other engineering controls that mitigate vapor intrusion, such as the installation of a vapor barrier, can be used to prevent VI. Vapor barriers should be designed and manufactured for use in VOC mitigation. The material should be chemically resistant and have demonstrated low permeability for the VOCs present. Moisture barriers typically do not meet these criteria. Vapor barriers should be installed and tested pursuant to the manufacturer's recommendations.

The following activity and use limitations (AULs) can be used to maintain the attainment of the Statewide health standard.

- Using mitigation as a means of eliminating or reducing vapor migration.
- Committing to mitigation (as described below) of currently planned future inhabited buildings on the property.
- Committing to evaluate potential VI sources at the time currently planned future inhabited buildings are constructed. The results of the evaluation should be submitted to DEP for review.
- Prohibiting construction of basements or future residential and/or nonresidential inhabited buildings in a specified area of the property where the VI pathway may be complete.

If there are no plans for future construction of inhabited buildings at the site, the remediator may still choose to use an AUL to address possible future VI issues. In this case, controls would not be required to maintain the Statewide health standard, but the remediator may wish to have additional protection for unplanned uses. Any combination of the above four conditions may be utilized. For example, Figure 3 depicts the proximity distance evaluation for a current building (Section E). Groundwater contamination in Zones B and C and the soil contamination zone in orange also represent potential VI sources at the site if a future inhabited building is constructed within the applicable proximity distances from these areas. Zone G, indicated by the outer dotted perimeter, is the area within the horizontal proximity distance from the potential VI source (Zones B and C) which exceeds soil and/or groundwater screening values. The remediator could evaluate VI within Zone G, for instance, with near-source soil gas sampling or modeling. Alternatively, the remediator could incorporate AULs requiring future evaluation if a new building is constructed, preemptive mitigation of new buildings, or the prohibition of occupied buildings within Zone G.

As required by the Uniform Environmental Covenants Act (Act 68 of 2007, 27 Pa. C.S. §§6501-6517, “UECA”) and the accompanying regulations (25 Pa. Code Chapter 253), engineering and institutional controls needed to address the VI pathway in order to demonstrate attainment of the Statewide health or site-specific standard are to be in the form of an environmental covenant, unless waived by DEP. The environmental covenant should include language that requires the property owner to maintain the VI mitigation system. In most cases the environmental covenant does not need to include language requiring periodic monitoring or reporting to DEP. DEP should be notified in the event of a property transfer, if there is a problem with the system or upon request by DEP.

Natural attenuation resulting in decreasing concentrations of soil and groundwater contamination over time can occur at sites with releases of substances that naturally degrade in soil. At sites for which an environmental covenant was used to address the vapor intrusion pathway from potential VI source(s), it may include a provision that allows for termination of the covenant or the AULs related to VI if the remediator can demonstrate to DEP that the AUL(s) is/are no longer necessary under current site conditions to comply with the selected standard.

The following language is provided as a guide for environmental covenants with only one AUL related to VI:

*This Environmental Covenant may be terminated if: (1) an evaluation is performed that demonstrates that mitigation to address a complete or potentially complete vapor intrusion pathway is no longer necessary and appropriate, and (2) the Department reviews and approves the demonstration.*

Alternatively, the following language is provided as a guide for environmental covenants with multiple AULs including AULs unrelated to VI:

*This Environmental Covenant may be modified with respect to the VI AUL if: (1) an evaluation is performed that demonstrates that mitigation to address a complete or potentially complete vapor intrusion pathway is no longer necessary and appropriate, and (2) the Department reviews and approves the demonstration.*

## **I. Remediating and Re-Assessing the VI Pathway**

Under some circumstances mitigation may not be practical or cost effective. The remediator may choose to perform further soil and/or groundwater remediation to address the VI pathway. Following the remediation, additional data must be collected for VI screening. This can include new soil or groundwater attainment data, or it can consist of soil gas or indoor air sampling data. The post-remediation data is evaluated following the process illustrated in Figure 5 and described in Sections F and G.

The timing of the remediation is an important consideration. If there is an excess VI risk but remediation is a long-term action (such as a pump-and-treat system), then excess inhalation risks may exist for an unacceptably long time. In such cases the remediator is responsible for implementing interim measures to protect human health.

## **J. Addressing Chapter 250 Requirements**

The final step in the process flowchart on Figure 5 is to address the requirements of Chapter 250 with respect to VI. This step is necessary to demonstrate compliance with the Statewide health standard in order to receive liability protection under Act 2. The submitted report should include a description of the conceptual site model for VI with a preferential pathway assessment. The flowchart endpoint can be reached in the following three ways, and compliance should be documented in either the final report (Chapter 250) or the site characterization and/or remedial action completion reports (Chapter 245):

- **Soil and Groundwater Screening.** The remediator may screen soil and groundwater concentration data within proximity distances of existing or planned buildings. If no potential VI sources are identified, then no further analysis is necessary. Maps and cross sections that show the spatial relationship between soil and groundwater data, any SPL, any potential preferential pathways, and existing or planned future inhabited structures should be used to document that no potential VI sources are present. Applicable proximity distances should be shown on these exhibits. Soil and groundwater data should

be tabulated and compared to applicable screening values. If statistical methods for screening the data are used, they should be explained.

- **Alternative Assessment Options.** The remediator may evaluate the VI pathway by screening near-source soil gas, sub-slab soil gas, or indoor air data, or by performing modeling. If the site data satisfy the screening criteria, then no further analysis is necessary. Sampling locations relative to potential VI sources and existing or planned future inhabited buildings should be shown on maps. The methodology for collecting the samples should be described and the results tabulated with applicable screening values. If statistical methods for screening the data are used, they should be explained. Refer to Appendix B for recommended modeling documentation.
- **Mitigation and Environmental Covenants.** The remediator may address the VI pathway by installing a mitigation system or implementing activity and use limitations in an environmental covenant. Installation of the mitigation system must be documented, for instance, with plans, manufacturer specifications, and the installer's certification. Testing to demonstrate the system's effectiveness should be performed (Appendix C) and the results described in the report. If mitigation is successful, no further analysis is required. The conditions to be included in a covenant to maintain the remedy should be detailed in the report.

When a potential VI source in soil or groundwater is remediated, new samples should be collected to reevaluate the VI pathway and data should be presented as described above. If the remediator chooses the site-specific standard to address VI, then the remediator should follow the process and reporting described in Section K.

## **K. Evaluating the VI Pathway under the Site-Specific Standard**

### **K.1. Overview**

A remediator may perform a site-specific standard VI evaluation for one of three reasons:

- The remediator has selected the site-specific standard for substances of VI concern in soil and/or groundwater;
- Soil and groundwater attain the Statewide health standard MSCs, but the VI pathway is not satisfactorily addressed by the Statewide health standard VI assessment process described previously in this guidance;
- The remediator wishes to evaluate VI for substances to which the Statewide health standard process cannot be applied, such as mercury, cyanide, or organics without inhalation toxicity values.

The site-specific VI evaluation process shares many elements with the Statewide health standard process, but the screening values are not the same and a human health risk assessment is an option. The site-specific standard VI process is outlined in Figure 6. It is important to note that the purpose of Figure 6 is to illustrate how all of the steps in the VI evaluation process under the site-specific standard fit together. Figure 6 should not be used as your sole guide for performing a VI evaluation; rather, it should be used in

conjunction with the text of this guidance. The principal steps of a VI evaluation under the site-specific standard are:

- Develop the conceptual site model and assess the presence of preferential pathways;
- Identify potential VI sources from exceedances of Statewide health standard soil and groundwater screening values within proximity distances and/or the occurrence of SPL;
- Screen near-source soil gas, sub-slab soil gas, or indoor air data;
- Perform a cumulative human health risk assessment, which may include modeling;
- Mitigate buildings using activity and use limitations;
- Remediate the soil and/or groundwater contamination and reassess the pathway;
- Address the Chapter 250 site-specific standard requirements.

In most cases all of the above steps will not be necessary, and the remediator is not required to follow the process sequentially. For instance, buildings with a potentially complete VI pathway may be mitigated without the collection of soil gas or indoor air data.

The Statewide health standard vapor intrusion screening values presented in this guidance are based on a carcinogenic target risk level of  $10^{-5}$  and a non-carcinogenic hazard quotient of 1.0. These screening values are not appropriate for use in risk assessments being performed under the site-specific standard because the Statewide health standard target risk levels may not be sufficiently conservative to account for cumulative risks to receptors from multiple contaminants and/or multiple pathways. However, screening can be performed under the site-specific standard for VI according to Section K.4 below.

## **K.2. Preferential Pathway Evaluation**

The remediator must assess potential preferential pathways and significant foundation openings as part of the site-specific standard conceptual site model development. The presence of a preferential pathway or significant opening may limit the use of proximity distances, screening values, and modeling.

The conditions listed in Section D to identify and evaluate preferential pathways and significant openings also apply under the site-specific standard. Specifically, contamination in soil and groundwater that exceeds Statewide health standard screening values within 30 horizontal and five vertical feet of a preferential pathway constitutes a potential VI source (Figure 2). Acceptable soil or soil-like material is qualified by no exceedances of Statewide health standard soil screening values. However, soil, groundwater, near-source soil gas, sub-slab, and indoor air sample data should be screened with the site-specific screening values described in Section K.4.

### K.3. Use of Proximity Distances

The remediator may utilize proximity distances to identify potential VI sources, as described in Section E. For non-petroleum substances the horizontal proximity distance is 100 feet, and for petroleum hydrocarbons it is 30 feet. When dissolved or adsorbed petroleum hydrocarbons are at least five feet below a building foundation and petroleum SPL is at least 15 feet below a building foundation, they are not considered to be a potential VI source. These vertical separations must encompass acceptable soil or soil-like material.

Potential VI sources are established by the presence of SPL and exceedances of Statewide health standard soil and groundwater screening values within the applicable horizontal proximity distance. Allowable site-specific screening values are one-tenth the Statewide health standard screening values given in Tables 1 and 2, as explained in Section K.4. For petroleum vertical proximity distances to apply, there must be acceptable soil or soil-like material (i.e., no exceedances of Statewide health standard soil screening values) in the upper five feet.

### K.4. Site-Specific Standard VI Screening

Screening of soil, groundwater, near-source soil gas, sub-slab soil gas, and indoor air data is available under the site-specific standard. This step in the evaluation allows substances to be eliminated prior to performing a risk assessment. Samples should be collected pursuant to the guidance in Table 6 and Appendix C. An assessment of external preferential pathways, significant foundation openings, and the presence of SPL needs to be performed prior to screening as these are conditions that can limit the use of screening values.

If no limiting conditions exist, then soil and groundwater data may be screened using site-specific standard screening values. If limiting conditions are present, near-source soil gas, sub-slab soil gas, and indoor air may be screened with the following exceptions:

- Near-source soil gas screening cannot be performed if there is a source less than five feet below the building foundation or if SPL or contaminated groundwater has entered a preferential pathway. If there is a significant foundation opening, then near-source soil gas data should be screened with sub-slab screening values.
- Sub-slab soil gas screening may not be performed if an external preferential pathway penetrates the building foundation or in the presence of a significant foundation opening. In that case, the data may be screened with indoor air screening values.

**The Statewide health standard vapor intrusion screening values listed in Tables 1 through 5 may *not* be used as is, without adjustment, for site-specific standard screening.** The Statewide health standard criteria are based on a  $10^{-5}$  target cancer risk and a 1.0 target hazard quotient, and on groundwater MSCs and soil-to-groundwater numeric values (Appendix A). Attainment for the site-specific standard is demonstrated

for cumulative risks to receptors from all substances, media, and pathways. VI evaluations using a combination of standards are discussed in Section C.3.

Substance-by-substance site-specific standard VI screening values can be determined using either of the following methods:

- Select the appropriate values for soil, groundwater, near-source soil gas, sub-slab soil gas, or indoor air from Tables 1 through 5, used aquifer groundwater MSCs (for groundwater less than five feet below the foundation), and/or groundwater MSCs and generic soil-to-groundwater numeric values (for significant foundation openings). Reduce each screening value by a factor of 10.
- Use the current EPA residential or industrial indoor air Regional Screening Level (RSL) values (based on a target cancer risk of  $10^{-6}$  and a target hazard quotient of 0.1) (U.S. EPA, 2016a). RSLs based on a  $10^{-5}$  cancer risk may be used for screening when it can be demonstrated that VI is the only complete exposure pathway for a receptor. RSLs may be used for screening indoor air data or for screening near-source or sub-slab soil gas data by using the following attenuation factors (refer to Appendix A):

Sample Type	Attenuation Factor		
	Residential	Non-Residential	Converted Residential
Sub-slab soil gas	0.026	0.0078	0.026
Near-source soil gas	0.005	0.001	0.005

The methodology for soil and groundwater screening is described in Section F.2, and the methods for near-source soil gas, sub-slab soil gas, and indoor air are provided in Section G.2. Screening may be applied to characterization and post-remediation data. A sufficient number of sample locations and rounds must be collected to satisfactorily evaluate the pathway. DEP recommends a minimum of two sample locations and two sampling rounds for screening.

For the site-specific standard the only acceptable screening criterion is no exceedances of the applicable screening values. Substances that screen out using either one-tenth of the Statewide health standard VI screening values or the EPA RSLs do not need to be included in a VI risk assessment.

### **K.5. Performing a VI Risk Assessment and Modeling**

In a risk assessment, the VI pathway should be considered when developing the CSM. The CSM should use a qualitative fate and transport analysis to identify all current and future potentially complete and incomplete exposure pathways, including source media, transport mechanisms, and all potential receptors (25 Pa. Code § 250.404). The risks associated with all complete exposure pathways must be combined for individual receptors in order to evaluate the total cumulative risk to each receptor. For example, if ingestion of contaminated soil, dermal contact with contaminated groundwater, and inhalation of vapor-phase contamination via VI are all complete exposure pathways for the same receptor, the calculated risk values for each of these pathways must be

combined to evaluate the total risk to the receptor. For the site-specific standard, the cumulative excess risk for known or suspected carcinogens may not be greater than  $10^{-4}$  and the hazard index may not exceed one for systemic toxicants (25 Pa. Code § 250.402).

Current toxicity values should be used in a site-specific standard risk assessment (25 Pa. Code § 250.605). Therefore, if a toxicity value has been updated since the last revision of the Statewide health standard screening values, that new information must be included in a cumulative risk assessment. This provision is consistent with DEP's discretion in allowing screening to substitute for a risk assessment.

VI modeling is one option for site-specific standard risk assessments. DEP's modeling guidance is provided in Appendix B. For site-specific standard modeling, the user inputs soil, groundwater, or near-source soil gas concentrations into the Pennsylvania versions of EPA's J&E models. The desired output is the incremental risks for each substance, *not* the predicted indoor air concentrations. The model risk results are then incorporated into the cumulative risk assessment.

The second option is to use indoor air, sub-slab soil gas, or near-source soil gas data for the risk assessment. Soil gas data must be converted to estimated indoor air concentrations using the conservative attenuation factors tabulated in Section K.4. Inhalation risks are calculated using standard equations. (See Appendices A and B).

The vapor intrusion risk assessment must be submitted in a risk assessment report meeting the procedural and substantive requirements of Act 2. For regulated storage tank sites, the risk assessment is provided in the site characterization and/or remedial action completion reports. Human health risk assessment guidance is found in Section IV.G of the Technical Guidance Manual (TGM). Screening of chemicals of concern may follow the methodology described in Section K.4.

## **K.6. Mitigation and Remediation**

If site contamination does not screen out using the site-specific standard screening values or the cumulative risks are excessive, then the remediator may choose to mitigate the VI pathway or remediate the VI sources. The remediator can also select these options before screening field data or carrying out a risk assessment.

Current and planned future inhabited buildings may be mitigated to eliminate the VI pathway (Section H). Mitigation measures that prevent the migration of vapor, such as vapor barriers or sub-slab depressurization systems, are considered to be engineering controls. The standard mitigation approach is an active sub-slab depressurization system (U.S. EPA, 2008). Performance and testing guidelines are provided in Appendix C. Measures taken that limit or prohibit exposure are considered to be institutional controls. Engineering or institutional controls used to mitigate the VI pathway must be addressed in the post-remediation care plan and must be memorialized in an environmental covenant.

Remediation of soil and/or groundwater is also an alternative to address the VI pathway (Section I). Post-remediation data must be collected and evaluated through screening or a



risk assessment. If remedial action is not completed promptly, then the remediator may be responsible for employing interim measures to protect human health.

#### **K.7. Using an OSHA Program to Address VI**

VI can be difficult to evaluate when vapors from soil or groundwater sources enter industrial (or commercial) facilities that use the same chemical(s) in their processes. DEP does not regulate indoor air. Rather, worker exposure to chemical vapors associated with an onsite industrial process is regulated by the Occupational Safety and Health Administration (OSHA). It is nearly impossible to accurately isolate and measure the VI component of the indoor air that can be attributed to soil and groundwater contamination using indoor air sampling. As a result, workers who are not properly trained to work in areas that contain these vapors can still be exposed to soil or groundwater related vapors due to VI.

Therefore, an OSHA program can be used to address VI as an institutional control within the site-specific standard. The remediator should demonstrate that the substances in the soil or groundwater contamination they are evaluating are currently being used in a regulated industrial process inside the inhabited building(s) and that OSHA regulations are fully implemented and documented **in all areas of the building(s)**. This means that a hazard communications plan is in place, including the posting of safety data sheets (formerly known as MSDSs), so that workers and others who might be exposed to all chemicals of concern have full knowledge of the chemicals' presence, have received appropriate health and safety training, and have been provided with the appropriate protective equipment (when needed) to minimize exposure. Remediators should not use an OSHA program to evaluate risk from VI in cases where the regulated substances being evaluated for the VI pathway are not used in the work place. It is also expected that a quantitative analysis of indoor air data using occupational screening values will be included in the VI assessment. Data is needed to show that OSHA worker protection measures are satisfied and also to demonstrate compliance and attainment of the site-specific standard. If OSHA implementation cannot be documented, then an OSHA program cannot be used as a means of addressing VI. A checklist is included in Appendix D to help remediators and reviewers ensure that the OSHA program is adequately documented. All items on the checklist should be provided to demonstrate that a complete OSHA program is present to provide protection. Additional guidance regarding the use of industrial hygiene/occupational health programs to address the VI pathway can be found in EPA's *OSWER Technical Guide for Assessing and Mitigating the Vapor Intrusion Pathway from Subsurface Vapor Sources to Indoor Air* (U.S. EPA, 2015a).

The use of an OSHA program to address VI is an institutional control because it limits exposure through the implementation of the OSHA requirements. If the future owner does not use the same chemical(s) in their industrial process as the previous owner and/or does not fully implement an OSHA program for the same chemical(s), then VI would need to be reevaluated by the new owner.

#### **K.8. Addressing Chapter 250 Requirements**


The final step in the process flowchart on Figure 6 is to address the requirements of Chapter 250 with respect to VI. This step is necessary to demonstrate compliance with

the site-specific standard under Act 2. The submitted report should include a description of the CSM for VI with a preferential pathway assessment. The flowchart endpoint can be reached in the following four ways. Compliance should be documented in Act 2 (Chapter 250) or storage tank corrective action (Chapter 245) reports:


- **Soil and Groundwater Screening.** The remediator may screen soil and groundwater concentration data within proximity distances to existing or currently planned inhabited buildings. If no potential VI sources are identified, then no further analysis is necessary. Documenting this conclusion requires the production of maps and cross sections that show the spatial relationship between soil and groundwater data, any SPL, any potential preferential pathways, and existing or planned future inhabited structures. Applicable proximity distances should be shown on these exhibits. Soil and groundwater data should be tabulated and compared to applicable screening values. This information is submitted in the remedial investigation and final reports or the site characterization and remedial action completion reports, as appropriate.
- **Alternative Assessment Options.** The remediator may evaluate the VI pathway by screening near-source soil gas, sub-slab soil gas, or indoor air data. If the site data satisfy the screening criteria, then no further analysis is necessary. Sampling locations relative to potential VI sources and existing or planned future inhabited buildings should be shown on maps. The methodology for collecting the samples should be described and the results tabulated with applicable screening values. Supporting information is submitted in the remedial investigation and final reports or the site characterization and remedial action completion reports, as appropriate.
- **Risk Assessment.** If VI screening values are not applicable or they are exceeded, then a human health risk assessment may be performed. If the site-specific risk thresholds (cumulative  $10^{-4}$  cancer risk and hazard index of 1.0) are satisfied, no further analysis is required. Risk assessment requirements are described in § 250.409 and the TGM, Section IV.G. Documentation is supplied in a risk assessment report or a risk assessment submitted as part of a site characterization report and remedial action completion report, as appropriate. The risk evaluation may include modeling, as described in Appendix B.
- **Mitigation and Activity and Use Limitations.** The remediator may address the VI pathway by installing a mitigation system or implementing AULs in an environmental covenant. Installation of the mitigation system must be documented, for instance, with plans, manufacturer specifications, and the installer's certification. Testing to demonstrate the system's effectiveness should be performed (Appendix C) and the results described in the report. The conditions to be included in a covenant to maintain the remedy or eliminate the pathway should also be detailed in a post-remediation care plan. Documentation for mitigation systems and covenant remedies is provided in the final report or remedial action completion report, as appropriate.

When a potential VI source in soil or groundwater is remediated, new samples are collected to reevaluate the VI pathway. That data is presented as described above for the site-specific standard or through the Statewide health standard process, as appropriate.

**Figure 5. Statewide Health Standard Vapor Intrusion Assessment Process**



**Figure 6. Site-Specific Standard Vapor Intrusion Assessment Process**



**Figure 7. Screening Value Use Restrictions**

Source	Data Type	Screening Value	Screening Value Use Restriction	Reason for Restriction
Groundwater within proximity distances	Groundwater	SV <sub>GW</sub>	<ol style="list-style-type: none"> <li>1. Presence of SPL within appropriate horizontal proximity distance</li> <li>2. Presence of a significant foundation opening</li> <li>3. Contaminated GW enters an external preferential pathway</li> <li>4. GW &lt; 5 feet below foundation level</li> </ol>	<ol style="list-style-type: none"> <li>1. SV<sub>GW</sub> values or the used aquifer GW MSCs cannot be used in the presence of SPL because both values assume no SPL is present.</li> <li>2. SV<sub>GW</sub> values cannot be used in the presence of significant foundation openings because the calculated SV<sub>GW</sub> values assume the presence of a slab.</li> <li>3. SV<sub>GW</sub> values cannot be used when GW enters a preferential pathway because the calculated SV<sub>GW</sub> values assume attenuation through soil.</li> <li>4. SV<sub>GW</sub> values cannot be used when GW &lt; 5 feet below foundation level because the calculated SV<sub>GW</sub> values require at least 5 feet of soil.</li> </ol> <p>• NOTE: For site-specific standard screening, use 1/10th of the Table 1 or MSC values.</p>
		Used Aquifer GW MSC	<ol style="list-style-type: none"> <li>1. Presence of SPL within appropriate horizontal proximity distance</li> </ol>	
Soil within proximity distances	Soil	SV <sub>SOIL</sub>	<ol style="list-style-type: none"> <li>1. Presence of SPL within appropriate horizontal proximity distance</li> <li>2. Presence of a significant foundation opening</li> </ol>	<ol style="list-style-type: none"> <li>1. SV<sub>SOIL</sub> values and the generic soil-to-GW numeric values cannot be used in the presence of SPL because both values assume no SPL is present.</li> <li>2. SV<sub>SOIL</sub> values cannot be used in the presence of a significant foundation opening because the calculated SV<sub>SOIL</sub> values assume a slab is present.</li> </ol> <p>• NOTE: For SSS screening, use 1/10th of the Table 2 or MSC values.</p>
		Generic Soil-to-GW Numeric Value	<ol style="list-style-type: none"> <li>1. Presence of SPL within appropriate horizontal proximity distance</li> </ol>	
Groundwater or Soil within proximity distances	Near-Source Soil Gas	SV <sub>NS</sub>	<ol style="list-style-type: none"> <li>1. Contaminated GW or SPL enters a preferential pathway</li> <li>2. Presence of a significant foundation opening</li> <li>3. External preferential pathway penetrates the building foundation</li> <li>4. Potential VI source is &lt; 5 feet below foundation level</li> </ol>	<ol style="list-style-type: none"> <li>1. SV<sub>NS</sub> values cannot be used when contaminated GW or SPL enters an external preferential pathway because the SV<sub>NS</sub> values assume attenuation through soil.</li> <li>2. SV<sub>NS</sub> values cannot be used in the presence of a significant foundation opening because the SV<sub>NS</sub> values assume the presence of a slab.</li> <li>3. SV<sub>NS</sub> values cannot be used if an external preferential pathways penetrates the building foundation because the SV<sub>NS</sub> values assume the presence of a slab.</li> <li>4. SV<sub>NS</sub> values cannot be used if the potential VI source is &lt; 5 feet below foundation level because the SV<sub>NS</sub> values assume 5 feet of soil between the source and the foundation.</li> <li>5. A comparison of near-source soil gas data to SV<sub>SS</sub> values cannot be performed if the potential VI source is &lt; 5 feet below grade because shallow soil gas data can be unreliable.</li> </ol> <p>• NOTE: For SSS screening, use 1/10th of the Table 3 values or use EPA indoor air RSLs with an appropriate attenuation factor.</p>
		SV <sub>SS</sub>	<ol style="list-style-type: none"> <li>1. Potential VI source is &lt; 5 feet below grade</li> </ol>	
		SV <sub>SS</sub>	<ol style="list-style-type: none"> <li>1. Presence of a significant foundation opening</li> <li>2. Preferential pathway penetrates the building foundation</li> </ol>	<ol style="list-style-type: none"> <li>1. The comparison of sub-slab data to SV<sub>SS</sub> is not available in the presence of a significant foundation opening because the calculation of the SV<sub>SS</sub> values assumes the presence of an intact slab.</li> <li>2. The comparison of sub-slab data to SV<sub>SS</sub> is not available if an external preferential pathway penetrates the building foundation because the SV<sub>SS</sub> values presume the presence of soil between the source and foundation.</li> </ol> <p>• NOTE: For SSS screening, use 1/10th of the Table 4 values or use EPA indoor air RSLs with an appropriate attenuation factor.</p>
Indoor Air	Indoor Air	SV <sub>IA</sub>	No Restrictions	<ol style="list-style-type: none"> <li>• NOTE: For SSS screening, use 1/10th of the Table 5 values or use EPA indoor air RSLs.</li> </ol>
		SV <sub>IA</sub>	No Restrictions	

## **L. References**

- American Petroleum Institute (API), 2005, Collecting and Interpreting Soil Gas Samples from the Vadose Zone, Publication No. 4741, Washington, DC.
- American Petroleum Institute (API), 2010, BioVapor User's Manual, Washington, DC.
- American Society for Testing and Materials (ASTM), 2007, Standard Test Method for Particle-Size Analysis of Soils, D422-63(2007)e2, West Conshohocken, PA.
- American Society for Testing and Materials (ASTM), 2008, Standard Practice for Radon Control Options for the Design and Construction of New Low-rise Residential Buildings, E1465-08a, West Conshohocken, PA.
- American Society for Testing and Materials (ASTM), 2009, Standard Test Methods for Laboratory Determination of Density (Unit Weight) of Soil Specimens, D7263-09, West Conshohocken, PA.
- American Society for Testing and Materials (ASTM), 2010a, Standard Test Method for Density of Soil in Place by the Drive-Cylinder Method, D2937-10, West Conshohocken, PA.
- American Society for Testing and Materials (ASTM), 2010b, Standard Test Methods for Laboratory Determination of Water (Moisture) Content of Soil and Rock by Mass, D2216-10, West Conshohocken, PA.
- American Society for Testing and Materials (ASTM), 2011a, Standard Practice for Classification of Soils for Engineering Purposes (Unified Soil Classification System), D2487-11, West Conshohocken, PA.
- American Society for Testing and Materials (ASTM), 2011b, Standard Guide for Assessing Depressurization-Induced Backdrafting and Spillage from Vented Combustion Appliances, E1998-11, West Conshohocken, PA.
- American Society for Testing and Materials (ASTM), 2012a, Standard Practice for Active Soil Gas Sampling in the Vadose Zone for Vapor Intrusion Evaluations, D7663-12, West Conshohocken, PA.
- American Society for Testing and Materials (ASTM), 2012b, Standard Test Method for Density, Relative Density, or API Gravity of Crude Petroleum and Liquid Petroleum Products by Hydrometer Method, D1298-12b, West Conshohocken, PA.
- American Society for Testing and Materials (ASTM), 2013a, Standard Test Method for Measurement of the Permeability of Unsaturated Porous Materials by Flowing Air, D6539-13, West Conshohocken, PA.
- American Society for Testing and Materials (ASTM), 2013b, Standard Practice for Installing Radon Mitigation Systems in Existing Low-Rise Residential Buildings, E2121-13, West Conshohocken, PA.

- American Society for Testing and Materials (ASTM), 2014, Standard Test Method for Estimation of Mean Relative Molecular Mass of Petroleum Oils from Viscosity Measurements, D2502-14, West Conshohocken, PA.
- American Society for Testing and Materials (ASTM), 2015a, Standard Practice for Analysis of Reformed Gas by Gas Chromatography, D1946-90(2015)e1, West Conshohocken, PA.
- American Society for Testing and Materials (ASTM), 2015b, Standard Guide for Application of Engineering Controls to Facilitate Use or Redevelopment of Chemical-Affected Properties, E2435-05(2015), West Conshohocken, PA.
- California Environmental Protection Agency (EPA), 2011a, Guidance for the Evaluation and Mitigation of Subsurface Vapor Intrusion to Indoor Air, Sacramento, CA.
- California Environmental Protection Agency (EPA), 2011b, Vapor Intrusion Mitigation Advisory, Sacramento, CA.
- California Environmental Protection Agency (EPA), 2015, Advisory—Active Soil Gas Investigations, Sacramento, CA.
- Folkes, D., W. Wertz, J. Kurtz, and T. Kuehster, 2009, Observed spatial and temporal distributions of CVOCs at Colorado and New York vapor intrusion sites, *Ground Water Monitoring & Remediation*, 29, 70–80.
- Guo, Y., C. Holton, H. Luo, P. Dahlen, K. Gorder, E. Dettenmaier, and P. Johnson, 2015, Identification of alternative vapor intrusion pathways using controlled pressure testing, soil gas monitoring, and screening model calculations, *Environmental Science & Technology*, 49, 13,472–13,482.
- Hawaii Department of Health (DoH), 2014, Technical Guidance Manual for the Implementation of the Hawaii State Contingency Plan—Soil Vapor and Indoor Air Sampling Guidance, Honolulu, HI.
- Hers, I., R. Zapf-Gilje, L. Li, and J. Atwater, 2001, The use of indoor air measurements to evaluate intrusion of subsurface VOC vapors into buildings, *Journal of the Air & Waste Management Association*, 51, 1318–1331.
- Hers, I., R. Zapf-Gilje, P. C. Johnson, and L. Li, 2003, Evaluation of the Johnson and Ettinger model for prediction of indoor air quality, *Ground Water Monitoring & Remediation*, 23, 119–133.
- Holton, C., H. Luo, P. Dahlen, K. Gorder, E. Dettenmaier, and P. C. Johnson, 2013, Temporal variability of indoor air concentrations under natural conditions in a house overlying a dilute chlorinated solvent groundwater plume, *Environmental Science & Technology*, 47, 13,347–13,354.
- The Interstate Technology & Regulatory Council (ITRC), 2007, Vapor Intrusion Pathway: A Practical Guideline, Washington, DC.

- The Interstate Technology & Regulatory Council (ITRC), 2014, Petroleum Vapor Intrusion: Fundamentals of Screening, Investigation, and Management, Washington, DC.
- Jarvela, S., K. Boyd, R. Gadinski, M. DiVincenzo, and T. Karlicek, 2003, Tranguch gasoline site case history, *International Oil Spill Conference Proceedings*, 637–642, April 2003.
- Johnson, P.C., and R. A. Ettinger, 1991, Heuristic model for predicting the intrusion rate of contaminant vapors into buildings, *Environmental Science & Technology*, 25, 1445-1452.
- Luo, H., P. Dahlen, P.C. Johnson, T. Peargin, and T. Creamer, 2009, Spatial variability of soil-gas concentrations near and beneath a building overlying shallow petroleum hydrocarbon-impacted soils, *Groundwater Monitoring & Remediation*, 29, 81–91.
- Massachusetts Department of Environmental Protection (DEP), 1995, Guidelines for the Design, Installation, and Operation of Sub-slab Depressurization Systems.
- Massachusetts Department of Environmental Protection (DEP), 2011, Interim Final Vapor Intrusion Guidance, Boston, MA.
- McHugh, T.E., T.N. Nickels, and S. Brock, 2007, Evaluation of spatial and temporal variability in VOC concentrations at vapor intrusion investigation sites, in *Proceedings of Air & Waste Management Association, Vapor Intrusion: Learning from the Challenges*, September 26–28, Providence, RI, 129–142.
- New Jersey Department of Environmental Protection (DEP), 2013, Vapor Intrusion Technical Guidance, Trenton, NJ.
- New York Department of Health (DoH), 2006, Guidance for Evaluating Soil Vapor Intrusion in the State of New York, Troy, NY.
- Pennell, K.G., M. Kangsen Scammell, M.D. McClean, J. Ames, B. Weldon, L. Friguglietti, E.M. Suuberg, R. Shen, P.A. Indeglia, and W.J. Heiger-Bernays, 2013, Sewer gas: An indoor air source of PCE to consider during vapor intrusion investigations, *Groundwater Monitoring & Remediation*, 33, 119–126.
- Pennsylvania Department of Environmental Protection (DEP), 1997, Pennsylvania Radon Mitigation Standards, Bureau of Radiation Protection, Harrisburg, PA, 294-2309-002.
- Pennsylvania Department of Environmental Protection (DEP), 2014, User’s Manual for the Quick Domenico Groundwater Fate-and-Transport Model, Bureau of Environmental Cleanup and Brownfields, Harrisburg, PA.
- Persily, A. K., and J. Gorfain, 2009, Analysis of Ventilation Data from the U.S. Environmental Protection Agency Building Assessment Survey and Evaluation (BASE) Study, NIST Interagency/Internal Report (NISTIR) 7145-R.
- Provoost, J., L. Reijnders, F. Swartjes, J. Bronders, P. Seuntjens, and J. Lijzen, 2009, Accuracy of seven vapour intrusion algorithms for VOC in groundwater, *Journal of Soils and Sediments*, 9, 62–73.



- Provoost, J., A. Bosman, L. Reijnders, J. Bronders, K. Touchant, and F. Swartjes, 2010, Vapour intrusion from the vadose zone—seven algorithms compared, *Journal of Soils and Sediments*, 10, 473–483.
- Taylor, C. A., and H. G. Stefan, 2008, Shallow groundwater temperature response to urbanization and climate change in the Twin Cities Metropolitan Area: Analysis of vertical heat convection effects from the ground surface, University of Minnesota, St. Anthony Falls Laboratory, Minneapolis, MN, Project Report No. 504.
- U.S. Department of Agriculture (USDA), 1993, Soil Survey Manual, Soil Conservation Service, USDA Handbook 18.
- U.S. Environmental Protection Agency (EPA), 1991, Handbook: Sub-Slab Depressurization for Low Permeability Fill Material—Design and Installation of a Home Radon Reduction System, EPA/625/6-91/029.
- U.S. Environmental Protection Agency (EPA), 1993, Radon Reduction Techniques for Existing Detached Houses—Technical Guidance (Third Edition) for Active Soil Depressurization Systems, EPA 625/R-93/011.
- U.S. Environmental Protection Agency (EPA), 1994a, Model Standards and Techniques for Control of Radon in New Residential Buildings, Air and Radiation (6604-J), EPA 402-R-94.
- U.S. Environmental Protection Agency (EPA), 1994b, Radon Prevention in the Design and Construction of Schools and Other Large Buildings, Office of Research and Development, EPA/625/R-92/016.
- U.S. Environmental Protection Agency (EPA), 2001, Building Radon Out: A Step-by-Step Guide on how to build Radon-Resistant Homes, Office of Air and Radiation, EPA/402-K-01-002.
- U.S. Environmental Protection Agency (EPA), 2004, User's Guide for Evaluating Subsurface Vapor Intrusion into Buildings, Office of Emergency and Remedial Response, Washington, DC.
- U.S. Environmental Protection Agency (EPA), 2006, Guidance on Systematic Planning Using the Data Quality Objectives Process, EPA QA/G-4, Office of Environmental Information, Washington, DC, EPA/240/B-06/001.
- U.S. Environmental Protection Agency (EPA), 2007, Test Methods for Evaluating Solid Waste, Physical/Chemical Methods (SW-846).
- U.S. Environmental Protection Agency (EPA), 2008, Indoor Air Vapor Intrusion Mitigation Approaches, Office of Research and Development, Cincinnati, OH, EPA/600/R-08-115.
- U.S. Environmental Protection Agency (EPA), 2009, Risk Assessment Guidance for Superfund (RAGS), Volume 1: Human Health Evaluation Manual (Part F, Supplemental Guidance

- for Inhalation Risk Assessment), Office of Superfund Remediation and Technology Innovation, Washington, DC, EPA-540-R-070-002.
- U.S. Environmental Protection Agency (EPA), 2010, Temporal Variation of VOCs in Soils from Groundwater to the Surface/Subslab, APM 349, Office of Research and Development, Washington, DC, EPA/600/R-10/118.
- U.S. Environmental Protection Agency (EPA), 2011a, Toxicological Review of Trichloroethylene, National Center for Environmental Assessment, Washington, DC, EPA/635/R-09/011F.
- U.S. Environmental Protection Agency (EPA), 2011b, Exposure Factors Handbook, Office of Research and Development, Washington, DC, EPA/600/R-09/052F.
- U.S. Environmental Protection Agency (EPA), 2012a, Conceptual Model Scenarios for the Vapor Intrusion Pathway, Office of Solid Waste and Emergency Response, Washington, DC, EPA 530-R-10-003.
- U.S. Environmental Protection Agency (EPA), 2012b, EPA's Vapor Intrusion Database: Evaluation and Characterization of Attenuation Factors for Chlorinated Volatile Organic Compounds and Residential Buildings, Office of Solid Waste and Emergency Response, Washington, DC, EPA 530-R-10-002.
- U.S. Environmental Protection Agency (EPA), 2012c, Fluctuation of Indoor Radon and VOC Concentrations Due to Seasonal Variations, Office of Research and Development, Washington, DC, EPA/600/R/12/673.
- U.S. Environmental Protection Agency (EPA), 2013, Evaluation of Empirical Data to Support Soil Vapor Intrusion Screening Criteria for Petroleum Hydrocarbon Compounds, Office of Underground Storage Tanks, Washington, DC, EPA 510-R-13-001.
- U.S. Environmental Protection Agency (EPA), 2014a, Vapor Intrusion Screening Level (VISL) Calculator, User's Guide, Office of Superfund Remediation and Technology Innovation, Washington, DC.
- U.S. Environmental Protection Agency (EPA), 2014b, Human Health Evaluation Manual, Supplemental Guidance: Update of Standard Default Exposure Factors, Office of Solid Waste and Emergency Response, Washington, DC, OSWER Directive 9200.1-120, February 6, 2014.
- U.S. Environmental Protection Agency (EPA), 2015a, OSWER Technical Guide for Assessing and Mitigating the Vapor Intrusion Pathway from Subsurface Vapor Sources to Indoor Air, Office of Solid Waste and Emergency Response, Washington, DC, OSWER Publication 9200.2-1154.
- U.S. Environmental Protection Agency (EPA), 2015b, Technical Guide for Addressing Petroleum Vapor Intrusion at Leaking Underground Storage Tank Sites, Office of Underground Storage Tanks, Washington, DC, EPA 510-R-15-001.

- U.S. Environmental Protection Agency (EPA), 2015c, Assessment of Mitigation Systems on Vapor Intrusion: Temporal Trends, Attenuation Factors, and Contaminant Migration Routes under Mitigated and non-Mitigated Conditions, Office of Research and Development, Washington, DC, EPA/600/R-13/241.
- U.S. Environmental Protection Agency (EPA), 2015d, Simple, Efficient, and Rapid Methods to Determine the Potential for Vapor Intrusion in the Home: Temporal Trends, Vapor Intrusion Forecasting, Sampling Strategies, and Contaminant Migration Routes, Office of Research and Development, Washington, DC, EPA/600/R-15/070.
- U.S. Environmental Protection Agency (EPA), 2016a, Regional Screening Levels for Chemical Contaminants at Superfund Sites—Generic Tables, Washington, DC.
- U.S. Environmental Protection Agency (EPA), 2016b, Regional Screening Levels for Chemical Contaminants at Superfund Sites—User’s Guide, Washington, DC.
- Yao, Y., R. Hen, K. G. Pennell, and E. M. Suuberg, 2011, Comparison of the Johnson–Ettinger vapor intrusion screening model predictions with full three-dimensional model results, *Environmental Science & Technology*, 45, 2227–2235.

# **TABLES**

**Table 1. Groundwater Statewide Health Standard Vapor Intrusion Screening Values (SV<sub>GW</sub>)**

Regulated Substance	CAS No.	Residential (µg/L)	Type	Nonresidential (µg/L)	Type	Converted Residential (µg/L)	Type
ACETALDEHYDE	75-07-0	5,300	SV	67,000	SV	22,000	SV
ACETONE	67-64-1	37,000,000	SV	470,000,000	SV	160,000,000	SV
ACETONITRILE	75-05-8	75,000	SV	940,000	SV	310,000	SV
ACROLEIN	107-02-8	6.8	SV	86	SV	29	SV
ACRYLAMIDE	79-06-1	3,200,000	SV	120,000,000	SV	41,000,000	SV
ACRYLIC ACID	79-10-7	150,000	SV	1,900,000	SV	650,000	SV
ACRYLONITRILE	107-13-1	110	SV	1,700	SV	560	SV
ALLYL ALCOHOL	107-18-6	1,000	SV	13,000	SV	4,300	SV
AMMONIA	7664-41-7	230,000	SV	2,900,000	SV	960,000	SV
ANILINE	62-53-3	27,000	SV	340,000	SV	110,000	SV
BENZENE	71-43-2	23	SV	350	SV	120	SV
BENZYL CHLORIDE	100-44-7	58	SV	870	SV	290	SV
BETA PROPIOLACTONE	57-57-8	0.012	MSC	0.063	MSC	0.063	MSC
BIPHENYL, 1,1-	92-52-4	91	MSC	970	SV	430	MSC
BIS(2-CHLOROETHYL)ETHER	111-44-4	240	SV	3,600	SV	1,200	SV
BIS(2-CHLORO-ISOPROPYL)ETHER	108-60-1	1,700	SV	25,000	SV	8,500	SV
BIS(CHLOROMETHYL)ETHER	542-88-1	0.0040	SV	0.060	SV	0.020	SV
BROMOCHLOROMETHANE	74-97-5	1,200	SV	15,000	SV	5,000	SV
BROMODICHLOROMETHANE	75-27-4	80	MSC	200	SV	80	MSC
BROMOMETHANE	74-83-9	26	SV	330	SV	110	SV
BUTADIENE, 1,3-	106-99-0	0.39	SV	5.9	SV	2.0	SV
CARBON DISULFIDE	75-15-0	2,000	SV	25,000	SV	8,200	SV
CARBON TETRACHLORIDE	56-23-5	6.0	SV	91	SV	30	SV
CHLORO-1,1-DIFLUOROETHANE, 1-	75-68-3	330,000	SV	1,400,000	Sol.	1,400,000	SV
CHLORO-1-PROPENE, 3- (ALLYL CHLORIDE)	107-05-1	3.8	SV	48	SV	16	SV
CHLOROBENZENE	108-90-7	760	SV	9,600	SV	3,200	SV
CHLORODIBROMOMETHANE	124-48-1	80	MSC	670	SV	220	SV
CHLORODIFLUOROMETHANE	75-45-6	110,000	MSC	540,000	SV	440,000	MSC
CHLOROETHANE	75-00-3	35,000	SV	440,000	SV	150,000	SV
CHLOROFORM	67-66-3	80	MSC	180	SV	80	MSC
CHLOROPRENE	126-99-8	0.16	MSC	0.90	SV	0.83	MSC
CHLOROPROPANE, 2-	75-29-6	230	SV	2,900	SV	970	SV
CRESOL(S)	1319-77-3	20,000,000	Sol.	20,000,000	Sol.	20,000,000	Sol.

**Table 1. Groundwater Statewide Health Standard Screening Values (cont.)**

Regulated Substance	CAS No.	Residential (□g/L)	Type	Nonresidential (□g/L)	Type	Converted Residential (□g/L)	Type
CUMENE (ISOPROPYL BENZENE)	98-82-8	1,900	SV	24,000	SV	8,000	SV
CYCLOHEXANE	110-82-7	13,000	MSC	53,000	MSC	53,000	MSC
CYCLOHEXANONE	108-94-1	4,000,000	SV	37,000,000	Sol.	17,000,000	SV
DIBROMO-3-CHLOROPROPANE, 1,2-	96-12-8	0.57	SV	22	SV	7.2	SV
DIBROMOETHANE, 1,2- (ETHYLENE DIBROMIDE)	106-93-4	2.9	SV	44	SV	15	SV
DIBROMOMETHANE	74-95-3	220	SV	2,800	SV	920	SV
DICHLORO-2-BUTENE, 1,4-	764-41-0	0.42	SV	6.3	SV	2.1	SV
DICHLORO-2-BUTENE, TRANS-1,4-	110-57-6	0.42	SV	6.4	SV	2.1	SV
DICHLOROBENZENE, 1,2-	95-50-1	5,400	SV	69,000	SV	23,000	SV
DICHLOROBENZENE, P-	106-46-7	75	MSC	680	SV	230	SV
DICHLORODIFLUOROMETHANE (FREON 12)	75-71-8	1,000	MSC	1,000	MSC	1,000	MSC
DICHLOROETHANE, 1,1-	75-34-3	110	SV	1,600	SV	550	SV
DICHLOROETHANE, 1,2-	107-06-2	34	SV	510	SV	170	SV
DICHLOROETHYLENE, 1,1-	75-35-4	300	SV	3,800	SV	1,300	SV
DICHLOROETHYLENE, TRANS-1,2-	156-60-5	600	SV	7,600	SV	2,500	SV
DICHLOROMETHANE (METHYLENE CHLORIDE)	75-09-2	7,600	SV	95,000	SV	32,000	SV
DICHLOROPROPANE, 1,2-	78-87-5	37	SV	560	SV	190	SV
DICHLOROPROPENE, 1,3-	542-75-6	75	SV	1,100	SV	380	SV
DICYCLOPENTADIENE	77-73-6	0.63	MSC	2.6	MSC	2.6	MSC
DIOXANE, 1,4-	123-91-1	30,000	SV	450,000	SV	150,000	SV
EPICHLOROHYDRIN	106-89-8	930	SV	12,000	SV	3,900	SV
ETHOXYETHANOL, 2- (EGEE)	110-80-5	22,000,000	SV	280,000,000	SV	94,000,000	SV
ETHYL ACETATE	141-78-6	23,000	SV	290,000	SV	98,000	SV
ETHYL ACRYLATE	140-88-5	1,100	SV	14,000	SV	4,700	SV
ETHYL BENZENE	100-41-4	700	MSC	860	SV	700	MSC
ETHYL METHACRYLATE	97-63-2	29,000	SV	370,000	SV	120,000	SV
ETHYLENE GLYCOL	107-21-1	420,000,000	SV	1,000,000,000	Sol.	1,000,000,000	Sol.
FLUOROTRICHLOROMETHANE (FREON 11)	75-69-4	2,000	MSC	3,600	SV	2,000	MSC
FORMALDEHYDE	50-00-0	200,000	SV	3,000,000	SV	990,000	SV
FORMIC ACID	64-18-6	69,000	SV	880,000	SV	290,000	SV
FURFURAL	98-01-1	700,000	SV	8,800,000	SV	2,900,000	SV

**Table 1. Groundwater Statewide Health Standard Screening Values (cont.)**

Regulated Substance	CAS No.	Residential (□g/L)	Type	Nonresidential (□g/L)	Type	Converted Residential (□g/L)	Type
HEXACHLOROETHANE	67-72-1	31	SV	480	SV	160	SV
HEXANE	110-54-3	1,500	MSC	6,200	MSC	6,200	MSC
HYDRAZINE/HYDRAZINE SULFATE	302-01-2	410	SV	6,200	SV	2,100	SV
METHACRYLONITRILE	126-98-7	5,400	SV	68,000	SV	23,000	SV
METHANOL	67-56-1	41,000,000	SV	510,000,000	SV	170,000,000	SV
METHOXYETHANOL, 2-	109-86-4	3,000,000	SV	38,000,000	SV	13,000,000	SV
METHYL ACRYLATE	96-33-3	4,400	SV	56,000	SV	19,000	SV
METHYL CHLORIDE	74-87-3	53	SV	810	SV	270	SV
METHYL ETHYL KETONE	78-93-3	3,900,000	SV	49,000,000	SV	16,000,000	SV
METHYL HYDRAZINE	60-34-4	320	SV	4,000	SV	1,300	SV
METHYL ISOBUTYL KETONE	108-10-1	1,000,000	SV	13,000,000	SV	4,300,000	SV
METHYL ISOCYANATE	624-83-9	44	SV	550	SV	180	SV
METHYL METHACRYLATE	80-62-6	110,000	SV	1,300,000	SV	450,000	SV
METHYL N-BUTYL KETONE (2-HEXANONE)	591-78-6	16,000	SV	200,000	SV	66,000	SV
METHYL STYRENE (MIXED ISOMERS)	25013-15-4	960	SV	12,000	SV	4,000	SV
METHYL TERT-BUTYL ETHER (MTBE)	1634-04-4	6,300	SV	96,000	SV	32,000	SV
METHYLNAPHTHALENE, 2-	91-57-6	380	SV	4,800	SV	1,600	SV
NAPHTHALENE	91-20-3	100	MSC	1,300	SV	440	SV
NITROBENZENE	98-95-3	1,400	SV	21,000	SV	7,000	SV
NITROPROPANE, 2-	79-46-9	3.4	SV	52	SV	17	SV
NITROSODIETHYLAMINE, N-	55-18-5	3.3	SV	120	SV	42	SV
NITROSODIMETHYLAMINE, N-	62-75-9	19	SV	710	SV	240	SV
NITROSO-DI-N-BUTYLAMINE, N-	924-16-3	91	SV	1,400	SV	460	SV
PCB-1221 (AROCLOR)	11104-28-2	3.5	SV	53	SV	18	SV
PCB-1232 (AROCLOR)	11141-16-5	3.6	SV	55	SV	18	SV
PHENOL	108-95-2	34,000,000	SV	84,000,000	Sol.	84,000,000	Sol.
PROPANOL, 2- (ISOPROPYL ALCOHOL)	67-63-0	1,200,000	SV	16,000,000	SV	5,200,000	SV
PROPYLBENZENE, N-	103-65-1	4,900	SV	52,000	Sol.	21,000	SV
PROPYLENE OXIDE	75-56-9	3,700	SV	56,000	SV	19,000	SV
STYRENE	100-42-5	18,000	SV	220,000	SV	75,000	SV
TETRACHLOROETHANE, 1,1,1,2-	630-20-6	70	MSC	980	SV	330	SV
TETRACHLOROETHANE, 1,1,2,2-	79-34-5	54	SV	820	SV	270	SV
TETRACHLOROETHYLENE (PCE)	127-18-4	110	SV	1,300	SV	440	SV

**Table 1. Groundwater Statewide Health Standard Screening Values (cont.)**

Regulated Substance	CAS No.	Residential (□g/L)	Type	Nonresidential (□g/L)	Type	Converted Residential (□g/L)	Type
TETRAHYDROFURAN	109-99-9	26	MSC	130	MSC	130	MSC
TOLUENE	108-88-3	34,000	SV	430,000	SV	140,000	SV
TRIBROMOMETHANE (BROMOFORM)	75-25-2	2,000	SV	30,000	SV	10,000	SV
TRICHLORO-1,2,2-TRIFLUOROETHANE, 1,1,2-	76-13-1	63,000	MSC	170,000	Sol.	170,000	Sol.
TRICHLOROBENZENE, 1,2,4-	120-82-1	80	SV	1,000	SV	340	SV
TRICHLOROBENZENE, 1,3,5-	108-70-3	59	SV	740	SV	250	SV
TRICHLOROETHANE, 1,1,1-	71-55-6	12,000	SV	160,000	SV	52,000	SV
TRICHLOROETHANE, 1,1,2-	79-00-5	11	SV	140	SV	48	SV
TRICHLOROETHYLENE (TCE)	79-01-6	9.0	SV	110	SV	38	SV
TRICHLOROPROPANE, 1,2,3-	96-18-4	44	SV	560	SV	190	SV
TRICHLOROPROPENE, 1,2,3-	96-19-5	0.83	SV	10	SV	3.5	SV
TRIETHYLAMINE	121-44-8	2,200	SV	27,000	SV	9,100	SV
TRIMETHYLBENZENE, 1,3,4- (TRIMETHYLBENZENE, 1,2,4-)	95-63-6	59	SV	750	SV	250	SV
TRIMETHYLBENZENE, 1,3,5-	108-67-8	420	MSC	1,200	MSC	1,200	MSC
VINYL ACETATE	108-05-4	18,000	SV	220,000	SV	74,000	SV
VINYL BROMIDE (BROMOETHENE)	593-60-2	2.2	SV	34	SV	11	SV
VINYL CHLORIDE	75-01-4	2.0	MSC	52	SV	17	SV
XYLENES (TOTAL)	1330-20-7	10,000	MSC	12,000	SV	10,000	MSC

**Note:** These groundwater screening values apply to depths of five feet or greater below the bottom of the building foundation.

Screening values for depths less than five feet are the used aquifer groundwater MSCs (Title 25 Pa. Code Ch. 250, Appendix A, Table 1)

**Type:** SV—calculated screening value

MSC—medium specific concentration (Title 25 Pa. Code Ch. 250, Appendix A, Table 1)

Sol.—aqueous solubility



**Table 2. Soil Statewide Health Standard Vapor Intrusion Screening Values (SV<sub>SOIL</sub>)**

Regulated Substance	CAS No.	Residential (mg/kg)	Type	Nonresidential (mg/kg)	Type	Converted Residential (mg/kg)	Type
ACETALDEHYDE	75-07-0	0.23	SGN	0.96	SGN	0.96	SGN
ACETONE	67-64-1	430	SGN	4,700	SV	1,200	SGN
ACETONITRILE	75-05-8	1.5	SGN	9.6	SV	6.0	SGN
ACROLEIN	107-02-8	0.00047	SGN	0.0020	SGN	0.0020	SGN
ACRYLAMIDE	79-06-1	37	SV	2,400	SV	480	SV
ACRYLIC ACID	79-10-7	1.9	SV	40	SV	8.1	SV
ACRYLONITRILE	107-13-1	0.010	SGN	0.051	SGN	0.051	SGN
ALLYL ALCOHOL	107-18-6	0.0068	SV	0.14	SV	0.029	SV
AMMONIA	7664-41-7	360	SGN	360	SGN	360	SGN
ANILINE	62-53-3	1.3	SV	27	SV	5.4	SV
BENZENE	71-43-2	0.13	SGN	0.13	SGN	0.13	SGN
BENZYL CHLORIDE	100-44-7	0.059	SGN	0.30	SGN	0.30	SGN
BETA PROPIOLACTONE	57-57-8	0.00015	SGN	0.00076	SGN	0.00076	SGN
BIPHENYL, 1,1-	92-52-4	40	SGN	190	SGN	190	SGN
BIS(2-CHLOROETHYL)ETHER	111-44-4	0.0056	SV	0.14	SV	0.028	SV
BIS(2-CHLORO-ISOPROPYL)ETHER	108-60-1	8.0	SGN	8.0	SGN	8.0	SGN
BIS(CHLOROMETHYL)ETHER	542-88-1	0.000012	SGN	0.000060	SGN	0.000060	SGN
BROMOCHLOROMETHANE	74-97-5	1.6	SGN	1.6	SGN	1.6	SGN
BROMODICHLOROMETHANE	75-27-4	2.7	SGN	2.7	SGN	2.7	SGN
BROMOMETHANE	74-83-9	0.54	SGN	0.54	SGN	0.54	SGN
BUTADIENE, 1,3-	106-99-0	0.0086	SGN	0.041	SGN	0.041	SGN
CARBON DISULFIDE	75-15-0	130	SGN	530	SGN	530	SGN
CARBON TETRACHLORIDE	56-23-5	0.26	SGN	0.26	SGN	0.26	SGN
CHLORO-1,1-DIFLUOROETHANE, 1-	75-68-3	1,800	SGN	7,300	SGN	7,300	SGN
CHLORO-1-PROPENE, 3- (ALLYL CHLORIDE)	107-05-1	0.049	SGN	0.20	SGN	0.20	SGN
CHLOROBENZENE	108-90-7	6.1	SGN	6.1	SGN	6.1	SGN
CHLORODIBROMOMETHANE	124-48-1	2.5	SGN	2.5	SGN	2.5	SGN
CHLORODIFLUOROMETHANE	75-45-6	2,800	SGN	10,000	SAT	10,000	SAT
CHLOROETHANE	75-00-3	5.4	SGN	26	SGN	26	SGN
CHLOROFORM	67-66-3	2.0	SGN	2.0	SGN	2.0	SGN
CHLOROPRENE	126-99-8	0.0038	SGN	0.020	SGN	0.020	SGN
CHLOROPROPANE, 2-	75-29-6	16	SGN	67	SGN	67	SGN
CRESOL(S)	1319-77-3	310	SV	6,600	SV	1,300	SV

**Table 2. Soil Statewide Health Standard Screening Values (cont.)**

Regulated Substance	CAS No.	Residential (mg/kg)	Type	Nonresidential (mg/kg)	Type	Converted Residential (mg/kg)	Type
CUMENE (ISOPROPYL BENZENE)	98-82-8	600	SGN	2,500	SGN	2,500	SGN
CYCLOHEXANE	110-82-7	1,700	SGN	6,900	SGN	6,900	SGN
CYCLOHEXANONE	108-94-1	84	SV	1,800	SV	350	SV
DIBROMO-3-CHLOROPROPANE, 1,2-	96-12-8	0.0092	SGN	0.0092	SGN	0.0092	SGN
DIBROMOETHANE, 1,2-(ETHYLENE DIBROMIDE)	106-93-4	0.0012	SGN	0.0013	SV	0.0012	SGN
DIBROMOMETHANE	74-95-3	0.32	SGN	1.4	SGN	1.4	SGN
DICHLORO-2-BUTENE, 1,4-	764-41-0	0.00067	SGN	0.0034	SGN	0.0034	SGN
DICHLORO-2-BUTENE, TRANS-1,4-	110-57-6	0.00078	SGN	0.0039	SGN	0.0039	SGN
DICHLOROBENZENE, 1,2-	95-50-1	59	SGN	59	SGN	59	SGN
DICHLOROBENZENE, P-	106-46-7	10	SGN	10	SGN	10	SGN
DICHLORODIFLUOROMETHANE (FREON 12)	75-71-8	100	SGN	100	SGN	100	SGN
DICHLOROETHANE, 1,1-	75-34-3	0.75	SGN	3.9	SGN	3.9	SGN
DICHLOROETHANE, 1,2-	107-06-2	0.10	SGN	0.10	SGN	0.10	SGN
DICHLOROETHYLENE, 1,1-	75-35-4	0.19	SGN	0.19	SGN	0.19	SGN
DICHLOROETHYLENE, TRANS-1,2-	156-60-5	2.3	SGN	2.3	SGN	2.3	SGN
DICHLOROMETHANE (METHYLENE CHLORIDE)	75-09-2	0.076	SGN	1.5	SV	0.30	SV
DICHLOROPROPANE, 1,2-	78-87-5	0.11	SGN	0.11	SGN	0.11	SGN
DICHLOROPROPENE, 1,3-	542-75-6	0.13	SGN	0.61	SGN	0.61	SGN
DICYCLOPENTADIENE	77-73-6	0.13	SGN	0.56	SGN	0.56	SGN
DIOXANE, 1,4-	123-91-1	0.23	SV	5.9	SV	1.2	SV
EPICHLOROHYDRIN	106-89-8	0.042	SGN	0.27	SV	0.17	SGN
ETHOXYETHANOL, 2- (EGEE)	110-80-5	190	SV	4,100	SV	820	SV
ETHYL ACETATE	141-78-6	3.9	SGN	16	SGN	16	SGN
ETHYL ACRYLATE	140-88-5	0.58	SGN	2.7	SGN	2.7	SGN
ETHYL BENZENE	100-41-4	46	SGN	46	SGN	46	SGN
ETHYL METHACRYLATE	97-63-2	10	SGN	43	SGN	43	SGN
ETHYLENE GLYCOL	107-21-1	3,000	SV	10,000	SAT	10,000	SAT
FLUOROTRICHLOROMETHANE (FREON 11)	75-69-4	87	SGN	87	SGN	87	SGN
FORMALDEHYDE	50-00-0	12	SGN	34	SV	12	SGN
FORMIC ACID	64-18-6	0.40	SV	8.9	SV	1.8	SV
FURFURAL	98-01-1	5.2	SV	110	SV	22	SV

**Table 2. Soil Statewide Health Standard Screening Values (cont.)**

Regulated Substance	CAS No.	Residential (mg/kg)	Type	Nonresidential (mg/kg)	Type	Converted Residential (mg/kg)	Type
HEXACHLOROETHANE	67-72-1	0.56	SGN	0.56	SGN	0.56	SGN
HEXANE	110-54-3	1,400	SGN	5,600	SGN	5,600	SGN
HYDRAZINE/HYDRAZINE SULFATE	302-01-2	0.0025	SV	0.063	SV	0.013	SV
METHACRYLONITRILE	126-98-7	0.069	SGN	1.2	SV	0.24	SV
METHANOL	67-56-1	270	SV	5,600	SV	1,100	SV
METHOXYETHANOL, 2-	109-86-4	18	SV	380	SV	75	SV
METHYL ACRYLATE	96-33-3	1.0	SGN	5	SGN	5	SGN
METHYL CHLORIDE	74-87-3	0.38	SGN	0.38	SGN	0.38	SGN
METHYL ETHYL KETONE	78-93-3	76	SGN	1,100	SV	210	SV
METHYL HYDRAZINE	60-34-4	0.0020	SV	0.041	SV	0.0082	SV
METHYL ISOBUTYL KETONE	108-10-1	51	SGN	210	SV	140	SGN
METHYL ISOCYANATE	624-83-9	0.029	SGN	0.12	SGN	0.12	SGN
METHYL METHACRYLATE	80-62-6	20	SGN	84	SGN	84	SGN
METHYL N-BUTYL KETONE (2-HEXANONE)	591-78-6	1.6	SGN	6.4	SGN	6.4	SGN
METHYL STYRENE (MIXED ISOMERS)	25013-15-4	47	SGN	200	SGN	200	SGN
METHYL TERT-BUTYL ETHER (MTBE)	1634-04-4	0.28	SGN	1.4	SV	0.28	SGN
METHYLNAPHTHALENE, 2-	91-57-6	680	SGN	1,900	SGN	1,900	SGN
NAPHTHALENE	91-20-3	25	SGN	25	SGN	25	SGN
NITROBENZENE	98-95-3	3.6	SGN	10	SGN	10	SGN
NITROPROPANE, 2-	79-46-9	0.00029	SGN	0.0015	SGN	0.0015	SGN
NITROSODIETHYLAMINE, N-	55-18-5	0.000039	SV	0.0025	SV	0.00049	SV
NITROSODIMETHYLAMINE, N-	62-75-9	0.00015	SV	0.0094	SV	0.0019	SV
NITROSO-DI-N-BUTYLAMINE, N-	924-16-3	0.017	SGN	0.25	SV	0.078	SGN
PCB-1221 (AROCLOR)	11104-28-2	0.18	SGN	0.83	SGN	0.83	SGN
PCB-1232 (AROCLOR)	11141-16-5	0.14	SGN	0.7	SGN	0.7	SGN
PHENOL	108-95-2	380	SV	7,900	SV	1,600	SV
PROPANOL, 2- (ISOPROPYL ALCOHOL)	67-63-0	15	SV	300	SV	61	SV
PROPYLBENZENE, N-	103-65-1	400	SGN	1,700	SGN	1,700	SGN
PROPYLENE OXIDE	75-56-9	0.052	SGN	1.1	SV	0.24	SGN
STYRENE	100-42-5	24	SGN	79	SV	24	SGN
TETRACHLOROETHANE, 1,1,1,2-	630-20-6	18	SGN	18	SGN	18	SGN
TETRACHLOROETHANE, 1,1,2,2-	79-34-5	0.026	SGN	0.13	SGN	0.13	SGN
TETRACHLOROETHYLENE (PCE)	127-18-4	0.43	SGN	0.43	SGN	0.43	SGN

**Table 2. Soil Statewide Health Standard Screening Values (cont.)**

Regulated Substance	CAS No.	Residential (mg/kg)	Type	Nonresidential (mg/kg)	Type	Converted Residential (mg/kg)	Type
TETRAHYDROFURAN	109-99-9	0.57	SGN	2.8	SGN	2.8	SGN
TOLUENE	108-88-3	44	SGN	44	SGN	44	SGN
TRIBROMOMETHANE (BROMOFORM)	75-25-2	3.5	SGN	3.5	SGN	3.5	SGN
TRICHLORO-1,2,2-TRIFLUOROETHANE, 1,1,2-	76-13-1	10,000	SAT	10,000	SAT	10,000	SAT
TRICHLOROBENZENE, 1,2,4-	120-82-1	27	SGN	27	SGN	27	SGN
TRICHLOROBENZENE, 1,3,5-	108-70-3	31	SGN	31	SGN	31	SGN
TRICHLOROETHANE, 1,1,1-	71-55-6	7.2	SGN	7.4	SV	7.2	SGN
TRICHLOROETHANE, 1,1,2-	79-00-5	0.15	SGN	0.15	SGN	0.15	SGN
TRICHLOROETHYLENE (TCE)	79-01-6	0.17	SGN	0.17	SGN	0.17	SGN
TRICHLOROPROPANE, 1,2,3-	96-18-4	3.2	SGN	3.2	SGN	3.2	SGN
TRICHLOROPROPENE, 1,2,3-	96-19-5	0.037	SGN	0.15	SGN	0.15	SGN
TRIETHYLAMINE	121-44-8	0.36	SGN	1.5	SGN	1.5	SGN
TRIMETHYLBENZENE, 1,3,4- (TRIMETHYLBENZENE, 1,2,4-)	95-63-6	8.4	SGN	35	SGN	35	SGN
TRIMETHYLBENZENE, 1,3,5-	108-67-8	74	SGN	210	SGN	210	SGN
VINYL ACETATE	108-05-4	5.0	SGN	21	SGN	21	SGN
VINYL BROMIDE (BROMOETHENE)	593-60-2	0.073	SGN	0.38	SGN	0.38	SGN
VINYL CHLORIDE	75-01-4	0.027	SGN	0.027	SGN	0.027	SGN
XYLENES (TOTAL)	1330-20-7	990	SGN	990	SGN	990	SGN

**Type:** SV—calculated screening value

SGN—generic soil-to-groundwater numeric value (Title 25 Pa. Code Ch. 250, Appendix A, Table 3B)

SAT—residual saturation limit

**Table 3. Near-Source Soil Gas Statewide Health Standard Vapor Intrusion Screening Values (SV<sub>NS</sub>)**

Regulated Substance	CAS No.	Residential ( $\mu\text{g}/\text{m}^3$ )	Nonresidential ( $\mu\text{g}/\text{m}^3$ )	Converted Residential ( $\mu\text{g}/\text{m}^3$ )
ACETALDEHYDE	75-07-0	1,900	39,000	7,900
ACETONE	67-64-1	6,500,000	140,000,000	27,000,000
ACETONITRILE	75-05-8	13,000	260,000	53,000
ACROLEIN	107-02-8	4.2	88	18
ACRYLAMIDE	79-06-1	19	1,200	250
ACRYLIC ACID	79-10-7	210	4,400	880
ACRYLONITRILE	107-13-1	72	1,800	360
ALLYL ALCOHOL	107-18-6	21	440	88
AMMONIA	7664-41-7	21,000	440,000	88,000
ANILINE	62-53-3	210	4,400	880
BENZENE	71-43-2	620	16,000	3,100
BENZYL CHLORIDE	100-44-7	99	2,500	500
BETA PROPIOLACTONE	57-57-8	1.2	31	6.1
BIPHENYL, 1,1-	92-52-4	83	1,800	350
BIS(2-CHLOROETHYL)ETHER	111-44-4	15	370	74
BIS(2-CHLORO-ISOPROPYL)ETHER	108-60-1	490	12,000	2,500
BIS(CHLOROMETHYL)ETHER	542-88-1	0.079	2.0	0.40
BROMOCHLOROMETHANE	74-97-5	8,300	180,000	35,000
BROMODICHLOROMETHANE	75-27-4	130	3,300	660
BROMOMETHANE	74-83-9	1,000	22,000	4,400
BUTADIENE, 1,3-	106-99-0	160	4,100	820
CARBON DISULFIDE	75-15-0	150,000	3,100,000	610,000
CARBON TETRACHLORIDE	56-23-5	810	20,000	4,100
CHLORO-1,1-DIFLUOROETHANE, 1-	75-68-3	10,000,000	220,000,000	44,000,000
CHLORO-1-PROPENE, 3- (ALLYL CHLORIDE)	107-05-1	210	4,400	880
CHLOROBENZENE	108-90-7	10,000	220,000	44,000
CHLORODIBROMOMETHANE	124-48-1	180	4,500	910
CHLORODIFLUOROMETHANE	75-45-6	10,000,000	220,000,000	44,000,000
CHLOROETHANE	75-00-3	2,100,000	44,000,000	8,800,000
CHLOROFORM	67-66-3	210	5,300	1,100
CHLOROPRENE	126-99-8	16	410	82
CHLOROPROPANE, 2-	75-29-6	21,000	440,000	88,000

**Table 3. Near-Source Soil Gas Statewide Health Standard Screening Values (cont.)**

Regulated Substance	CAS No.	Residential ( $\mu\text{g}/\text{m}^3$ )	Nonresidential ( $\mu\text{g}/\text{m}^3$ )	Converted Residential ( $\mu\text{g}/\text{m}^3$ )
CRESOL(S)	1319-77-3	130,000	2,600,000	530,000
CUMENE (ISOPROPYL BENZENE)	98-82-8	83,000	1,800,000	350,000
CYCLOHEXANE	110-82-7	1,300,000	26,000,000	5,300,000
CYCLOHEXANONE	108-94-1	150,000	3,100,000	610,000
DIBROMO-3-CHLOROPROPANE, 1,2-	96-12-8	0.32	20	4.1
DIBROMOETHANE, 1,2- (ETHYLENE DIBROMIDE)	106-93-4	8.1	200	41
DIBROMOMETHANE	74-95-3	830	18,000	3,500
DICHLORO-2-BUTENE, 1,4-	764-41-0	1.2	29	5.8
DICHLORO-2-BUTENE, TRANS-1,4-	110-57-6	1.2	29	5.8
DICHLOROBENZENE, 1,2-	95-50-1	42,000	880,000	180,000
DICHLOROBENZENE, P-	106-46-7	440	11,000	2,200
DICHLORODIFLUOROMETHANE (FREON 12)	75-71-8	21,000	440,000	88,000
DICHLOROETHANE, 1,1-	75-34-3	3,000	77,000	15,000
DICHLOROETHANE, 1,2-	107-06-2	190	4,700	940
DICHLOROETHYLENE, 1,1-	75-35-4	42,000	880,000	180,000
DICHLOROETHYLENE, TRANS-1,2-	156-60-5	13,000	260,000	53,000
DICHLOROMETHANE (METHYLENE CHLORIDE)	75-09-2	130,000	2,600,000	530,000
DICHLOROPROPANE, 1,2-	78-87-5	490	12,000	2,500
DICHLOROPROPENE, 1,3-	542-75-6	1,200	31,000	6,100
DICYCLOPENTADIENE	77-73-6	63	1,300	260
DIOXANE, 1,4-	123-91-1	630	16,000	3,200
EPICHLOROHYDRIN	106-89-8	210	4,400	880
ETHOXYETHANOL, 2- (EGEE)	110-80-5	42,000	880,000	180,000
ETHYL ACETATE	141-78-6	15,000	310,000	61,000
ETHYL ACRYLATE	140-88-5	1,700	35,000	7,000
ETHYL BENZENE	100-41-4	1,900	49,000	9,800
ETHYL METHACRYLATE	97-63-2	63,000	1,300,000	260,000
ETHYLENE GLYCOL	107-21-1	83,000	1,800,000	350,000
FLUOROTRICHLOROMETHANE (FREON 11)	75-69-4	150,000	3,100,000	610,000
FORMALDEHYDE	50-00-0	370	9,400	1,900
FORMIC ACID	64-18-6	63	1,300	260
FURFURAL	98-01-1	10,000	220,000	44,000

**Table 3. Near-Source Soil Gas Statewide Health Standard Screening Values (cont.)**

Regulated Substance	CAS No.	Residential ( $\mu\text{g}/\text{m}^3$ )	Nonresidential ( $\mu\text{g}/\text{m}^3$ )	Converted Residential ( $\mu\text{g}/\text{m}^3$ )
HEXACHLOROETHANE	67-72-1	490	12,000	2,500
HEXANE	110-54-3	150,000	3,100,000	610,000
HYDRAZINE/HYDRAZINE SULFATE	302-01-2	1.0	25	5.0
METHACRYLONITRILE	126-98-7	6,300	130,000	26,000
METHANOL	67-56-1	830,000	18,000,000	3,500,000
METHOXYETHANOL, 2-	109-86-4	4,200	88,000	18,000
METHYL ACRYLATE	96-33-3	4,200	88,000	18,000
METHYL CHLORIDE	74-87-3	2,700	68,000	14,000
METHYL ETHYL KETONE	78-93-3	1,000,000	22,000,000	4,400,000
METHYL HYDRAZINE	60-34-4	4.2	88	18
METHYL ISOBUTYL KETONE	108-10-1	630,000	13,000,000	2,600,000
METHYL ISOCYANATE	624-83-9	210	4,400	880
METHYL METHACRYLATE	80-62-6	150,000	3,100,000	610,000
METHYL N-BUTYL KETONE (2-HEXANONE)	591-78-6	6,300	130,000	26,000
METHYL STYRENE (MIXED ISOMERS)	25013-15-4	8,300	180,000	35,000
METHYL TERT-BUTYL ETHER (MTBE)	1634-04-4	19,000	470,000	94,000
METHYLNAPHTHALENE, 2-	91-57-6	630	13,000	2,600
NAPHTHALENE	91-20-3	140	3,600	720
NITROBENZENE	98-95-3	120	3,100	610
NITROPROPANE, 2-	79-46-9	1.8	45	9.1
NITROSODIETHYLAMINE, N-	55-18-5	0.045	2.9	0.57
NITROSODIMETHYLAMINE, N-	62-75-9	0.14	8.8	1.8
NITROSO-DI-N-BUTYLAMINE, N-	924-16-3	3.0	77	15
PCB-1221 (AROCLOR)	11104-28-2	8.5	220	43
PCB-1232 (AROCLOR)	11141-16-5	8.5	220	43
PHENOL	108-95-2	42,000	880,000	180,000
PROPANOL, 2- (ISOPROPYL ALCOHOL)	67-63-0	42,000	880,000	180,000
PROPYLBENZENE, N-	103-65-1	210,000	4,400,000	880,000
PROPYLENE OXIDE	75-56-9	1,300	33,000	6,600
STYRENE	100-42-5	210,000	4,400,000	880,000
TETRACHLOROETHANE, 1,1,1,2-	630-20-6	660	17,000	3,300
TETRACHLOROETHANE, 1,1,2,2-	79-34-5	84	2,100	420
TETRACHLOROETHYLENE (PCE)	127-18-4	8,300	180,000	35,000

**Table 3. Near-Source Soil Gas Statewide Health Standard Screening Values (cont.)**

Regulated Substance	CAS No.	Residential ( $\mu\text{g}/\text{m}^3$ )	Nonresidential ( $\mu\text{g}/\text{m}^3$ )	Converted Residential ( $\mu\text{g}/\text{m}^3$ )
TETRAHYDROFURAN	109-99-9	2,500	63,000	13,000
TOLUENE	108-88-3	1,000,000	22,000,000	4,400,000
TRIBROMOMETHANE (BROMOFORM)	75-25-2	4,400	110,000	22,000
TRICHLORO-1,2,2-TRIFLUOROETHANE, 1,1,2-	76-13-1	6,300,000	130,000,000	26,000,000
TRICHLOROBENZENE, 1,2,4-	120-82-1	420	8,800	1,800
TRICHLOROBENZENE, 1,3,5-	108-70-3	420	8,800	1,800
TRICHLOROETHANE, 1,1,1-	71-55-6	1,000,000	22,000,000	4,400,000
TRICHLOROETHANE, 1,1,2-	79-00-5	42	880	180
TRICHLOROETHYLENE (TCE)	79-01-6	420	8,800	1,800
TRICHLOROPROPANE, 1,2,3-	96-18-4	63	1,300	260
TRICHLOROPROPENE, 1,2,3-	96-19-5	63	1,300	260
TRIETHYLAMINE	121-44-8	1,500	31,000	6,100
TRIMETHYLBENZENE, 1,3,4- (TRIMETHYLBENZENE, 1,2,4-)	95-63-6	1,500	31,000	6,100
TRIMETHYLBENZENE, 1,3,5-	108-67-8	1,500	31,000	6,100
VINYL ACETATE	108-05-4	42,000	880,000	180,000
VINYL BROMIDE (BROMOETHENE)	593-60-2	150	3,800	770
VINYL CHLORIDE	75-01-4	160	14,000	2,700
XYLENES (TOTAL)	1330-20-7	21,000	440,000	88,000



**Table 4. Sub-Slab Soil Gas Statewide Health Standard Vapor Intrusion Screening Values (SV<sub>SS</sub>)**

Regulated Substance	CAS No.	Residential ( $\mu\text{g}/\text{m}^3$ )	Nonresidential ( $\mu\text{g}/\text{m}^3$ )	Converted Residential ( $\mu\text{g}/\text{m}^3$ )
ACETALDEHYDE	75-07-0	360	5,100	1,500
ACETONE	67-64-1	1,200,000	17,000,000	5,200,000
ACETONITRILE	75-05-8	2,400	34,000	10,000
ACROLEIN	107-02-8	0.80	11	3.4
ACRYLAMIDE	79-06-1	3.7	160	47
ACRYLIC ACID	79-10-7	40	560	170
ACRYLONITRILE	107-13-1	14	230	69
ALLYL ALCOHOL	107-18-6	4.0	56	17
AMMONIA	7664-41-7	4,000	56,000	17,000
ANILINE	62-53-3	40	560	170
BENZENE	71-43-2	120	2,000	610
BENZYL CHLORIDE	100-44-7	19	320	96
BETA PROPIOLACTONE	57-57-8	0.23	3.9	1.2
BIPHENYL, 1,1-	92-52-4	16	220	67
BIS(2-CHLOROETHYL)ETHER	111-44-4	2.8	48	14
BIS(2-CHLORO-ISOPROPYL)ETHER	108-60-1	94	1,600	470
BIS(CHLOROMETHYL)ETHER	542-88-1	0.015	0.25	0.076
BROMOCHLOROMETHANE	74-97-5	1,600	22,000	6,700
BROMODICHLOROMETHANE	75-27-4	25	430	130
BROMOMETHANE	74-83-9	200	2,800	840
BUTADIENE, 1,3-	106-99-0	31	520	160
CARBON DISULFIDE	75-15-0	28,000	390,000	120,000
CARBON TETRACHLORIDE	56-23-5	160	2,600	790
CHLORO-1,1-DIFLUOROETHANE, 1-	75-68-3	2,000,000	28,000,000	8,400,000
CHLORO-1-PROPENE, 3- (ALLYL CHLORIDE)	107-05-1	40	560	170
CHLOROBENZENE	108-90-7	2,000	28,000	8,400
CHLORODIBROMOMETHANE	124-48-1	35	580	170
CHLORODIFLUOROMETHANE	75-45-6	2,000,000	28,000,000	8,400,000
CHLOROETHANE	75-00-3	400,000	5,600,000	1,700,000
CHLOROFORM	67-66-3	41	680	210
CHLOROPRENE	126-99-8	3.1	52	16
CHLOROPROPANE, 2-	75-29-6	4,000	56,000	17,000

**Table 4. Sub-Slab Soil Gas Statewide Health Standard Screening Values (cont.)**

Regulated Substance	CAS No.	Residential ( $\mu\text{g}/\text{m}^3$ )	Nonresidential ( $\mu\text{g}/\text{m}^3$ )	Converted Residential ( $\mu\text{g}/\text{m}^3$ )
CRESOL(S)	1319-77-3	24,000	340,000	100,000
CUMENE (ISOPROPYL BENZENE)	98-82-8	16,000	220,000	67,000
CYCLOHEXANE	110-82-7	240,000	3,400,000	1,000,000
CYCLOHEXANONE	108-94-1	28,000	390,000	120,000
DIBROMO-3-CHLOROPROPANE, 1,2-	96-12-8	0.062	2.6	0.79
DIBROMOETHANE, 1,2- (ETHYLENE DIBROMIDE)	106-93-4	1.6	26	7.9
DIBROMOMETHANE	74-95-3	160	2,200	670
DICHLORO-2-BUTENE, 1,4-	764-41-0	0.22	3.7	1.1
DICHLORO-2-BUTENE, TRANS-1,4-	110-57-6	0.22	3.7	1.1
DICHLOROBENZENE, 1,2-	95-50-1	8,000	110,000	34,000
DICHLOROBENZENE, P-	106-46-7	85	1,400	430
DICHLORODIFLUOROMETHANE (FREON 12)	75-71-8	4,000	56,000	17,000
DICHLOROETHANE, 1,1-	75-34-3	590	9,800	3,000
DICHLOROETHANE, 1,2-	107-06-2	36	610	180
DICHLOROETHYLENE, 1,1-	75-35-4	8,000	110,000	34,000
DICHLOROETHYLENE, TRANS-1,2-	156-60-5	2,400	34,000	10,000
DICHLOROMETHANE (METHYLENE CHLORIDE)	75-09-2	24,000	340,000	100,000
DICHLOROPROPANE, 1,2-	78-87-5	94	1,600	470
DICHLOROPROPENE, 1,3-	542-75-6	230	3,900	1,200
DICYCLOPENTADIENE	77-73-6	12	170	51
DIOXANE, 1,4-	123-91-1	120	2,000	610
EPICHLOROHYDRIN	106-89-8	40	560	170
ETHOXYETHANOL, 2- (EGEE)	110-80-5	8,000	110,000	34,000
ETHYL ACETATE	141-78-6	2,800	39,000	12,000
ETHYL ACRYLATE	140-88-5	320	4,500	1,300
ETHYL BENZENE	100-41-4	370	6,300	1,900
ETHYL METHACRYLATE	97-63-2	12,000	170,000	51,000
ETHYLENE GLYCOL	107-21-1	16,000	220,000	67,000
FLUOROTRICHLOROMETHANE (FREON 11)	75-69-4	28,000	390,000	120,000
FORMALDEHYDE	50-00-0	72	1,200	360
FORMIC ACID	64-18-6	12	170	51
FURFURAL	98-01-1	2,000	28,000	8,400

**Table 4. Sub-Slab Soil Gas Statewide Health Standard Screening Values (cont.)**

Regulated Substance	CAS No.	Residential ( $\mu\text{g}/\text{m}^3$ )	Nonresidential ( $\mu\text{g}/\text{m}^3$ )	Converted Residential ( $\mu\text{g}/\text{m}^3$ )
HEXACHLOROETHANE	67-72-1	94	1,600	470
HEXANE	110-54-3	28,000	390,000	120,000
HYDRAZINE/HYDRAZINE SULFATE	302-01-2	0.19	3.2	1.0
METHACRYLONITRILE	126-98-7	1,200	17,000	5,100
METHANOL	67-56-1	160,000	2,200,000	670,000
METHOXYETHANOL, 2-	109-86-4	800	11,000	3,400
METHYL ACRYLATE	96-33-3	800	11,000	3,400
METHYL CHLORIDE	74-87-3	520	8,700	2,600
METHYL ETHYL KETONE	78-93-3	200,000	2,800,000	840,000
METHYL HYDRAZINE	60-34-4	0.80	11	3.4
METHYL ISOBUTYL KETONE	108-10-1	120,000	1,700,000	510,000
METHYL ISOCYANATE	624-83-9	40	560	170
METHYL METHACRYLATE	80-62-6	28,000	390,000	120,000
METHYL N-BUTYL KETONE (2-HEXANONE)	591-78-6	1,200	17,000	5,100
METHYL STYRENE (MIXED ISOMERS)	25013-15-4	1,600	22,000	6,700
METHYL TERT-BUTYL ETHER (MTBE)	1634-04-4	3,600	61,000	18,000
METHYLNAPHTHALENE, 2-	91-57-6	120	1,700	510
NAPHTHALENE	91-20-3	28	460	140
NITROBENZENE	98-95-3	23	390	120
NITROPROPANE, 2-	79-46-9	0.35	5.8	1.7
NITROSODIETHYLAMINE, N-	55-18-5	0.0086	0.37	0.11
NITROSODIMETHYLAMINE, N-	62-75-9	0.026	1.1	0.34
NITROSO-DI-N-BUTYLAMINE, N-	924-16-3	0.59	10	3.0
PCB-1221 (AROCLOR)	11104-28-2	1.6	28	8.3
PCB-1232 (AROCLOR)	11141-16-5	1.6	28	8.3
PHENOL	108-95-2	8,000	110,000	34,000
PROPANOL, 2- (ISOPROPYL ALCOHOL)	67-63-0	8,000	110,000	34,000
PROPYLBENZENE, N-	103-65-1	40,000	560,000	170,000
PROPYLENE OXIDE	75-56-9	250	4,300	1,300
STYRENE	100-42-5	40,000	560,000	170,000
TETRACHLOROETHANE, 1,1,1,2-	630-20-6	130	2,100	640
TETRACHLOROETHANE, 1,1,2,2-	79-34-5	16	270	81
TETRACHLOROETHYLENE (PCE)	127-18-4	1,600	22,000	6,700

**Table 4. Sub-Slab Soil Gas Statewide Health Standard Screening Values (cont.)**

Regulated Substance	CAS No.	Residential ( $\mu\text{g}/\text{m}^3$ )	Nonresidential ( $\mu\text{g}/\text{m}^3$ )	Converted Residential ( $\mu\text{g}/\text{m}^3$ )
TETRAHYDROFURAN	109-99-9	480	8,100	2,400
TOLUENE	108-88-3	200,000	2,800,000	840,000
TRIBROMOMETHANE (BROMOFORM)	75-25-2	850	14,000	4,300
TRICHLORO-1,2,2-TRIFLUOROETHANE, 1,1,2-	76-13-1	1,200,000	17,000,000	5,100,000
TRICHLOROBENZENE, 1,2,4-	120-82-1	80	1,100	340
TRICHLOROBENZENE, 1,3,5-	108-70-3	80	1,100	340
TRICHLOROETHANE, 1,1,1-	71-55-6	200,000	2,800,000	840,000
TRICHLOROETHANE, 1,1,2-	79-00-5	8.0	110	34
TRICHLOROETHYLENE (TCE)	79-01-6	80	1,100	340
TRICHLOROPROPANE, 1,2,3-	96-18-4	12	170	51
TRICHLOROPROPENE, 1,2,3-	96-19-5	12	170	51
TRIETHYLAMINE	121-44-8	280	3,900	1,200
TRIMETHYLBENZENE, 1,3,4- (TRIMETHYLBENZENE, 1,2,4-)	95-63-6	280	3,900	1,200
TRIMETHYLBENZENE, 1,3,5-	108-67-8	280	3,900	1,200
VINYL ACETATE	108-05-4	8,000	110,000	34,000
VINYL BROMIDE (BROMOETHENE)	593-60-2	29	490	150
VINYL CHLORIDE	75-01-4	30	1,700	520
XYLENES (TOTAL)	1330-20-7	4,000	56,000	17,000

**Table 5. Indoor Air Statewide Health Standard Vapor Intrusion Screening Values (SV<sub>IA</sub>)**

Regulated Substance	CAS No.	Residential (µg/m <sup>3</sup> )	Nonresidential (µg/m <sup>3</sup> )
ACETALDEHYDE	75-07-0	9.4	39
ACETONE	67-64-1	32,000	140,000
ACETONITRILE	75-05-8	63	260
ACROLEIN	107-02-8	0.021	0.088
ACRYLAMIDE	79-06-1	0.096	1.2
ACRYLIC ACID	79-10-7	1.0	4.4
ACRYLONITRILE	107-13-1	0.36	1.8
ALLYL ALCOHOL	107-18-6	0.10	0.44
AMMONIA	7664-41-7	100	440
ANILINE	62-53-3	1.0	4.4
BENZENE	71-43-2	3.1	16
BENZYL CHLORIDE	100-44-7	0.50	2.5
BETA PROIOLACTONE	57-57-8	0.0061	0.031
BIPHENYL, 1,1-	92-52-4	0.42	1.8
BIS(2-CHLOROETHYL)ETHER	111-44-4	0.074	0.37
BIS(2-CHLORO-ISOPROPYL)ETHER	108-60-1	2.4	12
BIS(CHLOROMETHYL)ETHER	542-88-1	0.00039	0.0020
BROMOCHLOROMETHANE	74-97-5	42	180
BROMODICHLOROMETHANE	75-27-4	0.66	3.3
BROMOMETHANE	74-83-9	5.2	22
BUTADIENE, 1,3-	106-99-0	0.81	4.1
CARBON DISULFIDE	75-15-0	730	3,100
CARBON TETRACHLORIDE	56-23-5	4.1	20
CHLORO-1,1-DIFLUOROETHANE, 1-	75-68-3	52,000	220,000
CHLORO-1-PROPENE, 3- (ALLYL CHLORIDE)	107-05-1	1.0	4.4
CHLOROBENZENE	108-90-7	52	220
CHLORODIBROMOMETHANE	124-48-1	0.90	4.5
CHLORODIFLUOROMETHANE	75-45-6	52,000	220,000
CHLOROETHANE	75-00-3	10,000	44,000
CHLOROFORM	67-66-3	1.1	5.3
CHLOROPRENE	126-99-8	0.081	0.41
CHLOROPROPANE, 2-	75-29-6	100	440
CRESOL(S)	1319-77-3	630	2,600

**Table 5. Indoor Air Statewide Health Standard Screening Values (cont.)**

Regulated Substance	CAS No.	Residential ( $\mu\text{g}/\text{m}^3$ )	Nonresidential ( $\mu\text{g}/\text{m}^3$ )
CUMENE (ISOPROPYL BENZENE)	98-82-8	420	1,800
CYCLOHEXANE	110-82-7	6,300	26,000
CYCLOHEXANONE	108-94-1	730	3,100
DIBROMO-3-CHLOROPROPANE, 1,2-	96-12-8	0.0016	0.020
DIBROMOETHANE, 1,2- (ETHYLENE DIBROMIDE)	106-93-4	0.041	0.20
DIBROMOMETHANE	74-95-3	4.2	18
DICHLORO-2-BUTENE, 1,4-	764-41-0	0.0058	0.029
DICHLORO-2-BUTENE, TRANS-1,4-	110-57-6	0.0058	0.029
DICHLOROBENZENE, 1,2-	95-50-1	210	880
DICHLOROBENZENE, P-	106-46-7	2.2	11
DICHLORODIFLUOROMETHANE (FREON 12)	75-71-8	100	440
DICHLOROETHANE, 1,1-	75-34-3	15	77
DICHLOROETHANE, 1,2-	107-06-2	0.94	4.7
DICHLOROETHYLENE, 1,1-	75-35-4	210	880
DICHLOROETHYLENE, TRANS-1,2-	156-60-5	63	260
DICHLOROMETHANE (METHYLENE CHLORIDE)	75-09-2	630	2,600
DICHLOROPROPANE, 1,2-	78-87-5	2.4	12
DICHLOROPROPENE, 1,3-	542-75-6	6.1	31
DICYCLOPENTADIENE	77-73-6	0.31	1.3
DIOXANE, 1,4-	123-91-1	3.2	16
EPICHLOROHYDRIN	106-89-8	1.0	4.4
ETHOXYETHANOL, 2- (EGEE)	110-80-5	210	880
ETHYL ACETATE	141-78-6	73	310
ETHYL ACRYLATE	140-88-5	8.3	35
ETHYL BENZENE	100-41-4	9.7	49
ETHYL METHACRYLATE	97-63-2	310	1,300
ETHYLENE GLYCOL	107-21-1	420	1,800
FLUOROTRICHLOROMETHANE (FREON 11)	75-69-4	730	3,100
FORMALDEHYDE	50-00-0	1.9	9.4
FORMIC ACID	64-18-6	0.31	1.3
FURFURAL	98-01-1	52	220
HEXACHLOROETHANE	67-72-1	2.4	12
HEXANE	110-54-3	730	3,100

**Table 5. Indoor Air Statewide Health Standard Screening Values (cont.)**

Regulated Substance	CAS No.	Residential ( $\mu\text{g}/\text{m}^3$ )	Nonresidential ( $\mu\text{g}/\text{m}^3$ )
HYDRAZINE/HYDRAZINE SULFATE	302-01-2	0.0050	0.025
METHACRYLONITRILE	126-98-7	31	130
METHANOL	67-56-1	4,200	18,000
METHOXYETHANOL, 2-	109-86-4	21	88
METHYL ACRYLATE	96-33-3	21	88
METHYL CHLORIDE	74-87-3	14	68
METHYL ETHYL KETONE	78-93-3	5,200	22,000
METHYL HYDRAZINE	60-34-4	0.021	0.088
METHYL ISOBUTYL KETONE	108-10-1	3,100	13,000
METHYL ISOCYANATE	624-83-9	1.0	4.4
METHYL METHACRYLATE	80-62-6	730	3,100
METHYL N-BUTYL KETONE (2-HEXANONE)	591-78-6	31	130
METHYL STYRENE (MIXED ISOMERS)	25013-15-4	42	180
METHYL TERT-BUTYL ETHER (MTBE)	1634-04-4	94	470
METHYLNAPHTHALENE, 2-	91-57-6	3.1	13
NAPHTHALENE	91-20-3	0.72	3.6
NITROBENZENE	98-95-3	0.61	3.1
NITROPROPANE, 2-	79-46-9	0.0090	0.045
NITROSODIETHYLAMINE, N-	55-18-5	0.00022	0.0029
NITROSODIMETHYLAMINE, N-	62-75-9	0.00069	0.0088
NITROSO-DI-N-BUTYLAMINE, N-	924-16-3	0.015	0.077
PCB-1221 (AROCFLOR)	11104-28-2	0.043	0.22
PCB-1232 (AROCFLOR)	11141-16-5	0.043	0.22
PHENOL	108-95-2	210	880
PROPANOL, 2- (ISOPROPYL ALCOHOL)	67-63-0	210	880
PROPYLBENZENE, N-	103-65-1	1,000	4,400
PROPYLENE OXIDE	75-56-9	6.6	33
STYRENE	100-42-5	1,000	4,400
TETRACHLOROETHANE, 1,1,1,2-	630-20-6	3.3	17
TETRACHLOROETHANE, 1,1,2,2-	79-34-5	0.42	2.1
TETRACHLOROETHYLENE (PCE)	127-18-4	42	180
TETRAHYDROFURAN	109-99-9	13	63
TOLUENE	108-88-3	5,200	22,000
TRIBROMOMETHANE (BROMOFORM)	75-25-2	22	110

**Table 5. Indoor Air Statewide Health Standard Screening Values (cont.)**

Regulated Substance	CAS No.	Residential ( $\mu\text{g}/\text{m}^3$ )	Nonresidential ( $\mu\text{g}/\text{m}^3$ )
TRICHLORO-1,2,2-TRIFLUOROETHANE, 1,1,2-	76-13-1	31,000	130,000
TRICHLOROBENZENE, 1,2,4-	120-82-1	2.1	8.8
TRICHLOROBENZENE, 1,3,5-	108-70-3	2.1	8.8
TRICHLOROETHANE, 1,1,1-	71-55-6	5,200	22,000
TRICHLOROETHANE, 1,1,2-	79-00-5	0.21	0.88
TRICHLOROETHYLENE (TCE)	79-01-6	2.1	8.8
TRICHLOROPROPANE, 1,2,3-	96-18-4	0.31	1.3
TRICHLOROPROPENE, 1,2,3-	96-19-5	0.31	1.3
TRIETHYLAMINE	121-44-8	7.3	31
TRIMETHYLBENZENE, 1,3,4- (TRIMETHYLBENZENE, 1,2,4-)	95-63-6	7.3	31
TRIMETHYLBENZENE, 1,3,5-	108-67-8	7.3	31
VINYL ACETATE	108-05-4	210	880
VINYL BROMIDE (BROMOETHENE)	593-60-2	0.76	3.8
VINYL CHLORIDE	75-01-4	0.79	14
XYLENES (TOTAL)	1330-20-7	100	440



**Table 6. Collection of Data for Vapor Intrusion Screening**

Sample	Conditions for VI Data Collection
Soil	<ul style="list-style-type: none"> <li>• Collect an appropriate number of samples to characterize the source(s) and/or demonstrate attainment.</li> <li>• The samples are from unsaturated soil.</li> <li>• No SPL is present.</li> </ul>
Groundwater	<ul style="list-style-type: none"> <li>• Install an appropriate number of monitoring wells to characterize the source(s) and/or demonstrate attainment.</li> <li>• Sample from properly constructed monitoring wells.</li> <li>• Sample at or near the water table.</li> <li>• Monitoring well screens cross the water table.</li> <li>• The wetted length of the well screen should be no more than 10 feet.</li> <li>• If the depth to water below the foundation is less than 5 feet then MSC-based screening values should be used.</li> <li>• Acceptable soil or soil-like material exists between the water table and the building foundation.</li> <li>• No SPL is present.</li> </ul>
Near-Source Soil Gas	<ul style="list-style-type: none"> <li>• Account for potential spatial variability in the sampling design based on the soil and groundwater data.</li> <li>• Collect at least two rounds of samples from at least two locations.</li> <li>• Locate sample points where they will be most representative of soil gas in potential VI sources and preferential pathways (if applicable).</li> <li>• The sample depth is within about 1 foot of the top of the capillary fringe for groundwater sources, considering the effects of water table fluctuations.</li> <li>• Sample above bedrock when the water table is within bedrock.</li> <li>• Sample within or no more than 1 foot above vadose zone soil sources.</li> <li>• Sample at least 5 feet below grade.</li> <li>• Acceptable soil or soil-like material exists between the source and the building foundation.</li> <li>• Refer to Appendix C.</li> </ul>
Sub-Slab Soil Gas	<ul style="list-style-type: none"> <li>• Account for potential spatial variability in the sampling design.</li> <li>• Collect at least two rounds of samples from at least two locations.</li> <li>• Bias sample points towards areas of greatest expected impact.</li> <li>• Refer to Appendix C.</li> </ul>
Indoor Air	<ul style="list-style-type: none"> <li>• Account for potential spatial variability in the sampling design.</li> <li>• Collect at least two rounds of samples from at least two locations.</li> <li>• Sample in the lowest occupied floor (basement and/or first floor).</li> <li>• Sample when the daily average outdoor temperature is at least 15°F (8°C) below the minimum indoor temperature of the occupied space.</li> <li>• Refer to Appendix C.</li> </ul>

**Table 7. Application of Statewide Health Standard Vapor Intrusion Screening Criteria**

Characterization Data	Vapor Intrusion Screening Conditions
Soil Characterization	<ul style="list-style-type: none"> <li>• Soil attains the Statewide health standard on the basis of the characterization data without remediation.</li> <li>• Use all applicable soil characterization data for VI screening.</li> <li>• If there are no exceedances of VI soil screening values (<math>SV_{SOIL}</math>), then the VI evaluation is complete. *</li> </ul>
Groundwater Characterization	<ul style="list-style-type: none"> <li>• Groundwater attains the Statewide health standard on the basis of the characterization data without remediation.</li> <li>• Use all applicable groundwater characterization data for VI screening.</li> <li>• Collect at least two rounds of data.</li> <li>• If there are no exceedances of vapor intrusion groundwater screening values (<math>SV_{GW}</math>), then the VI evaluation is complete. *</li> </ul>
Near-Source Soil Gas, Sub-Slab Soil Gas, or Indoor Air Characterization	<ul style="list-style-type: none"> <li>• The remediator may characterize and screen soil gas or indoor air with a limited number of sampling rounds.</li> <li>• Sample at least two locations and perform a minimum of two sampling events.</li> <li>• Collect samples at least 45 days apart.</li> <li>• If there are no exceedances of VI screening values (<math>SV_{NS}</math>, <math>SV_{SS}</math>, <math>SV_{IA}</math>) then the VI evaluation is complete. *</li> </ul>
Attainment Data	Vapor Intrusion Screening Conditions
Soil Attainment	<ul style="list-style-type: none"> <li>• Use all applicable soil attainment data.</li> <li>• The attainment requirements for soil in Sections 250.702, 250.703, and 250.707(b)(1) of the regulations may be utilized for vapor intrusion soil screening (e.g., 75%/10x test).</li> </ul>
Groundwater Attainment	<ul style="list-style-type: none"> <li>• Use all applicable groundwater attainment data.</li> <li>• When eight or more consecutive quarters of data are available then the attainment requirements for groundwater in 25 Pa. Code §§ 250.702, 250.704, and 250.707(b)(2)(i) of the regulations may be utilized for vapor intrusion groundwater screening (e.g., 75%/10x test on the property and 75%/2x test beyond the property boundary).</li> <li>• Fewer than eight rounds of data may be screened with DEP approval pursuant to 25 Pa. Code § 250.704(d) of the regulations. The VI evaluation is complete if all concentrations are less than or equal to the groundwater screening values (<math>SV_{GW}</math>).</li> <li>• The alternate groundwater attainment statistical method found at 25 Pa. Code § 250.707(b)(2)(ii) of the regulations may be applied to VI screening when the minimum number of samples specified by the documentation of the method have been collected.</li> </ul>

**Table 7. Application of Statewide Health Standard Vapor Intrusion Screening Criteria (cont.)**

VI Monitoring Data	Vapor Intrusion Screening Conditions
Near-Source Soil Gas, Sub-Slab Soil Gas, or Indoor Air Monitoring	<ul style="list-style-type: none"> <li>• Soil gas and indoor air monitoring is performed on a quarterly basis or twice per quarter with samples collected at least 45 days apart.</li> <li>• The Department may approve alternative sampling frequencies.</li> <li>• Near-source and sub-slab soil gas samples are collected from all of the same probes in each event.</li> <li>• Indoor air samples are collected at all of the same locations in each event.</li> <li>• There are a minimum of two sampling rounds.</li> <li>• Statistical tests for screening are applied to the collective data from all near-source soil gas, sub-slab soil gas, or indoor air locations and rounds at each building or portion of a building with a potential VI impact.</li> <li>• Statistical tests may be used when there is a combination of at least eight sample locations and sampling rounds of any given type (near source soil gas, sub-slab soil gas, or indoor air) at each current or planned future building.</li> <li>• The following statistical test may be applied when screening VI data: Seventy-five percent of all samples are equal to or less than the applicable screening value with no individual sample exceeding ten times the screening value on the property (75%/10x test) and two times the screening value beyond the property boundary (75%/2x test).</li> <li>• An alternative statistical method may be applied to VI screening when the minimum number of samples specified by the documentation of the method have been collected: As applied in accordance with EPA approved statistical methods, the 95% UCL of the arithmetic mean is at or below the applicable screening value.</li> </ul>

\* The use of screening values may be restricted due to the presence of SPL, external preferential pathways, or significant foundation openings. See Sections F and G and Figure 7 for additional information on screening value use.

# **APPENDICES**

## Appendix A: Methodology for Developing Statewide Health Standard Vapor Intrusion Screening Values

DEP has calculated screening values (SVs) for regulated substances of VI concern for use with the Statewide health standard. These SVs may be applied to appropriately collected data for indoor air, sub-slab soil gas, near-source soil gas, soil, and groundwater. The methods used to develop the SVs are explained in the following sections.

The SVs for subsurface media are derived using attenuation factors ( $\alpha$ ). An attenuation factor is the ratio between the contaminant concentration in indoor air and the equilibrium soil gas concentration in the unsaturated zone or sub-slab area ( $\alpha \equiv C_{IA}/C_{SG}$ ).

DEP's approach is to first calculate indoor air SVs ( $SV_{IA}$ ), then to determine sub-slab soil gas, near-source soil gas, soil, and groundwater SVs based on attenuation factors established for each of those points of application (POA).

As there are distinct attenuation factors for residential ( $\alpha_R$ ) and nonresidential ( $\alpha_{NR}$ ) structures, DEP carries out separate calculations for SVs that apply to buildings constructed for residential use that have been converted to a purely nonresidential use. These attenuation factors ( $\alpha_{CR}$ ) are equal to the residential factors under the assumption that vapor flow rates and indoor air exchange rates are comparable to residential structures. The converted residential SVs are derived from the nonresidential indoor air SVs.

The VI screening values are provided in Tables 1–5 of the VI Guidance. They will be updated periodically using current scientific information when Chapter 250 MSCs are revised, consistent with Section 250.11 of the regulations.

### 1. Indoor Air

Indoor air represents the point of exposure for inhalation of volatile chemicals in the VI pathway. The POA for indoor air screening is the basement or lowest occupied level of the building.

Contaminants that pose a risk for VI either have a boiling point less than 200°C or a Henry's law constant greater than or equal to  $1 \times 10^{-5}$  atm-m<sup>3</sup>/mol and a molecular weight less than 200 g/mol. Certain regulated substances meet these criteria but currently have no inhalation toxicity values; they are listed in Table A-1. DEP has not published VI SVs for most of these chemicals. Statewide health standard VI evaluations are not available for substances without SVs. The remediator may choose to evaluate VI using the site-specific standard for these chemicals. In addition, DEP does not consider the polycyclic aromatic hydrocarbons (PAHs) in Table A-1 to be of VI concern because of their high boiling points, relatively low Henry's law constants, and very low vapor pressures.

In the case of 1,3,5-trimethylbenzene, DEP has chosen 1,2,4-trimethylbenzene as a surrogate for inhalation toxicity. These two substances have similar chemical and toxicological characteristics which is likely to result in conservative SVs.

Indoor air SVs ( $SV_{IA}$ ) are determined from the inhalation risk equations in U.S. EPA (2009). This method is equivalent to that used by EPA for Regional Screening Levels and in the VISL

Calculator (U.S. EPA, 2014a, 2016b). SVs for systemic toxicants ( $SV_{IA(nc)}$ ) and carcinogens ( $SV_{IA(c)}$ ) are calculated in units of micrograms per cubic meter ( $\mu\text{g}/\text{m}^3$ ).

For systemic toxicants (non-carcinogens) the indoor air SV is:

$$SV_{IA(nc)} = \frac{\text{THQ} \times \text{RfC}_i \times \text{AT}_{nc} \times \left(365 \frac{\text{days}}{\text{yr}}\right) \times \left(24 \frac{\text{hr}}{\text{day}}\right)}{\text{ET} \times \text{EF} \times \text{ED}} \times \frac{1,000 \mu\text{g}}{\text{mg}}$$

For carcinogens the indoor air SV is:

$$SV_{IA(c)} = \frac{\text{TR} \times \text{AT}_c \times \left(365 \frac{\text{days}}{\text{yr}}\right) \times \left(24 \frac{\text{hr}}{\text{day}}\right)}{\text{IUR} \times \text{ET} \times \text{EF} \times \text{ED}}$$

For substances classified as mutagens, except for vinyl chloride and trichloroethylene, the residential carcinogenic indoor air SV is:

$$SV_{IA(c,m,R)} = \frac{\text{TR} \times \text{AT}_c \times \left(365 \frac{\text{days}}{\text{yr}}\right) \times \left(24 \frac{\text{hr}}{\text{day}}\right)}{\text{IUR} \times \text{ET} \times \text{EF} \times \text{AED}}$$

For vinyl chloride the residential carcinogenic indoor air SV is:

$$SV_{IA(c,vc,R)} = \frac{\text{TR}}{\frac{\text{IUR} \times \text{ET} \times \text{EF} \times \text{ED}}{\text{AT}_c \times \left(365 \frac{\text{days}}{\text{yr}}\right) \times \left(24 \frac{\text{hr}}{\text{day}}\right)} + \text{IUR}}$$

For trichloroethylene the residential carcinogenic indoor air SV is:

$$SV_{IA(c,TCE,R)} = \frac{\text{TR} \times \text{AT}_c \times \left(365 \frac{\text{days}}{\text{yr}}\right) \times \left(24 \frac{\text{hr}}{\text{day}}\right)}{(\text{IUR}_k \times \text{AED} + \text{IUR}_l \times \text{ED}) \times \text{ET} \times \text{EF}}$$

As TCE has a mutagenic mode of action for the kidneys, the residential carcinogenic SV is calculated using distinct IUR values for kidney cancer and non-Hodgkin lymphoma and liver cancer (U.S. EPA, 2011a).

The variables and exposure factors in the above equations are defined in Table A-2. Certain conditions are explained in § 250.307(h) of the regulations.

Residential and nonresidential indoor air SVs are defined as the lower of the applicable systemic, carcinogenic, and mutagenic values. The toxicity parameters used are from Chapter 250, Appendix A, Table 5A (Table A-5 herein).

**Table A-1. Volatile Substances Without Inhalation Toxicity Data**

<b>Regulated Substance</b>	<b>CAS No.</b>
ACENAPHTHENE [PAH]	83-32-9
ACENAPHTHYLENE [PAH]	208-96-8
ACETOPHENONE	98-86-2
AMMONIUM SULFAMATE	7773-06-0
ANTHRACENE [PAH]	120-12-7
BENZOTRICHLORIDE	98-07-7
BUTYL ALCOHOL, N-BUTYLATE	71-36-3
BUTYLBENZENE, N-BUTYLBENZENE, SEC-BUTYLBENZENE, TERT-CHLOROACETALDEHYDE	2008-41-5
CHLOROBUTANE, 1-CHLORONAPHTHALENE, 2-CHLOROPHENOL, 2-CHLOROTOLUENE, O-CHLOROTOLUENE, P-CRESOL, O- (METHYLPHENOL, 2-)	104-51-8
CROTONALDEHYDE	135-98-8
CROTONALDEHYDE, TRANS-DICHLOROBENZENE, 1,3-DICHLOROETHYLENE, CIS-1,2-DICHLOROPROPIONIC ACID, 2,2- (DALAPON)	98-06-6
DIISOPROPYL METHYLPHOSPHONATE	107-20-0
DIMETHYL METHYLPHOSPHONATE	109-69-3
DIMETHYLANILINE, N,N-DITHIANE, 1,4-ETHYL DIPROPYLTHIOCARBAMATE, S- (EPTC)	91-58-7
ETHYL ETHER	95-57-8
ETHYLENE CHLORHYDRIN	95-49-8
FLUORENE [PAH]	106-43-4
FURAN	95-48-7
ISOBUTYL ALCOHOL	4170-30-3
METHYL ACETATE	123-73-9
METHYLSTYRENE, ALPHA	541-73-1
METOLACHLOR	156-59-2
MONOCHLOROACETIC ACID	75-99-0
NITROPHENOL, 2-NITROPHENOL, 4-PENTACHLOROETHANE	1445-75-6
PHENANTHRENE [PAH]	756-79-6
PHENYL MERCAPTAN	121-69-7
PYRIDINE	505-29-3
TRICHLOROACETIC ACID	759-94-4
TRICHLOROPROPANE, 1,1,2-TRIMETHYLBENZENE, 1,3,5-*	60-29-7
TRINITROGLYCEROL (NITROGLYCERIN)	107-07-3
	86-73-7
	110-00-9
	78-83-1
	79-20-9
	98-83-9
	51218-45-2
	79-11-8
	88-75-5
	100-02-7
	76-01-7
	85-01-8
	108-98-5
	110-86-1
	76-03-9
	598-77-6
	108-67-8
	55-63-0

PAH: polycyclic (or polynuclear) aromatic hydrocarbon

\*The Department has determined that 1,2,4-trimethylbenzene is an appropriate surrogate for 1,3,5-trimethylbenzene, and VI screening values for 1,3,5-trimethylbenzene are based on the RfC<sub>i</sub> value for 1,2,4-trimethylbenzene.

**Table A-2. Inhalation Risk Variables**

Symbol	Term	Residential	Nonresidential
THQ	Target Hazard Quotient, systemic toxicants	1.0	1.0
RfC <sub>i</sub>	Inhalation Reference Concentration (mg/m <sup>3</sup> )	Table A-5	Table A-5
AT <sub>nc</sub>	Averaging Time for systemic toxicants (yr)	30	25
ET	Exposure Time (hr/day)	24	8
EF	Exposure Frequency (days/yr)	350	250
ED	Exposure Duration (yr)	30	25
TR	Target Risk, carcinogens	1 x 10 <sup>-5</sup>	1 x 10 <sup>-5</sup>
IUR	Inhalation Unit Risk ((μg/m <sup>3</sup> ) <sup>-1</sup> )	Table A-5	Table A-5
AT <sub>c</sub>	Averaging Time for carcinogens (yr)	70	70
AED	Combined Age-Dependent Adjustment Factor and Exposure Duration (yr)	76	N/A
IUR <sub>k</sub>	TCE IUR, residential, kidney cancer ((μg/m <sup>3</sup> ) <sup>-1</sup> )	1.0 x 10 <sup>-6</sup>	N/A
IUR <sub>l</sub>	TCE IUR, residential, non-Hodgkin lymphoma and liver cancer ((μg/m <sup>3</sup> ) <sup>-1</sup> )	3.0 x 10 <sup>-6</sup>	N/A

## 2. Sub-Slab Soil Gas

The POA for sub-slab soil gas screening is immediately beneath the slab or basement of a building. In some circumstances samples may be collected from behind basement walls or below intact paved areas large enough to be representative of future inhabited buildings. Sub-slab SVs (SV<sub>SS</sub>) are defined using attenuation factors from U.S. EPA (2012b, 2015a). These SVs have units of micrograms per cubic meter (μg/m<sup>3</sup>).

EPA derived a sub-slab attenuation factor ( $\alpha_{SS}$ ) from a statistical evaluation of 431 paired sub-slab and indoor air sampling data at over 400 residential buildings at 12 sites. The data was limited to chlorinated VOCs. The empirical attenuation factors are defined as  $\alpha_{SS} = C_{IA}/C_{SS}$ .

EPA's recommended residential attenuation factor is  $\alpha_{SS,R} = 0.026$ , the 95<sup>th</sup> percentile of the screened data. DEP has adopted this attenuation factor for all chemicals, including petroleum hydrocarbons, as a conservative approach. This residential factor also applies to nonresidential buildings that were originally constructed for residential use ( $\alpha_{SS,CR}$ ) or that have mixed residential and commercial uses.

For nonresidential buildings that were constructed purely for nonresidential use (e.g., commercial, industrial, and institutional buildings), DEP adjusts EPA's attenuation factor to account for a higher air exchange rate in such structures. The 10<sup>th</sup> percentile air exchange rates for residential and commercial buildings are 0.18 and 0.60 air changes per hour, respectively (U.S. EPA, 2011b, Ch. 19). These are conservative rates, particularly for modern nonresidential buildings which typically have values exceeding 1 hr<sup>-1</sup>. The adjusted nonresidential sub-slab attenuation factor is:

$$\alpha_{SS,NR} = (0.026) \times \frac{0.18 \text{ hr}^{-1}}{0.60 \text{ hr}^{-1}} = 0.0078$$



Sub-slab SVs are calculated directly from the indoor air SVs using the applicable attenuation factor:

$$SV_{SS} = \frac{SV_{IA}}{\alpha_{SS}}$$

### 3. Near-Source Soil Gas

Near-source soil gas samples are collected proximal to the source to minimize the influence of variable effects such as soil moisture, atmospheric conditions, and leakage from the surface into the sample that can bias shallow soil gas measurements. For groundwater and SPL the POA is immediately above the capillary zone throughout the area of the plume. For soil in the vadose zone the POA is within or immediately above the contaminated soil. Screening may be applied when at least a 5-foot vertical section of acceptable soil or soil-like material is present between the bottom of the building foundation and the depth where the near-source soil gas sample is obtained. (If a near-source soil gas sample is collected less than 5 feet below the foundation it may be screened using sub-slab soil gas SVs.) Near-source soil gas SVs ( $SV_{NS}$ ) are defined using attenuation factors derived from modeling as explained below. These SVs have units of micrograms per cubic meter ( $\mu\text{g}/\text{m}^3$ ).

DEP estimated a near-source soil gas attenuation factor ( $\alpha_{NS}$ ) by running numerous Johnson & Ettinger (J&E) model simulations (Johnson and Ettinger, 1991; U.S. EPA, 2004). DEP utilized EPA's advanced soil model (version 3.1, February 2004) to determine soil gas source concentrations corresponding to specified indoor air SVs. The simulations encompassed 12 to 16 different chemicals, the full suite of soil types, and water-filled porosities ranging from residual saturation to the EPA default values in the J&E manual. DEP made conservative assumptions of a shallow source (5 feet) and a high vapor flow rate ( $Q_{\text{soil}} = 5 \text{ L}/\text{min}$ ). EPA's default building characteristics for a small, slab-on-grade building were retained. The models had low, 10<sup>th</sup> percentile values for the air exchange rate ( $0.18 \text{ hr}^{-1}$  residential,  $0.60 \text{ hr}^{-1}$  nonresidential; U.S. EPA, 2011b, Ch. 19).

The results of this modeling indicated that there is relatively little variability in the soil gas attenuation factor for different conditions. The silt soil type has the highest attenuation factor because of its low residual water content and relatively high air-filled porosity. Representative factors are  $\alpha_{NS,R} = 0.005$  and  $\alpha_{NS,NR} = 0.001$  for residential and nonresidential scenarios. To further assess these values DEP examined the soil gas data in EPA's VI database (U.S. EPA, 2012b). Of 46 buildings at four sites with paired deep soil gas (> 10 feet) and indoor air measurements, only one exceeded the modeled attenuation factor of 0.005. (This exception had a calculated attenuation factor of 0.0075.)

Near-source SVs are calculated directly from the indoor air values using the applicable attenuation factor:

$$SV_{NS} = \frac{SV_{IA}}{\alpha_{NS}}$$

#### 4. Soil

Soil samples may be collected in the unsaturated zone as part of the site characterization or a demonstration of attainment following remediation. The POA is throughout the area of contamination. Screening may be applied to samples collected at any depth below the building foundation and above the water table. SPL should not be present. Soil SVs ( $SV_{SOIL}$ ) are defined as the higher of a calculated SV and the generic soil-to-groundwater pathway numeric value for a used aquifer in Chapter 250. Soil SVs have units of milligrams per kilogram, dry basis (mg/kg).

The calculated SVs are based on equilibrium partitioning of the contaminant between the sorbed phase on soil, the dissolved phase in pore water, and the vapor phase in the pore space. This relationship is given in § 250.308(a)(3) of the regulations, with the dilution factor set to 1:

$$SV'_{SOIL} = \left( f_{oc}K_{oc} + \frac{\theta_w}{\rho_b} \right) C_{pw} \times \frac{1 \text{ mg}}{1,000 \text{ } \mu\text{g}}$$

where  $SV'_{SOIL}$  is the calculated SV for soil (mg/kg) and  $C_{pw}$  is the concentration in pore water ( $\mu\text{g/L}$ ). The other parameters are defined in Table A-3. The value of  $f_{oc}$  is from § 250.308(a)(3). The dry bulk density used is representative of typical soil types (U.S. EPA, 2004). DEP defines  $\theta_w$  equal to 0.1 to represent relatively dry conditions, close to residual saturation, beneath a building.

The pore water concentration is related to the pore vapor concentration ( $C_{pv}$ ) by Henry's law:

$$C_{pw} = \frac{C_{pv}}{H'} \times \frac{1 \text{ m}^3}{1,000 \text{ L}}$$

where  $C_{pv}$  has units of micrograms per cubic meter ( $\mu\text{g/m}^3$ ).  $H'$  is calculated at a soil temperature of 16°C (61°F) (Appendix B).

The value of the pore vapor concentration is determined from the  $SV_{IA}$  by means of soil attenuation factors:

$$C_{pv} = \frac{SV_{IA}}{\alpha_{SOIL}}$$

The soil attenuation factors were determined through testing with the J&E model as described in Section 3 of this appendix, but with a source depth of 0.5 feet, directly below the slab. The corresponding factors are  $\alpha_{SOIL,R} = 0.01$  and  $\alpha_{SOIL,NR} = 0.002$ .

The soil SVs are limited by the residual saturation value of 10,000 mg/kg as defined in § 250.305(b).

Each calculated SV is compared to the generic soil-to-groundwater pathway numeric value for a used aquifer with total dissolved solids less than or equal to 2,500 mg/L (Chapter 250, Appendix A, Table 3B), and DEP defines the higher of the two values as the soil SV for VI ( $SV_{SOIL}$ ). The generic soil-to-groundwater numeric values are considered appropriate for VI screening because soil contamination that is unable to impact aquifers in excess of groundwater

MSCs is also unlikely to pose an excess inhalation risk. DEP also recognizes that the infinite source assumption used to calculate SVs is very conservative, that soil contamination commonly occurs outside the footprint of potentially impacted buildings, and that these SVs do not account for the natural biological degradation of petroleum hydrocarbons in soil vapor.

**Table A-3. Soil Partitioning Parameters**

Symbol	Description	Value
$f_{oc}$	fraction organic carbon in soil	0.0025
$K_{oc}$	organic carbon partitioning coefficient (L/kg)	Table A-5
$\theta_w$	water-filled porosity of soil	0.1
$\rho_b$	dry bulk density of soil (kg/L)	1.5
$H'$	Henry's law constant at soil temperature	Table A-5

## 5. Groundwater

Groundwater data that have been collected as part of the site characterization or a demonstration of attainment may be used for VI screening. The POA is throughout the area of the groundwater plume. Certain conditions apply to groundwater screening. Groundwater samples are collected from properly constructed monitoring wells screened across the water table, and the wetted length of the well screen should be no more than 10 feet. SPL is not present. When using screening values for groundwater that is at least 5 feet below the foundation, acceptable soil or soil-like material should be present between the groundwater and the foundation.

Groundwater SVs ( $SV_{GW}$ ) for depths less than 5 feet below the foundation are defined by the groundwater MSCs for a used aquifer. Groundwater SVs for depths of 5 feet below the foundation and greater are defined as the higher of calculated SVs based on empirically determined attenuation factors and the groundwater MSCs for a used aquifer. SVs have units of micrograms per liter ( $\mu\text{g/L}$ ).

EPA developed a database of 774 paired groundwater and indoor air sampling data at over 600 residential buildings located at 24 sites (U.S. EPA, 2012b). The data was limited to chlorinated VOCs. EPA performed a statistical evaluation of the database, and they recommended an attenuation factor of 0.001. This value is the 95<sup>th</sup> percentile of the screened data. The groundwater attenuation factor is defined as  $\alpha_{GW} = C_{IA}/C_{GW}$ .

The Department has reexamined EPA's database by considering two additional factors. One is the uncertainty in the groundwater temperatures selected for each site. In some instances the assigned temperatures may have been underestimated. The other is that EPA's evaluation included some data from buildings over shallow groundwater (less than 5 feet below the foundation). DEP reanalyzed the database with a range of plausible annual average groundwater temperatures and without the shallow groundwater data.

DEP has derived a residential groundwater attenuation factor of 0.0009 for groundwater that is at least 5 feet below the foundation. DEP has adopted this attenuation factor for all chemicals, including petroleum hydrocarbons, as a conservative approach. This residential factor ( $\alpha_{GW,R}$ ) also applies to nonresidential buildings that were originally constructed for residential use ( $\alpha_{GW,CR}$ ) or that have mixed residential and commercial uses.

For nonresidential buildings that were constructed purely for nonresidential use (e.g., commercial, industrial, and institutional buildings), DEP adjusts the residential attenuation factor to account for a higher air exchange rate in these structures. The 10<sup>th</sup> percentile air exchange rates for residential and commercial buildings are 0.18 and 0.60 air changes per hour, respectively (U.S. EPA, 2011b, Ch. 19). The adjusted nonresidential groundwater attenuation factor is:

$$\alpha_{\text{GW,NR}} = (0.0009) \times \frac{0.18 \text{ hr}^{-1}}{0.60 \text{ hr}^{-1}} = 0.0003$$

Calculated groundwater SVs ( $SV'_{\text{GW}}$ ) are determined from the indoor air SVs using the applicable attenuation factor and a conversion from soil gas to a dissolved concentration via Henry's law:

$$SV'_{\text{GW}} = \frac{SV_{\text{IA}}}{\alpha_{\text{GW}}} \times \frac{1}{(1,000 \text{ L/m}^3)H'}$$

where  $H'$  is the nondimensional Henry's law constant at the groundwater temperature (Table A-5). DEP calculates the Henry's law constant at a groundwater temperature of 16°C (61°F) (Appendix B).

DEP compares each calculated SV to the groundwater MSC for a used aquifer with total dissolved solids less than or equal to 2,500 mg/L (Chapter 250, Appendix A, Table 1). DEP defines the groundwater SV for VI ( $SV_{\text{GW}}$ ) for depths of 5 feet below the foundation and greater as the maximum of the calculated SV ( $SV'_{\text{GW}}$ ) and the MSC, limited by the aqueous solubility ( $S$ ). DEP regards the groundwater MSCs as suitable for VI screening at any depth because they are acceptable for water used inside homes, including inhalation exposures.

## 6. Building Foundation Openings

The sub-slab soil gas and groundwater attenuation factors are derived from EPA's database of residential VI sampling. DEP recognizes that many of the buildings used in EPA's study likely had typical foundation openings such as sumps, French drains, floor drains, and gaps around utility penetrations. (For instance, over three-quarters of the homes included in the sub-slab attenuation factor analysis had basements, and EPA did not filter the data for the presence of foundation openings.) For this reason, DEP considers the attenuation factors and screening values to be applicable to buildings with common openings. For a small house with a sump and an open, interior French drain, the size of these openings would not be more than a few percent of the foundation area. DEP's threshold for significant openings, which preclude the use of the attenuation factors and SVs, is 5% of the foundation area (Section D.2).

DEP establishes attenuation factors for near-source soil gas and soil based on J&E model simulations. These tests assume a conservative, high vapor flow rate into the building, which would be representative of vapor entry through typical foundation openings. Therefore, the near-source soil gas and soil attenuation factors and SVs are also applicable to buildings that do not have foundation openings exceeding 5% of the foundation area.

## 7. Attenuation Factor Summary

The attenuation factors used to calculate the VI SVs are listed in Table A-4. The sub-slab and groundwater attenuation factors are based on EPA's empirical database (U.S. EPA, 2012b). The near source soil gas and soil attenuation factors are defined from DEP's modeling studies.

**Table A-4. Attenuation Factors**

<b>Sample Type</b>	<b><math>\alpha_R</math></b>	<b><math>\alpha_{NR}</math></b>	<b><math>\alpha_{CR}</math></b>
Sub-slab soil gas	0.026	0.0078	0.026
Near-source soil gas	0.005	0.001	0.005
Soil	0.01	0.002	0.01
Groundwater	0.0009	0.0003	0.0009

R: residential building

NR: nonresidential building

CR: residential building converted to nonresidential use

The near-source and sub-slab soil gas attenuation factors may also be used within a site-specific standard risk assessment for estimating indoor air concentrations (Section K.4) or for calculating SVs from EPA's indoor air regional screening levels (RSLs) (Section K.5).

**Table A-5. Vapor Intrusion Screening Value Calculation Parameters**

Regulated Substance	CAS No.	MW (g/mol)	$K_{oc}$ (L/kg)	S (mg/L)	$T_B$ (°C)	$T_C$ (K)	$\Delta H_{v,b}$ (cal/mol)	H (atm-m <sup>3</sup> /mol)	H' (@ $T_{kw}$ )	RfC <sub>1</sub> (mg/m <sup>3</sup> )	IUR ( $\mu\text{g}/\text{m}^3$ ) <sup>-1</sup>
ACETALDEHYDE	75-07-0	44	4.1	1,000,000	20	466	6,157	$6.7 \times 10^{-3}$	$2.0 \times 10^{-3}$	$9.0 \times 10^{-3}$	$2.2 \times 10^{-6}$
ACETONE	67-64-1	58	0.31	1,000,000	56	508	6,955	$3.5 \times 10^{-5}$	$9.7 \times 10^{-4}$	$3.1 \times 10^{+1}$	
ACETONITRILE	75-05-8	41	0.5	1,000,000	82	546	7,110	$3.5 \times 10^{-5}$	$9.3 \times 10^{-4}$	$6.0 \times 10^{-2}$	
ACROLEIN	107-02-8	56	0.56	208,000	53	506	6,731	$1.2 \times 10^{-4}$	$3.4 \times 10^{-3}$	$2.0 \times 10^{-5}$	
ACRYLAMIDE [M]	79-06-1	71	25	2,151,000	193	818	12,363	$1.7 \times 10^{-9}$	$3.3 \times 10^{-8}$	$6.0 \times 10^{-3}$	$1.0 \times 10^{-4}$
ACRYLIC ACID	79-10-7	72	29	1,000,000	141	617	11,000	$3.7 \times 10^{-7}$	$7.5 \times 10^{-6}$	$1.0 \times 10^{-3}$	
ACRYLONITRILE	107-13-1	53	11	73,500	77	519	7,786	$1.4 \times 10^{-4}$	$3.6 \times 10^{-3}$	$2.0 \times 10^{-3}$	$6.8 \times 10^{-5}$
ALLYL ALCOHOL	107-18-6	58	3.2	1,000,000	97	545	9,550	$5.0 \times 10^{-6}$	$1.1 \times 10^{-4}$	$1.0 \times 10^{-4}$	
AMMONIA	7664-41-7	17	3.1	310,000	-33	406	5,572	$1.6 \times 10^{-5}$	$5.1 \times 10^{-4}$	$1.0 \times 10^{-1}$	
ANILINE	62-53-3	93	190	33,800	184	699	10,000	$2.0 \times 10^{-6}$	$4.4 \times 10^{-5}$	$1.0 \times 10^{-3}$	$1.6 \times 10^{-6}$
BENZENE	71-43-2	78	58	1,781	81	562	7,342	$5.6 \times 10^{-3}$	$1.5 \times 10^{-1}$	$3.0 \times 10^{-2}$	$7.8 \times 10^{-6}$
BENZYL CHLORIDE	100-44-7	127	190	493	179	685	8,773	$4.1 \times 10^{-4}$	$9.6 \times 10^{-3}$	$1.0 \times 10^{-3}$	$4.9 \times 10^{-5}$
BETA PROPIOLACTONE	57-57-8	72	4	370,000	162	686	10,285	$1.3 \times 10^{-5}$	$2.8 \times 10^{+2}$	$4.0 \times 10^{-3}$	
BIPHENYL, 1,1-	92-52-4	154	1700	7	255	789	10,890	$3.1 \times 10^{-4}$	$6.0 \times 10^{-3}$	$4.0 \times 10^{-4}$	
BIS(2-CHLOROETHYL)ETHER	111-44-4	143	76	10,200	179	660	10,803	$1.7 \times 10^{-5}$	$3.4 \times 10^{-4}$		$3.3 \times 10^{-4}$
BIS(2-CHLORO-ISOPROPYL)ETHER	108-60-1	171	62	1,700	189	690	9,695	$7.4 \times 10^{-5}$	$1.6 \times 10^{-3}$		$1.0 \times 10^{-5}$
BIS(CHLOROMETHYL)ETHER	542-88-1	115	16	22,000	105	569	7,981	$4.4 \times 10^{-3}$	$1.1 \times 10^{-1}$		$6.2 \times 10^{-2}$
BROMOCHLOROMETHANE	74-97-5	129	27	16,700	68	512	7,168	$1.5 \times 10^{-3}$	$3.9 \times 10^{-2}$	$4.0 \times 10^{-2}$	
BROMODICHLOROMETHANE	75-27-4	164	93	4,500	87	586	7,800	$2.1 \times 10^{-3}$	$5.5 \times 10^{-2}$		$3.7 \times 10^{-5}$
BROMOMETHANE	74-83-9	95	170	17,500	4	467	5,714	$7.3 \times 10^{-3}$	$2.2 \times 10^{-1}$	$5.0 \times 10^{-3}$	
BUTADIENE, 1,3-	106-99-0	54	120	735	-5	425	5,370	$7.4 \times 10^{-2}$	$2.3 \times 10^{+0}$	$2.0 \times 10^{-3}$	$3.0 \times 10^{-5}$
CARBON DISULFIDE	75-15-0	76	300	2,100	46	552	6,391	$1.4 \times 10^{-2}$	$4.2 \times 10^{-1}$	$7.0 \times 10^{-1}$	
CARBON TETRACHLORIDE	56-23-5	154	160	795	77	557	7,127	$2.8 \times 10^{-2}$	$7.5 \times 10^{-1}$	$1.0 \times 10^{-1}$	$6.0 \times 10^{-6}$
CHLORO-1,1-DIFLUOROETHANE, 1-	75-68-3	101	22	1,400	-9	410	53,298	$5.9 \times 10^{-2}$	$1.8 \times 10^{-1}$	$5.0 \times 10^{+1}$	
CHLORO-1-PROPENE, 3-(ALLYL CHLORIDE)	107-05-1	77	48	3,300	45	514	6,936	$1.1 \times 10^{-2}$	$3.1 \times 10^{-1}$	$1.0 \times 10^{-3}$	$6.0 \times 10^{-6}$
CHLOROBENZENE	108-90-7	113	200	490	132	632	8,410	$3.1 \times 10^{-3}$	$7.6 \times 10^{-2}$	$5.0 \times 10^{-2}$	
CHLORODIBROMOMETHANE	124-48-1	208	83	4,200	116	678	5,900	$7.8 \times 10^{-4}$	$2.3 \times 10^{-2}$		$2.7 \times 10^{-5}$
CHLORODIFLUOROMETHANE	75-45-6	86	59	2,899	-41	369	4,836	$4.1 \times 10^{-2}$	$1.3 \times 10^{+0}$	$5.0 \times 10^{+1}$	
CHLOROETHANE	75-00-3	65	42	5,700	12	460	5,879	$1.1 \times 10^{-2}$	$3.3 \times 10^{-1}$	$1.0 \times 10^{+1}$	
CHLOROFORM	67-66-3	119	56	8,000	61	536	6,988	$3.7 \times 10^{-3}$	$1.0 \times 10^{-1}$	$9.8 \times 10^{-2}$	$2.3 \times 10^{-5}$
CHLOROPRENE	126-99-8	89	50	1,736	59	525	8,075	$5.6 \times 10^{-2}$	$1.5 \times 10^{+0}$	$2.0 \times 10^{-2}$	$3.0 \times 10^{-4}$
CHLOROPROPANE, 2-	75-29-6	79	260	3,100	47	485	6,286	$1.8 \times 10^{-2}$	$5.0 \times 10^{-1}$	$1.0 \times 10^{-1}$	
CHLOROPROPANE, 1,2-	1319-77-3	108	25	20,000	139	701	10,886	$1.2 \times 10^{-6}$	$2.6 \times 10^{-5}$	$6.0 \times 10^{-1}$	
CRESOL(S)	98-82-8	120	2800	50	152	631	10,335	$1.2 \times 10^{-2}$	$2.4 \times 10^{-1}$	$4.0 \times 10^{-1}$	
CUMENE (ISOPROPYL BENZENE)	110-82-7	84	479	55	81	553	7,154	$1.5 \times 10^{-1}$	$4.0 \times 10^{+0}$	$6.0 \times 10^{+0}$	
CYCLOHEXANE	108-94-1	98	66	36,500	157	653	9,500	$9.0 \times 10^{-6}$	$2.0 \times 10^{-4}$	$7.0 \times 10^{-1}$	
DIBROMO-3-CHLOROPROPANE, 1,2-[M]	96-12-8	236	140	1,000	196	704	9,960	$1.5 \times 10^{-4}$	$3.1 \times 10^{-3}$	$2.0 \times 10^{-4}$	$6.0 \times 10^{-3}$

**Table A-5. Vapor Intrusion Screening Value Calculation Parameters (cont.)**

Regulated Substance	CAS No.	MW (g/mol)	$K_{oc}$ (L/kg)	S (mg/L)	$T_B$ (°C)	$T_C$ (K)	$\Delta H_{v,b}$ (cal/mol)	H (atm-m <sup>3</sup> /mol)	$H'$ (@ $T_{kw}$ )	RfC <sub>i</sub> (mg/m <sup>3</sup> )	IUR (µg/m <sup>3</sup> ) <sup>-1</sup>
DIBROMOETHANE, 1,2-(ETHYLENE DIBROMIDE)	106-93-4	188	54	4,150	131	583	8,310	6.5 x 10 <sup>-4</sup>	1.6 x 10 <sup>-2</sup>	9.0 x 10 <sup>-3</sup>	6.0 x 10 <sup>-4</sup>
DIBROMOMETHANE	74-95-3	174	110	11,400	96	583	7,868	8.2 x 10 <sup>-4</sup>	2.1 x 10 <sup>-2</sup>	4.0 x 10 <sup>-3</sup>	4.2 x 10 <sup>-3</sup>
DICHLORO-2-BUTENE, 1,4-	764-41-0	125	180	850	156	647	8,875	6.6 x 10 <sup>-4</sup>	1.5 x 10 <sup>-2</sup>		4.2 x 10 <sup>-3</sup>
DICHLORO-2-BUTENE, TRANS-1,4-	110-57-6	125	215	850	155	646	9,125	6.6 x 10 <sup>-4</sup>	1.5 x 10 <sup>-2</sup>		1.1 x 10 <sup>-5</sup>
DICHLOROBENZENE, 1,2-	95-50-1	147	350	147	180	705	9,700	1.9 x 10 <sup>-3</sup>	4.3 x 10 <sup>-2</sup>	2.0 x 10 <sup>-1</sup>	
DICHLOROBENZENE, P-	106-46-7	147	510	83	174	685	9,271	2.4 x 10 <sup>-3</sup>	5.5 x 10 <sup>-2</sup>	8.0 x 10 <sup>-1</sup>	
DICHLORODIFLUOROMETHANE (FREON 12)	75-71-8	121	360	280	-30	385	9,421	3.4 x 10 <sup>-1</sup>	9.1 x 10 <sup>+0</sup>	1.0 x 10 <sup>-1</sup>	
DICHLOROETHANE, 1,1-	75-34-3	99	52	5,000	57	523	6,895	5.6 x 10 <sup>-3</sup>	1.6 x 10 <sup>-1</sup>	5.0 x 10 <sup>-1</sup>	1.6 x 10 <sup>-6</sup>
DICHLOROETHANE, 1,2-	107-06-2	99	38	8,412	83	561	7,643	1.2 x 10 <sup>-3</sup>	3.1 x 10 <sup>-2</sup>	7.0 x 10 <sup>-3</sup>	2.6 x 10 <sup>-5</sup>
DICHLOROETHYLENE, 1,1-	75-35-4	97	65	2,500	32	576	6,247	2.6 x 10 <sup>-2</sup>	7.6 x 10 <sup>-1</sup>	2.0 x 10 <sup>-1</sup>	
DICHLOROETHYLENE, TRANS-1,2-	156-60-5	97	47	6,300	48	517	6,717	4.1 x 10 <sup>-3</sup>	1.2 x 10 <sup>-1</sup>	6.0 x 10 <sup>-2</sup>	
DICHLOROMETHANE (METHYLENE CHLORIDE) [M]	75-09-2	85	16	20,000	40	510	6,706	3.3 x 10 <sup>-3</sup>	9.2 x 10 <sup>-2</sup>	6.0 x 10 <sup>-1</sup>	1.0 x 10 <sup>-8</sup>
DICHLOROPROPANE, 1,2-	78-87-5	113	47	2,700	96	572	7,590	2.8 x 10 <sup>-3</sup>	7.3 x 10 <sup>-2</sup>	4.0 x 10 <sup>-3</sup>	1.0 x 10 <sup>-5</sup>
DICHLOROPROPENE, 1,3-	542-75-6	111	27	2,700	108	587	7,900	3.6 x 10 <sup>-3</sup>	9.0 x 10 <sup>-2</sup>	2.0 x 10 <sup>-2</sup>	4.0 x 10 <sup>-6</sup>
DICYCLOPENTADIENE	77-73-6	132	810	40	167	665	2,197	6.3 x 10 <sup>-2</sup>	2.2 x 10 <sup>+0</sup>	3.0 x 10 <sup>-4</sup>	7.7 x 10 <sup>-6</sup>
DIOXANE, 1,4-	123-91-1	88	7.8	1,000,000	101	587	8,690	4.8 x 10 <sup>-6</sup>	1.2 x 10 <sup>-4</sup>	1.1 x 10 <sup>-1</sup>	1.2 x 10 <sup>-6</sup>
EPICHLOROHYDRIN	106-89-8	93	35	65,800	116	600	10	3.0 x 10 <sup>-5</sup>	1.2 x 10 <sup>-3</sup>	1.0 x 10 <sup>-3</sup>	1.2 x 10 <sup>-6</sup>
ETHOXYETHANOL, 2-(EGEE)	110-80-5	90	12	1,000,000	136	572	9,368	4.7 x 10 <sup>-7</sup>	1.0 x 10 <sup>-5</sup>	2.0 x 10 <sup>-1</sup>	
ETHYL ACETATE	141-78-6	88	59	80,800	77	523	7,634	1.3 x 10 <sup>-4</sup>	3.5 x 10 <sup>-3</sup>	7.0 x 10 <sup>-2</sup>	
ETHYL ACRYLATE	140-88-5	100	110	15,000	100	552	8,270	3.4 x 10 <sup>-4</sup>	8.4 x 10 <sup>-3</sup>	8.0 x 10 <sup>-3</sup>	
ETHYL BENZENE	100-41-4	106	220	161	136	617	8,501	7.9 x 10 <sup>-3</sup>	1.9 x 10 <sup>-1</sup>	1.0 x 10 <sup>+0</sup>	2.5 x 10 <sup>-6</sup>
ETHYL METHACRYLATE	97-63-2	114	22	4,636	117	571	10,957	5.7 x 10 <sup>-4</sup>	1.2 x 10 <sup>-2</sup>	3.0 x 10 <sup>-1</sup>	
ETHYLENE GLYCOL	107-21-1	62	4.4	1,000,000	198	718	12,550	6.0 x 10 <sup>-8</sup>	1.1 x 10 <sup>-6</sup>	4.0 x 10 <sup>-1</sup>	
FLUOROTRICHLOROMETHANE (FREON 11)	75-69-4	137	130	1,090	24	471	5,999	9.7 x 10 <sup>-2</sup>	2.9 x 10 <sup>+0</sup>	7.0 x 10 <sup>-1</sup>	
FORMALDEHYDE	50-00-0	30	3.6	55,000	-21	408	5,500	3.4 x 10 <sup>-7</sup>	1.1 x 10 <sup>-5</sup>	9.8 x 10 <sup>-3</sup>	1.3 x 10 <sup>-5</sup>
FORMIC ACID	64-18-6	46	0.54	1,000,000	101	588	5,240	1.7 x 10 <sup>-7</sup>	5.0 x 10 <sup>-6</sup>	3.0 x 10 <sup>-4</sup>	
FURFURAL	98-01-1	96	6.3	91,000	162	670	9,826	3.8 x 10 <sup>-6</sup>	8.3 x 10 <sup>-5</sup>	5.0 x 10 <sup>-2</sup>	
HEXACHLOROETHANE	67-72-1	237	2200	50	187	695	9,510	3.9 x 10 <sup>-3</sup>	8.6 x 10 <sup>-2</sup>	3.0 x 10 <sup>-2</sup>	1.0 x 10 <sup>-5</sup>
HEXANE	110-54-3	86	3600	10	69	508	6,895	1.8 x 10 <sup>+0</sup>	4.9 x 10 <sup>+1</sup>	7.0 x 10 <sup>-1</sup>	
HYDRAZINE/HYDRAZINE SULFATE	302-01-2	32	0.0053	1,000,000	114	653	10,700	6.1 x 10 <sup>-7</sup>	1.3 x 10 <sup>-5</sup>	3.0 x 10 <sup>-5</sup>	4.9 x 10 <sup>-3</sup>
METHACRYLONITRILE	126-98-7	67	21	25,700	90	554	7,600	2.5 x 10 <sup>-4</sup>	6.4 x 10 <sup>-3</sup>	3.0 x 10 <sup>-2</sup>	
METHANOL	67-56-1	32	2.8	1,000,000	65	513	8,426	4.6 x 10 <sup>-6</sup>	1.1 x 10 <sup>-4</sup>	4.0 x 10 <sup>+0</sup>	
METHOXYETHANOL, 2-	109-86-4	76	1	1,000,000	124	598	8,966	3.3 x 10 <sup>-7</sup>	7.8 x 10 <sup>-6</sup>	2.0 x 10 <sup>-2</sup>	
METHYL ACRYLATE	96-33-3	86	55	52,000	70	536	7,749	2.0 x 10 <sup>-4</sup>	5.2 x 10 <sup>-3</sup>	2.0 x 10 <sup>-2</sup>	
METHYL CHLORIDE	74-87-3	50	6	6,180	-24	416	5,115	8.8 x 10 <sup>-3</sup>	2.8 x 10 <sup>-1</sup>	9.0 x 10 <sup>-2</sup>	1.8 x 10 <sup>-6</sup>

**Table A-5. Vapor Intrusion Screening Value Calculation Parameters (cont.)**

Regulated Substance	CAS No.	MW (g/mol)	$K_{oc}$ (L/kg)	S (mg/L)	$T_B$ (°C)	$T_C$ (K)	$\Delta H_{v,b}$ (cal/mol)	H (atm-m <sup>3</sup> /mol)	$H'$ (@ $T_{kw}$ )	RfC <sub>i</sub> (mg/m <sup>3</sup> )	IUR (µg/m <sup>3</sup> ) <sup>-1</sup>
METHYL ETHYL KETONE	78-93-3	72	32	275,000	80	537	7,481	$5.7 \times 10^{-5}$	$1.5 \times 10^{-3}$	$5.0 \times 10^{-10}$	
METHYL HYDRAZINE	60-34-4	46	1	1,000,000	88	585	8,890	$3.0 \times 10^{-6}$	$7.4 \times 10^{-5}$	$2.0 \times 10^{-5}$	$1.0 \times 10^{-3}$
METHYL ISOBUTYL KETONE	108-10-1	100	17	19,550	117	571	8,243	$1.4 \times 10^{-4}$	$3.4 \times 10^{-3}$	$3.0 \times 10^{-10}$	
METHYL ISOCYANATE	624-83-9	57	10	100,000	40	491	6,394	$9.3 \times 10^{-4}$	$2.7 \times 10^{-2}$	$1.0 \times 10^{-3}$	
METHYL METHACRYLATE	80-62-6	100	10	15,600	100	567	8,975	$3.2 \times 10^{-4}$	$7.6 \times 10^{-3}$	$7.0 \times 10^{-1}$	
METHYL N-BUTYL KETONE (2-HEXANONE)	591-78-6	100	54	17,500	128	601	8,610	$9.3 \times 10^{-5}$	$2.2 \times 10^{-3}$	$3.0 \times 10^{-2}$	
METHYL STYRENE (MIXED ISOMERS)	25013-15-4	118	2200	89	163	655	12,027	$2.6 \times 10^{-3}$	$4.8 \times 10^{-2}$	$4.0 \times 10^{-2}$	
METHYL TERT-BUTYL ETHER (MTBE)	1634-04-4	88	12	45,000	55	497	6,678	$5.9 \times 10^{-4}$	$1.6 \times 10^{-2}$	$3.0 \times 10^{-10}$	$2.6 \times 10^{-7}$
METHYLNAPHTHALENE, 2-NAPHTHALENE	91-57-6	142	16,000	25	241	761	12,600	$5.2 \times 10^{-4}$	$9.1 \times 10^{-3}$	$3.0 \times 10^{-3}$	
NITROBENZENE	91-20-3	128	950	30	218	748	10,373	$4.4 \times 10^{-4}$	$9.2 \times 10^{-3}$	$3.0 \times 10^{-3}$	$3.4 \times 10^{-5}$
NITROPROPANE, 2-NITROSODIETHYLAMINE, N-[M]	98-95-3	123	130	2,000	211	719	10,566	$2.4 \times 10^{-5}$	$4.9 \times 10^{-4}$	$9.0 \times 10^{-3}$	$4.0 \times 10^{-5}$
NITROSODIMETHYLAMINE, N-[M]	79-46-9	89	20	16,700	120	594	8,383	$1.2 \times 10^{-4}$	$2.9 \times 10^{-3}$	$2.0 \times 10^{-2}$	$2.7 \times 10^{-3}$
NITROSODIETHYLAMINE, N-[M]	55-18-5	102	26	93,000	176	655	10,087	$3.6 \times 10^{-6}$	$7.6 \times 10^{-5}$	$4.0 \times 10^{-5}$	$4.3 \times 10^{-2}$
NITROSO-DI-N-BUTYLAMINE, N-	62-75-9	74	8.5	1,000,000	154	645	9,448	$1.8 \times 10^{-6}$	$4.1 \times 10^{-5}$	$4.0 \times 10^{-5}$	$1.4 \times 10^{-2}$
PCB-1221 (AROCLOR)	924-16-3	158	450	1,200	235	584	11,653	$1.3 \times 10^{-5}$	$1.8 \times 10^{-4}$	$4.0 \times 10^{-5}$	$1.6 \times 10^{-3}$
PCB-1232 (AROCLOR)	11104-28-2	189	1900	1	275	845	12,100	$7.4 \times 10^{-4}$	$1.4 \times 10^{-2}$	$2.0 \times 10^{-1}$	$5.7 \times 10^{-4}$
PHENOL	11141-16-5	189	1500	1	290	845	12,200	$7.4 \times 10^{-4}$	$1.3 \times 10^{-2}$	$2.0 \times 10^{-1}$	$5.7 \times 10^{-4}$
PROPANOL, 2-(ISOPROPYL ALCOHOL)	108-95-2	94	22	84,300	182	694	10,920	$3.3 \times 10^{-7}$	$6.8 \times 10^{-6}$	$2.0 \times 10^{-1}$	
PROPYLBENZENE, N-PROPYLENE OXIDE	67-63-0	60	25	1,000,000	82	508	9,518	$8.1 \times 10^{-6}$	$1.9 \times 10^{-4}$	$2.0 \times 10^{-1}$	
STYRENE	103-65-1	120	720	52	159	630	9,123	$1.1 \times 10^{-2}$	$2.4 \times 10^{-1}$	$1.0 \times 10^{-10}$	
TETRACHLOROETHANE, 1,1,1,2-TETRACHLOROETHANE, 1,1,2,2-TETRACHLOROETHYLENE (PCE)	75-56-9	58	25	405,000	34	482	6,621	$7.0 \times 10^{-5}$	$2.0 \times 10^{-3}$	$3.0 \times 10^{-2}$	$3.7 \times 10^{-6}$
TETRAHYDROFURAN	100-42-5	104	910	300	145	636	8,737	$2.8 \times 10^{-3}$	$6.5 \times 10^{-2}$	$1.0 \times 10^{-10}$	
TOLUENE	630-20-6	168	980	1,100	131	624	9,768	$2.5 \times 10^{-3}$	$5.6 \times 10^{-2}$	$7.4 \times 10^{-6}$	$7.4 \times 10^{-6}$
TRIBROMOMETHANE (BROMOFORM)	79-34-5	168	79	2,860	147	661	8,996	$3.7 \times 10^{-4}$	$8.6 \times 10^{-3}$	$4.0 \times 10^{-2}$	$5.8 \times 10^{-5}$
TRICHLOROETHANE, 1,1,2-TRIFLUOROETHANE, 1,1,2-TRICHLOROBENZENE, 1,2,4-TRICHLOROBENZENE, 1,3,5-TRICHLOROETHANE, 1,1,1-TRICHLOROETHANE, 1,1,2-TRICHLOROETHANE, 1,1,2-	127-18-4	166	300	162	121	620	8,288	$1.8 \times 10^{-2}$	$4.4 \times 10^{-1}$	$4.0 \times 10^{-2}$	$2.6 \times 10^{-7}$
	109-99-9	72	43	300,000	66	541	7,074	$7.1 \times 10^{-5}$	$1.9 \times 10^{+2}$	$2.0 \times 10^{+0}$	$1.9 \times 10^{-6}$
	108-88-3	92	130	532	111	592	7,930	$6.6 \times 10^{-3}$	$1.7 \times 10^{-1}$	$5.0 \times 10^{+0}$	
	75-25-2	253	130	3,050	149	696	9,479	$5.4 \times 10^{-4}$	$1.2 \times 10^{-2}$	$2.0 \times 10^{-1}$	$1.1 \times 10^{-6}$
	76-13-1	187	1200	170	48	487	6,463	$5.3 \times 10^{-1}$	$1.5 \times 10^{+1}$	$3.0 \times 10^{+1}$	
	120-82-1	181	1500	44	213	725	10,471	$1.4 \times 10^{-3}$	$2.9 \times 10^{-2}$	$2.0 \times 10^{-3}$	
	108-70-3	181	3100	6	208	744	10,600	$1.9 \times 10^{-3}$	$3.9 \times 10^{-2}$	$2.0 \times 10^{-3}$	
	71-55-6	133	100	1,495	74	545	7,136	$1.7 \times 10^{-2}$	$4.7 \times 10^{-1}$	$5.0 \times 10^{+0}$	
	79-00-5	133	76	4,420	114	602	8,322	$8.2 \times 10^{-4}$	$2.0 \times 10^{-2}$	$2.0 \times 10^{-4}$	$1.6 \times 10^{-5}$



**Table A-5. Vapor Intrusion Screening Value Calculation Parameters (cont.)**

Regulated Substance	CAS No.	MW (g/mol)	$K_{oc}$ (L/kg)	$S$ (mg/L)	$T_B$ (°C)	$T_C$ (K)	$\Delta H_{v,b}$ (cal/mol)	$H$ (atm-m <sup>3</sup> /mol)	$H'$ (@ $T_{hw}$ )	RfC <sub>i</sub> (mg/m <sup>3</sup> )	IUR (µg/m <sup>3</sup> ) <sup>-1</sup>
TRICHLOROETHYLENE (TCE) [M]	79-01-6	131	93	1,100	87	544	7,505	$9.9 \times 10^{-3}$	$2.6 \times 10^{-1}$	$2.0 \times 10^{-3}$	$4.0 \times 10^{-6}$
TRICHLOROPROPANE, 1,2,3- [M]	96-18-4	147	280	1,896	157	652	9,171	$3.4 \times 10^{-4}$	$7.9 \times 10^{-3}$	$3.0 \times 10^{-4}$	
TRICHLOROPROPENE, 1,2,3-	96-19-5	145	190	2,700	142	623	8,585	$1.8 \times 10^{-2}$	$4.2 \times 10^{-1}$	$3.0 \times 10^{-4}$	
TRIETHYLAMINE	121-44-8	101	51	55,000	90	536	8,095	$1.5 \times 10^{-4}$	$3.7 \times 10^{-3}$	$7.0 \times 10^{-3}$	
TRIMETHYLBENZENE, 1,3,4- (TRIMETHYLBENZENE, 1,2,4-)	95-63-6	120	2200	56	169	649	9,369	$6.2 \times 10^{-3}$	$1.4 \times 10^{-1}$	$7.0 \times 10^{-3}$	
TRIMETHYLBENZENE, 1,3,5- *	108-67-8	120	660	49	165	637	9,321	$8.8 \times 10^{-3}$	$1.9 \times 10^{-1}$	$7.0 \times 10^{-3}$	
VINYL ACETATE	108-05-4	86	2.8	20,000	73	519	7,800	$5.1 \times 10^{-4}$	$1.3 \times 10^{-2}$	$2.0 \times 10^{-1}$	
VINYLBROMIDE (BROMOETHENE)	593-60-2	107	150	4,180	16	464	5,398	$1.2 \times 10^{-2}$	$3.8 \times 10^{-1}$	$3.0 \times 10^{-3}$	$3.2 \times 10^{-5}$
VINYLCHLORIDE [M]	75-01-4	63	10	2,700	-13	432	5,250	$2.8 \times 10^{-2}$	$8.8 \times 10^{-1}$	$1.0 \times 10^{-1}$	$9.0 \times 10^{-6}$
XYLENES (TOTAL)	1330-20-7	106	350	175	140	616	8,523	$5.2 \times 10^{-3}$	$1.2 \times 10^{-1}$	$1.0 \times 10^{-1}$	

**Notes to Table A-5**

\* 1,3,5-trimethylbenzene does not have a RfC<sub>i</sub> value defined in Chapter 250, Appendix A, Table 5A. The Department has selected 1,2,4-trimethylbenzene as a surrogate chemical and assigns its RfC<sub>i</sub> as a conservative value.

Symbol	Definition	Source
MW	molecular weight	VISL Calculator (U.S. EPA, 2014a), or alternate
$K_{oc}$	organic carbon partition coefficient	Chapter 250, Appendix A, Table 5A
$S$	aqueous solubility	Chapter 250, Appendix A, Table 5A
$T_B$	boiling point temperature	Chapter 250, Appendix A, Table 5A
$T_C$	critical temperature	VISL Calculator (U.S. EPA, 2014a), or alternate
$\Delta H_{v,b}$	enthalpy of vaporization at the normal boiling point	VISL Calculator (U.S. EPA, 2014a), or alternate
$H$	Henry's law constant	VISL Calculator (U.S. EPA, 2014a), or alternate
$H'$	Dimensionless Henry's law constant	Calculated in the VISL Calculator (U.S. EPA, 2014a)
$T_{hw}$	Groundwater temperature (16°C)	Appendix B, Section 3
RfC <sub>i</sub>	Inhalation reference concentration	Chapter 250, Appendix A, Table 5A
IUR	Inhalation unit risk	Chapter 250, Appendix A, Table 5A
[M]	Mutagenic substance	Section 250.301(b)

Alternate sources include:

- The U.S. National Institutes of Health online Hazardous Substances Data Bank
- DEP's Land Recycling Program online Chemical and Physical Properties Database
- EPA's Johnson & Ettlinger model (U.S. EPA, 2004)

## Appendix B: Vapor Intrusion Modeling Guidance

DEP recommends the use of EPA's Johnson & Ettinger model (U.S. EPA, 2004) for analyzing VI with the Statewide health and site-specific standards. Remediators should use DEP's versions of the model which are based on EPA's advanced model version 3.1 spreadsheets. These versions are posted on DEP's website, and they will be updated periodically with current scientific information when Chapter 250 MSCs are revised.

This appendix describes key assumptions and limitations of the Johnson & Ettinger (J&E) model, acceptable adjustments to default input values, and the use of alternative models for petroleum hydrocarbons.

### 1. Background

The J&E model solves for the transport of vapor-phase contaminants into a building above the source (Johnson and Ettinger, 1991; U.S. EPA, 2004). There are three spreadsheets for the different source types: groundwater, soil, and soil gas. The model calculates the vaporization of dissolved or adsorbed contaminants, the diffusion of these vapors toward the surface, their advection through the foundation or slab into the occupied space, and their dilution in indoor air. The calculations rely on five sets of parameters integral to this process and the inhalation risk assessment:

- source description (e.g., depth)
- chemical properties
- toxicological properties
- capillary fringe and vadose zone properties (e.g., soil type)
- building characteristics (e.g., air exchange rate).

The J&E model is an approximation that is dependent on many parameters, not all of which are well known. It is not easily calibrated; therefore, the user should input conservative values to avoid underestimating inhalation risks. Users submitting J&E models to DEP are expected to be familiar with EPA's *User's Guide* and should understand the model's assumptions and limitations (U.S. EPA, 2004).

Several studies have compared J&E model results to field data (Hers *et al.*, 2003; Provoost *et al.*, 2009, 2010) and to numerical analyses (Yao *et al.*, 2011). This research indicates that J&E gives reasonable, conservative results in most cases, within about one order of magnitude. These studies reinforce the need to use J&E with caution because the model is highly sensitive to some parameters. It is essential to have adequate site data and a strong CSM when modeling VI.

The objective of VI modeling is to determine if an Act 2 standard is attained. Although the EPA spreadsheets can calculate screening values, models submitted to DEP should not be used in this manner. Users must instead input the contaminant concentration on the DATENTER worksheet to calculate the incremental risk. The DEP versions give results in two forms, depending on the Act 2 standard selected for the contaminant.

- For Statewide health standard evaluations the user compares the predicted indoor air concentration on the RESULTS sheet to the Statewide health standard indoor air screening value ( $SV_{IA}$ ) (Table 5).
- For site-specific standard risk assessments the user obtains the incremental carcinogenic and noncarcinogenic inhalation risks from the RESULTS sheet, determines the cumulative risks for all site-specific standard contaminants of concern, and compares the cumulative risks to the Act 2 thresholds (Section K.5).

Under appropriate conditions in the site-specific standard, predicted indoor air concentrations can be compared to occupational limits (OSHA PELs) (Section K.7).

## 2. Assumptions

Users are referred to EPA's *J&E User's Guide* for a complete description of the model (U.S. EPA, 2004). It has several critical assumptions and limitations that all users must be aware of.

- The source extent is horizontally and vertically infinite. Source mass does not diminish with time. These are conservative assumptions.
- No SPL is present for soil and groundwater modeling.
- The solution is one-dimensional, accounting only for vertical vapor transport; lateral migration of vapors is ignored.
- Soil properties are homogeneous.
- There is no biodegradation of contaminant vapors in the vadose zone, a conservative assumption.
- There are no preferential pathways between the source and the building.
- The system is in steady state; that is, vapor transport is in equilibrium.
- The model does not account for the combined effects of multiple contaminants.

In addition, see U.S. EPA (2004) Sections 2.11 and 5.

## 3. J&E Model Parameter Adjustments

Key input parameters and allowable changes to these values for VI modeling are explained in this section. The Department's conservative default model parameter values, as input on the DATENTER sheet of the J&E spreadsheet, are given in Table B-1. Most input values used are EPA's defaults.

**Table B-1. Adjustable J&E Model Input Parameters and Default Values**

<b>Parameter</b>	<b>Symbol</b>	<b>Residential</b>	<b>Nonresidential</b>
Average soil/groundwater temperature (°C)	$T_s$	Table B-2	Table B-2
Depth below grade to bottom of enclosed space floor <sup>1</sup> (cm)	$L_F$	15 / 200	15 / 200
Depth below grade to source (cm)	$L_{WT}, L_t, L_s$	150	150
Thickness of soil strata (cm)	$h$	150	150
Capillary and vadose zone USDA soil types		sandy loam	sandy loam
Soil dry bulk density <sup>2</sup> (g/cm <sup>3</sup> )	$\rho_b$	1.62	1.62
Soil total porosity <sup>2</sup>	$n$	0.387	0.387
Soil water-filled porosity <sup>2</sup>	$\theta_w$	0.1	0.1
Enclosed space floor thickness (cm)	$L_{crack}$	10	10
Soil–building pressure differential (g/cm-s <sup>2</sup> )	$\Delta P$	40	20
Enclosed space floor length (cm)	$L_B$	1000	1000
Enclosed space floor width (cm)	$W_B$	1000	1000
Enclosed space height <sup>3</sup> (cm)	$H_B$	244 / 366	244 / 366
Floor–wall seam crack width (cm)	$w$	0.1	0.1
Indoor air exchange rate (hr <sup>-1</sup> )	ER	0.18	0.60
Average vapor flow rate into building <sup>4</sup> (L/min)	$Q_{soil}$	5	5

**Notes to Table B-1**

<sup>1</sup> Default is 15 cm for a slab-on-grade building and 200 cm for buildings with basements.

<sup>2</sup> The values shown are for a sandy loam. Models must use the J&E default values associated with the selected soil type unless soil samples are tested for physical characteristics.

<sup>3</sup> Default is 244 cm for slab-on-grade buildings and 366 cm for buildings with basements.

<sup>4</sup> Adjust default based on building size; see text.

- Source concentration ( $C_w, C_R, C_g$ ):** The user enters an appropriate contaminant concentration for groundwater ( $C_w$ , µg/L), soil ( $C_R$ , µg/kg), or soil gas ( $C_g$ , µg/m<sup>3</sup>). Source data should conform to the conditions in Table 6. Input concentrations should generally be the maximum from recent sampling in the source area near current or future buildings (see Appendix C, Figures C-1–3). If sufficient data are available, a 95% upper confidence limit of the mean may be a suitable value. The data selected for determining the source concentration may have been collected for the site characterization and/or the demonstration of attainment. When the vapor source is a groundwater plume, fate-and-transport modeling may be used to estimate groundwater concentrations at downgradient receptors if monitoring well data is unavailable. The groundwater model should be calibrated, conservative, and applied in a manner consistent with DEP’s Quick Domenico user’s guide (Pennsylvania DEP, 2014). For the soil gas J&E model only near-source soil gas data may be used, and the source may include SPL.
- Building foundation:** The default foundation type is slab-on-grade construction. The type of foundation establishes the value of the depth below grade of the enclosed space floor ( $L_F$ ). For slab-on-grade foundations the EPA default is  $L_F = 15$  cm (0.5 feet); for basements it is  $L_F = 200$  cm (6.6 feet). This value may be altered with supporting documentation for the site building.

- **Depth below grade to source ( $L_{WT}$ ,  $L_t$ ,  $L_s$ ):** The default value is 150 cm (5 feet). The user enters the actual minimum depth based on the site characterization and/or monitoring data. For groundwater it should be the seasonally high water table depth of the contaminated aquifer ( $L_{WT}$ ). For soil it should be the depth to the top of contaminated soil ( $L_t$ ). DEP recommends using the shallowest depth that either exceeds the soil screening value ( $SV_{SOIL}$ ) or that is contaminated as indicated by field screening. For soil gas the source depth is the top of the screen in the soil gas probe ( $L_s$ ).

Acceptable soil or soil-like material should be present between the building foundation and the contaminant source. Acceptable soil or soil-like material will not have the following characteristics: obvious contamination (staining or odors), field instrument readings in the head space above soil samples greater than 100 ppmv, evidence of separate phase liquids, or exceedances of soil screening values (refer to Section B of the guidance). The thickness of acceptable soil or soil-like material may be less than 5 feet.

Where there is a basement, the source must be entirely below the foundation as J&E does not model lateral vapor transport. Soil or groundwater with concentrations exceeding screening values cannot be in contact with the foundation. J&E simulates vapor diffusion through homogeneous, isotropic porous media. Therefore, it cannot determine vapor migration through fractured bedrock. If the water table is below the bedrock interface, then the model groundwater source depth ( $L_{WT}$ ) should be input as the depth to bedrock. A continuous layer of acceptable soil or soil-like material should be present between the bedrock surface and the building foundation.

- **Depth below grade to bottom of contamination ( $L_b$ ):** A finite source calculation is allowed for the soil model if the depth to the bottom of the contaminated soil has been delineated.
- **Soil/groundwater temperature ( $T_s$ ):** Long-term average subsurface temperatures depend on the average air temperature of the locale and the nature of the surface material. Ground temperatures are higher in developed areas with buildings and pavement than where the land is undeveloped. DEP has compiled shallow groundwater temperature data collected during low-flow purging of monitoring wells at sites in the Southeast Region. In addition, DEP has examined continuous soil temperature data from three U.S. Department of Agriculture, Natural Resources Conservation Service, Soil Climate Analysis Network stations (Mahantango Creek, PA, Rock Springs, PA, and Powder Mill, MD). Each data set was compared to air temperature data collected from weather stations during corresponding periods. This information was supplemented with the study by Taylor and Stefan (2008).

Average shallow subsurface temperatures are typically  $\sim 4^\circ\text{C}$  higher than local air temperatures. DEP recommends using a model soil/groundwater temperature that is  $4^\circ\text{C}$  greater than the long-term average air temperature for the region. Thirty-year average temperatures for 1986–2015 available from the National Oceanic and Atmospheric Administration’s NOWData application ranged from  $50^\circ\text{F}$  to  $56^\circ\text{F}$  for Pennsylvania ( $10\text{--}14^\circ\text{C}$ ). Therefore, estimated regional average soil/groundwater temperatures are  $14\text{--}18^\circ\text{C}$  (Table B-2).

**Table B-2. Pennsylvania Shallow Soil and Groundwater Temperatures**

Northwest Region 14°C	Northcentral Region 15°C	Northeast Region 14°C
Southwest Region 15°C	Southcentral Region 16°C	Southeast Region 18°C

Users may input a site-specific soil and groundwater temperature based on data from a local weather station. The long-term average air temperature should be increased by 4°C for input as  $T_s$ . Discrete groundwater temperature measurements collected over a short period of time may not be representative of long-term conditions.

- Soil type:** It is the user’s responsibility to assess soil boring logs to select an appropriate soil type for input to the model. Field logging of borings should be performed by a qualified environmental professional (i.e., a geological scientist or a soil scientist). Where the soil is heterogeneous or there are different interpretations of the soil type, professional judgment must be used, but the best practice is to select the soil type with the greatest vapor intrusion potential. This may require sensitivity testing of the model. The user may define up to three soil layers in the model if sufficient data has been obtained to support this option. The soil type entry in DEP’s model versions is a sandy loam as a conservative default.

EPA categorized soil using the U.S. Department of Agriculture’s Soil Conservation Service (SCS) (now the Natural Resources Conservation Service) soil types. To select the soil type, the environmental professional interprets boring logs based on the Unified Soil Classification System (ASTM, 2011a) in terms of the SCS classifications. A gradation analysis of soil samples is the best means to select the proper soil type in J&E (ASTM, 2007). Table B-3 can also assist the user with this selection, and Figure B-1 shows the SCS soil types in terms of the proportions of clay, silt, and sand.


If artificial fill is present then the user must be cautious in applying the J&E model to the site. The fill might have characteristics sufficiently close to a USDA soil type to be acceptable for modeling; if so, the user can choose an appropriate soil type with justification in the report.

**Table B-3. Guidance for the Selection of the J&E Model Soil Type**

<b>Predominant Soil Types in Boring Logs</b>	<b>Recommended Soil Classification</b>
• Sand or Gravel or Sand and Gravel, with less than about 12% fines, where “fines” are smaller than 0.075 mm in size.	Sand
• Sand or Silty Sand, with about 12% to 25% fines	Loamy Sand
• Silty Sand, with about 20% to 50% fines	Sandy Loam
• Silt and Sand or Silty Sand or Clayey, Silty Sand or Sandy Silt or Clayey, Sandy Silt, with about 45 to 75% fines	Loam
• Sandy Silt or Silt, with about 50 to 85% fines	Silt Loam

Source: U.S. EPA (2004), Table 11

**Figure B-1. USDA SCS Soil Classification Chart**



Source: USDA (1993, Ch. 3).

- Soil properties:** DEP has adopted the EPA default values for bulk soil density ( $\rho_b$ ) and total porosity ( $n$ ), which depend on the soil type. These values should not be altered unless properly collected samples (e.g., in thin-walled tubes) have been analyzed for these parameters (ASTM, 2009, 2010a). DEP does not consider the EPA default water-filled porosity values ( $\theta_w$ ) to be sufficiently conservative because soil beneath buildings is relatively dry. DEP's default value is 0.1 or the residual saturation ( $\theta_r$ ), whichever is greater for the soil type. The user can change  $\theta_w$  only based on laboratory analyses of the moisture content of properly collected soil samples from underneath the building or an intact paved area large enough to be representative of a future inhabited building (ASTM, 2010b).
- Fraction of organic carbon ( $f_{oc}$ ):** The default value is 0.0025 from EPA and Section 250.308(a). The user may change this value for soil modeling only with laboratory measurements of  $f_{oc}$  in site soils (e.g., U.S. EPA Method 9060A). However, the  $f_{oc}$  may be set to zero if the material is not believed to contain any organic carbon.

- **Floor thickness ( $L_{\text{crack}}$ ):** The EPA default value is 10 cm (4 inches). This may be changed by the user if the actual (or planned) slab thickness is known. A dirt floor may be simulated with a value of zero.
- **Building dimensions ( $L_B$ ,  $W_B$ ,  $H_B$ ):** The EPA default residential floor space area is 1,080 ft<sup>2</sup> (100 m<sup>2</sup>) for a 10- by 10-m home. Default enclosed space heights ( $H_B$ ) are 244 cm (8 feet) for slab-on-grade buildings and 366 cm (12 feet) for structures with basements. Note, however, that if indoor air does not communicate efficiently between the basement and the first floor, then the default value is not conservative and it should be reduced. The user may input the actual (or planned) building dimensions.
- **Air exchange rate (ER):** Air exchange rates exhibit a large range for different buildings and seasons. DEP adopts the current 10<sup>th</sup> percentile residential value of 0.18 hr<sup>-1</sup> (U.S. EPA, 2011b, Ch. 19). The measured range in a study of 100 office buildings was approximately 0.2–4.5 per hour (Persily and Gorfain, 2009). A 10<sup>th</sup> percentile nonresidential value is 0.60 hr<sup>-1</sup> (U.S. EPA, 2011b, Ch. 19). The user should input these 10<sup>th</sup>-percentile values for residential and nonresidential buildings. The actual air exchange rate of an existing or planned building may be input to the J&E model if it has been measured or is documented in the HVAC system design and settings.
- **Vapor flow rate ( $Q_{\text{soil}}$ ):** The soil gas flow rate into buildings is highly uncertain, and it depends on the material in contact with the foundation, the arrangement of cracks and other foundation openings, the pressure differential, and other factors. The EPA default value is 5 L/min based on tracer gas studies at five sites summarized by Hers *et al.* (2003). In the absence of better information on this parameter, DEP's default  $Q_{\text{soil}}$  is 5 L/min. If the user changes the building dimensions ( $L_B$  and  $W_B$ ) then the value of  $Q_{\text{soil}}$  should be scaled correspondingly. Assuming vapor entry through foundation perimeter cracks, the scale factor is the ratio of the building perimeters. The default perimeter for the 10- by 10-m building is 40 m (130 feet). For example, if the building dimensions are 50 feet by 100 feet, the perimeter is 300 feet, the scale factor is 2.3, and  $Q_{\text{soil}} = 12$  L/min.

The J&E model will calculate an estimated  $Q_{\text{soil}}$  rate if this field is left blank. The calculation will depend on the permeability of the soil in contact with the foundation. Most buildings are assumed to have a relatively coarse-grained material beneath the foundation, and 5 L/min is an appropriate minimum value. If the user has detailed knowledge of the native soil type that is present beneath and in contact with the foundation, this soil type may be entered in the “Soil stratum A SCS soil type (used to estimate soil vapor permeability)” field and the  $Q_{\text{soil}}$  field may be left blank. The report should justify this selection with data for soil samples collected from beneath the foundation and described by an environmental professional (i.e., a geological scientist or a soil scientist).

Another option is to enter a soil vapor permeability value and allow the model to calculate  $Q_{\text{soil}}$ . This is permitted only if the user obtains vapor permeability test data for the soil in contact with the foundation (ASTM, 2013a).

- **Pressure differential ( $\Delta P$ ):** The pressure differential only affects the model calculation of  $Q_{\text{soil}}$ . EPA's default residential value is 40 g/cm-s<sup>2</sup> (4 Pa). The ventilation system



design of commercial buildings typically results in less under-pressurization than in homes (Hers *et al.*, 2001). DEP allows a value of  $20 \text{ g/cm-s}^2$  (2 Pa) for nonresidential modeling. If the remediator can document the actual or planned ventilation system design for a building, that information may be used in the model.

- **Crack width ( $w$ ):** The crack width only affects the model calculation of  $Q_{\text{soil}}$ . EPA's default value is 0.1 cm. This value may be changed only with a documented study of the foundation cracks in the modeled building.

Chemical, physical, and toxicological properties for substances with VI potential are found in the VLOOKUP sheet. DEP's default values are listed in Appendix A, Table A-5. These default properties and the default residential or nonresidential exposure factors cannot be changed in Statewide health standard modeling. (Model-predicted indoor air concentrations for the Statewide health standard do not depend on the exposure factors on the DATENTER sheet.)

The EPA J&E model versions do not account for the effect of mutagenic chemicals on the cancer risks for residential exposure scenarios. The inhalation risk equations for mutagens are provided in Appendix A. DEP's versions of the spreadsheets include a mutagenic risk adjustment factor (MRF) that is applied when the exposure time is entered as 24 hr/day. For the default conditions, MRF = 1.4 for trichloroethylene, 3.4 for vinyl chloride, and 2.5 for other mutagens.

#### 4. Site-Specific Standard Parameter Adjustments

Users of the J&E model may change certain chemical and toxicological properties in the VLOOKUP sheet for the site-specific standard.

- **Organic carbon partition coefficient ( $K_{oc}$ ):** The default values are from Chapter 250, Appendix A, Table 5A. The values may be changed only if the user obtains laboratory test data of soil samples collected at the site.
- **Toxicity parameters (IUR,  $RfC_i$ ):** The inhalation unit risk (or unit risk factor, URF) and the inhalation reference concentration are from Chapter 250, Appendix A, Table 5A. For a site-specific standard risk assessment, the user should determine if there is more recent toxicity information available. Current values should be substituted for the Chapter 250 values, if available.

Exposure factors are entered on the DATENTER sheet for site-specific standard risk assessments. The default values are listed in Table B-4. Residential factors should not be changed. The user may adjust nonresidential factors based on conditions at the site. For instance, the daily exposure time could depend on the workplace shift length. EPA currently recommends a residential exposure duration of 26 years (U.S. EPA, 2014b), which may be used in site-specific standard models. (DEP's versions of the J&E spreadsheets include a field for the exposure time (ET), allowing it to be altered from the residential default of 24 hr/day.)

**Table B-4. J&E Model Default Exposure Factors**

<b>Symbol</b>	<b>Term</b>	<b>Residential</b>	<b>Nonresidential</b>
AT <sub>nc</sub>	Averaging Time for systemic toxicants (yr)	30	25
ET	Exposure Time (hr/day)	24	8
EF	Exposure Frequency (days/yr)	350	250
ED	Exposure Duration (yr)	30	25
AT <sub>c</sub>	Averaging Time for carcinogens (yr)	70	70

## 5. Petroleum Hydrocarbons

DEP can accept the use of models that account for biodegradation when evaluating petroleum hydrocarbon vapor intrusion. An example is the American Petroleum Institute's BioVapor (API, 2010).

BioVapor has several additional parameters that must be assessed in the modeling. The user should test the model sensitivity to these values.

- **Oxygen boundary condition:** The user should normally select a constant air flow rate ( $Q_f$ ), and this is typically set equal to the vapor flow rate through the foundation (e.g.,  $Q_{soil} = 5$  L/min). If site data is collected to determine vertical profiles of oxygen, carbon dioxide, and methane concentrations, then the user may estimate the depth of the aerobic zone for model input.
- **Baseline soil oxygen respiration rate:** The model scales this rate with the fraction of organic carbon ( $f_{oc}$ ), which is not typically known for the site.
- **Biodegradation rate constants ( $k_w$ ):** BioVapor selects default first-order, aqueous phase, aerobic decay rates. Actual degradation rates are extremely variable. Vertical profiling of contaminant concentrations in soil gas may allow the user to estimate the decay rates.

EPA produced a NAPL version of the J&E model (U.S. EPA, 2004). This model was limited to residual NAPL in soil; it was not applicable to mobile NAPL on groundwater. DEP has not developed an updated version of EPA's NAPL spreadsheet. DEP recommends the collection of near-source soil gas data in areas of SPL (NAPL) for purposes of VI modeling.

## 6. Attenuation Factor Risk Calculations

Site-specific standard screening and risk assessments may also be performed under certain conditions with near-source soil gas and sub-slab soil gas data by using conservative attenuation factors ( $\alpha$ ). An attenuation factor is the ratio between the contaminant concentration in indoor air and the equilibrium soil gas concentration in the unsaturated zone ( $\alpha \equiv C_{IA}/C_{SG}$ ). Therefore, conservative indoor air concentrations may be estimated using a measured or calculated soil gas concentration and an appropriate attenuation factor. Refer to Appendix A for the relevant equations and Table A-4 for DEP's default attenuation factors. The conditions for using near-source soil gas attenuation factors are the same as those listed for the screening values in the VI Guidance, Table 6.

Other soil gas attenuation factors may be used with adequate justification for the site-specific standard. For instance, a tracer test could be used to determine a sub-slab attenuation factor ( $\alpha_{SS}$ ) for the building. The default attenuation factors may be scaled with actual air exchange rates (AER) for the building. DEP's default indoor air exchange rates are  $0.18 \text{ hr}^{-1}$  for residential properties and  $0.60 \text{ hr}^{-1}$  for nonresidential facilities. The adjusted attenuation factor ( $\alpha'$ ) is the product of the default attenuation factor and the ratio of the default AER and the actual AER. For example, if a nonresidential building has a measured air exchange rate of  $1.2 \text{ hr}^{-1}$ , then the sub-slab attenuation factor may be reduced as follows:

$$\alpha'_{SS,NR} = \alpha_{SS,NR} \frac{0.60 \text{ hr}^{-1}}{1.2 \text{ hr}^{-1}} = (0.0078) \frac{0.60 \text{ hr}^{-1}}{1.2 \text{ hr}^{-1}} = 0.0039$$

## 7. Report Contents

The J&E modeling should be fully documented in the submitted report. The information provided should be sufficient for DEP to understand how the modeling was performed and to reproduce the results. The model description should include the following.

- An explanation for how the model is being used to evaluate the VI pathway; that is, for a Statewide health standard prediction of indoor air concentrations or a site-specific standard human health risk assessment.
- A list of the contaminants of concern being modeled and the input source concentrations.
- An explanation of how source concentrations were selected (for example, the maximum groundwater concentrations from monitoring well data).
- A table of all input parameters, such as source depth and soil type.
- The reasoning for any changes to default input values.
- References for any changes to toxicological values in site-specific standard models.
- A table of the predicted indoor air concentrations for each contaminant of concern in Statewide health standard reports, or a table of the individual and cumulative inhalation risks in site-specific standard reports.
- A figure showing the source area, the locations of sample points used for the source concentrations, any preferential pathways, and potentially impacted buildings.
- An appendix with J&E worksheet printouts for the modeling. The DATENTER and RESULTS sheets should be provided for each contaminant of concern. One copy of the VLOOKUP sheet should be included.

## Appendix C: Vapor Intrusion Sampling Methods

### 1. Introduction

This appendix provides guidance on sampling and testing procedures to support VI investigations and mitigation. It describes recommendations for collecting VI-related samples, but it is not meant to be a manual with step-by-step instructions for VI sampling requirements. Professional judgment should be exercised during the development of sampling plans considering that every site will have its own unique conditions. Remediators are encouraged to communicate with the DEP Project Manager in order to determine the best path forward for VI sampling.

The information in Appendix C includes descriptions of the methods and quality assurance procedures to be used when collecting and analyzing VI-related samples. DEP's focus is on sampling with Summa canisters and U.S. EPA Method TO-15 analyses. When other methods are used the remediator should refer to alternative sources and consult with the laboratory. This appendix also provides guidance on testing to confirm the effectiveness of sub-slab depressurization systems which are the most commonly used VI mitigation technology for existing buildings.

#### a) Applicability

The guidance supplied by this appendix applies whenever sampling and analysis of soil gas or indoor air is performed:

- During site characterization;
- During site monitoring following site characterization;
- Following remediation; or
- When mitigation is performed using sub-slab depressurization (SSD) systems.

The information provided herein may be used to address VI sampling or mitigation activities under either the Statewide health standard or the site-specific standard or under a combination of these two standards. These procedures also apply regardless of the size or scope of the VI evaluation when sampling and analysis of indoor air or soil gas is performed or a SSD System is used to mitigate VI.

#### b) Conceptual Site Model Development

A comprehensive CSM is an important tool in the development of a sampling and analysis plan. The CSM is needed to determine the locations and types of samples that are to be taken. More information on the development of a comprehensive conceptual site model can be found in Section C.1.

### c) **Spatial and Temporal Variability Considerations**

When preparing a VI sampling plan it is important to consider the spatial and temporal variability of contamination in soil gas and indoor air. Spatial variability refers to non-uniform concentrations at different locations within or beneath the same building. Temporal variability involves concentrations that change from one sampling event to the next. Compared to groundwater concentrations, there are many complicating factors that can cause significant variability in vapor data.

Some causes of spatial variability include:

- Distribution of the source in soil or groundwater;
- Natural heterogeneity (different soil types, soil moisture, bedrock fractures);
- Oxygen distribution in the soil (aerobic/anaerobic conditions);
- Subsurface building structures (footers, utilities);
- Surface features (pavement).

Some causes of temporal variability include:

- Wind, barometric pressure, temperature;
- Precipitation, infiltration, soil moisture, frozen ground;
- Building ventilation, heating, cooling;
- Ambient contaminants (indoor and outdoor sources);
- Sampling errors (equipment leaks).

Research studies have been conducted regarding the spatial variability of vapor concentrations by collecting multiple samples beneath, around, or within buildings (e.g., McHugh *et al.*, 2007; Luo *et al.*, 2009; U.S. EPA, 2012b, 2015c). The results of these studies have shown that sub-slab and soil gas concentrations can span orders of magnitude at a given building, even for moderately sized homes. Indoor air concentrations tend to show less variability as indoor air is typically well mixed in homes and smaller nonresidential buildings. Larger buildings may show greater room-to-room variability influenced by spatial heterogeneity of VI in those areas, possible indoor sources, and different ventilation conditions. For the same reasons, a sample collected at one building may not be representative of conditions at a neighboring building.

Accounting for VI spatial variability in the sampling plan is similar to adequately characterizing soil contamination at a site: a sufficient number of sample points must be installed to evaluate representative concentrations. The CSM should be the guide for choosing these locations. The horizontal and vertical distribution of the vapor source

relative to the building, the soil and bedrock conditions, likely pathways to and through the foundation, and the building characteristics (construction, ventilation, etc.) should be considered by the environmental professional developing the sampling approach. Based on site-specific conditions, a single sample location may not be adequate.

Repeat sampling of the same location at several study sites has similarly demonstrated substantial changes in vapor concentrations over time (e.g., Folkes *et al.*, 2009; U.S. EPA, 2010, 2012b, 2012c, 2015c, 2015d; Holton *et al.*, 2013). Soil gas, sub-slab, and indoor air concentrations have been found to vary by up to three orders of magnitude over periods of months to years. Shallow soil gas tends to have much greater variability than deeper soil gas, making near-source soil gas a more reliable measure of vapor intrusion. Much of the variability of indoor air data can be attributed to conditions other than vapor intrusion.

Temporal and spatial variability in soil gas and indoor air sample results is addressed by using a combination of multiple rounds of samples and multiple sample locations. The goal is to collect sufficient data to determine representative concentrations beneath or within the building. Refer to Section G.2 and Table 7 for recommendations on the appropriate number of sampling events and sample locations.


## 2. Sampling Locations

Figures C-1 through C-3 depict simplified vapor intrusion scenarios that illustrate sampling location options for the application of screening values and modeling. They include situations without any preferential pathways (Figure C-1), an external preferential pathway (Figure C-2), and a significant foundation opening (Figure C-3). Vertical proximity distances are not considered in these examples. (See Figures 2 and 3 for additional illustrations of the relationships between sources and buildings in the context of preferential pathways and proximity distances.) The information conveyed in Figures C-1–C-3 must be used in association with the sampling and screening conditions discussed in Sections D, F, G, and K.4, Tables 6 and 7, and the other parts of this appendix. Refer to Appendix B for further details on using sample data in VI models.

In Figure C-1 a release has contaminated soil adjacent to one building, and the resultant groundwater plume potentially affects it and a downgradient building. Building B is beyond the horizontal proximity distance from the soil contamination, so potential VI from soil only needs to be evaluated for Building A. Potential VI impacts from groundwater beneath Building B should be evaluated with monitoring well data near or upgradient of that building. Note that if the remediator chooses to sample near-source soil gas then distinct samples may be required for the soil and groundwater sources near a given building.


Figure C-2 illustrates an external preferential pathway, such as gravel backfill around a utility line that allows vapors to migrate to a building from a source farther than the horizontal proximity distance. (No significant foundation openings are present.) Modeling is not an assessment option for the pathway to the existing building. The remediator may attempt to collect soil gas samples from within the backfill (location 4); they should be evaluated with sub-slab soil gas screening values. See Section D.1 for additional information.

**Figure C-1. Sampling Location Options for the Vapor Intrusion Evaluation of Soil and Groundwater Sources**



Sample	Description	Screen
1	Soil samples in source area, evaluation of Building A. Restriction: No SPL. Modeling: Yes.	SV <sub>SOIL</sub>
2	Groundwater samples in source area, evaluation of Building A. Restriction: No SPL. Modeling: Yes.	SV <sub>GW</sub>
3	Groundwater samples in plume, evaluation of Building B. Restriction: No SPL. Modeling: Yes.	SV <sub>GW</sub>
4	Near-source soil gas samples at soil source, evaluation of Building A. Modeling: Yes.	SV <sub>NS</sub>
5	Near-source soil gas samples above groundwater source, evaluation of Building A. Modeling: Yes.	SV <sub>NS</sub>
6	Near-source soil gas samples above groundwater plume, evaluation of Building B. Modeling: Yes.	SV <sub>NS</sub>
7	Sub-slab soil gas samples beneath Building A foundation.	SV <sub>SS</sub>
8	Sub-slab soil gas samples beneath Building B foundation.	SV <sub>SS</sub>
9	Indoor air samples, evaluation of Building A.	SV <sub>IA</sub>
10	Indoor air samples, evaluation of Building B.	SV <sub>IA</sub>


**Figure C-2. Sampling Location Options for Evaluation of an External Preferential Pathway**



Sample	Description	Screen
<b>1</b>	Soil samples in source area. Restriction: No SPL. Modeling: Permitted for future use over source, but not for current use via preferential pathway.	SV <sub>SOIL</sub>
<b>2</b>	Groundwater samples in source area. Restriction: No SPL. Modeling: Permitted for future use over source, but not for current use via preferential pathway.	SV <sub>GW</sub>
<b>3</b>	Near-source soil gas samples in source area (soil and/or groundwater). Restriction: No groundwater contamination or SPL migrating through preferential pathway. Modeling: Permitted for future use over source, but not for current use via preferential pathway.	SV <sub>NS</sub>
<b>4</b>	Soil gas samples within preferential pathway. Restriction: Preferential pathway must contain a permeable material, such as backfill in a utility line trench. Modeling not permitted.	SV <sub>SS</sub>
<b>5</b>	Sub-slab soil gas samples beneath building foundation. Restriction: Preferential pathway does not penetrate foundation.	SV <sub>SS</sub>
<b>6</b>	Indoor air samples.	SV <sub>IA</sub>



**Figure C-3. Sampling Location Options for Evaluation of a Significant Foundation Opening**



Sample	Description	Screen
1	Soil samples in source area. Restriction: No SPL. Modeling: Enter floor thickness of zero ( $L_{crack} = 0$ ).	SGN*
2	Groundwater samples in source area. Restriction: No SPL. Modeling: Enter floor thickness of zero ( $L_{crack} = 0$ ).	MSC
3	Near-source soil gas samples in soil source area. Modeling: Enter floor thickness of zero ( $L_{crack} = 0$ ).	SV <sub>SS</sub>
4	Near-source soil gas samples above groundwater plume. Modeling: Enter floor thickness of zero ( $L_{crack} = 0$ ).	SV <sub>SS</sub>
5	Sub-slab soil gas samples beneath building foundation. Restriction: Foundation slab must be present.	SV <sub>IA</sub>
6	Indoor air sampling.	SV <sub>IA</sub>

\* Generic soil-to-groundwater numeric value.

Figure C-3 shows sampling locations for a significant foundation opening, such as a section of dirt floor in the basement. In the example the contamination is beneath the building, and there is no external preferential pathway. Soil data can be screened with generic soil-to-groundwater numeric values; groundwater data can be screened with used aquifer MSCs. For screening of near-source soil gas data only sub-slab soil gas screening values should be used. Modeling of soil, groundwater, and near-source soil gas data may be carried out by setting the floor thickness equal to zero (Appendix B). Both sub-slab and indoor air sample data should be screened with indoor air screening values; sub-slab points require an area of intact floor slab. See Section D.2 for further information.

### 3. Near-Source Soil Gas Sampling

#### a) Description

Near-source soil gas is sampled from within the vadose zone, specifically from within nominally 1 foot of the contamination source (contaminated soil or groundwater). For a groundwater source, near-source soil gas samples should be collected within 1 foot of the top of the capillary fringe if the water table occurs in soil. If the water table occurs in bedrock, the near-source soil gas samples should be collected within 1 foot of the soil–bedrock interface.

The height of the capillary fringe is not readily determined in the field. The following table provides theoretical estimates from U.S. EPA (2004, Table 10) which may be used as a guide. (Refer also to Appendix B, Section 3 for additional information on soil type identification.)

**Table C-1. Capillary Fringe Height Estimates**

Soil Type	$L_{cz}$ (cm)	$L_{cz}$ (ft)
Sand	17	0.6
Loamy Sand	19	0.6
Sandy Loam	25	0.8
Sandy Clay Loam	26	0.9
Sandy Clay	30	1.0
Loam	38	1.2
Clay Loam	47	1.5
Silt Loam	68	2.2
Clay	82	2.7
Silty Clay Loam	134	4.4
Silt	163	5.3
Silty Clay	192	6.3

$L_{cz}$ : capillary fringe thickness

#### b) Sample Point Installation

Near-source soil gas sampling points can be temporary (used for one sampling event and decommissioned) or semi-permanent (used for multiple sampling events).

Recommended resources for soil gas points include API (2005), California EPA (2015), ASTM (2012a), Hawaii DoH (2014), and ITRC (2014).

##### i) Installation of Temporary Points

Installation and construction of temporary points may be less time and cost sensitive. However, these potential savings may be offset over the life of the project as new points must be installed for each round of sampling. In general, temporary points rely on the use of boring advancement tools for the collection of the soil gas sample and the sealing of the point from the atmosphere. This is accomplished with the compression of the soil along the sides of the boring against the boring advancement tools. Use of temporary points is not

recommended but may be necessary due to site conditions or site development. Prior to the utilization of temporary points, the feasibility of the following factors should be carefully considered:

- Proper sealing of the sampling interval from the surface;
- Isolation of the sampling interval within the boring;
- Potential of negative effects of boring advancement using drive-point techniques (e.g., decrease of soil gas permeability due to smearing or compression); and
- Unknown correlation of analytical results for multiple sampling rounds.

**ii) Installation and Construction of Semi-Permanent Points**

Semi-permanent points are generally constructed in borings advanced using conventional drilling technologies and sealing of the point is accomplished using bentonite or grout in the annulus of the boring. Boring advancement techniques should attempt to minimize disturbance of the vadose zone geologic strata and soil vapor column. Drilling methods that introduce air (e.g., air rotary) or liquid (e.g., mud-rotary) should be avoided.

**4. Sub-Slab Soil Gas Sampling**

**a) Description**

Sub-slab soil gas is sampled immediately below the floor slab of a building. The slab can be at grade (slab-on-grade) or below grade (basement).

**b) Location**

Sub-slab soil gas is located beneath the slab in the porosity of the native soil, ballast stone, or gravel that the building slab was placed over. Sub-slab soil gas sampling locations should be determined based on the specific characteristics of the building being sampled and the objectives of the sampling plan. Whenever possible, sampling locations should be biased toward areas of the building with the greatest expected VI impact, based on a combination of the location of VI sources and building occupancy and use. In general, sampling locations are at least 5 feet from perimeter foundation walls and sampling next to footers, large floor cracks, and apparent slab penetrations (e.g., sumps, floor drains) should be avoided.

**c) Sample Point Installation**

Sub-slab soil gas sampling points can be temporary (used for one sampling event and decommissioned) or semi-permanent (used for multiple sampling events). The building occupancy, use, and project goals are influential in the determination of which type of sampling point to use. A pre-survey, as described in Section 8(a)(i) herein, can be completed to assist in determining this information. Generally, installation and

construction of temporary points is less time and cost intensive. However, these potential savings may be offset over the life of the project as new points must be installed for each round of sampling.

Sub-slab soil gas sampling points are generally installed inside penetrations through the building slab. Penetrating the floor slab can be accomplished using a hammer drill and bit, a core drill, or direct-push technology. Care should be taken during the floor slab penetration activities to avoid the creation of cracks in the slab. Additionally, the use of water or other lubricants and coolants during the advancement of the floor slab penetration should be compatible with the sampling analyte list and may result in the need for additional point equilibration time (see Section 8(a)(iv) herein) or the need to develop the sampling point to limit potential interaction of the sample with the water or lubricants.

Recommended resources for sub-slab points include California EPA (2011a), New Jersey DEP (2013), Hawaii DoH (2014), and ITRC (2014).

## **5. Indoor Air Sampling**

### **a) Sampling Indoor Air**

Indoor air sampling is performed when the potential for VI exists through other lines of evidence, and other investigative tools are not able to eliminate the VI pathway. Indoor air sampling may also be considered as a method for mitigation system verification. When compared to the other investigative tools available, indoor air sampling represents the most direct measure of exposure due to the VI pathway however it also can be heavily influenced by background conditions.

Recommended resources for indoor air sampling include New York DoH (2006), California EPA (2011a), New Jersey DEP (2013), Hawaii DoH (2014), and ITRC (2014).

When collecting indoor air samples, it is preferable to collect samples at a time and location that will result in the highest potential concentrations. Samples should be collected from the lowest level of the structure with appropriate accessibility where vapors are expected to enter, including basements, crawl spaces, and where preferential pathways have been identified. Existing environmental data (e.g., groundwater, soil, sub-slab soil gas, etc.), site background information, building construction (e.g., basement, slab-on-grade, or multiple types of foundations, elevator shafts, tunnels, etc.), and building operation details (e.g., number and operation of HVAC systems) as evaluated through the development of the CSM should be considered when selecting locations within the building for indoor air sampling. Indoor air samples may be collected concurrently and collocated with sub-slab soil gas sampling locations, and concurrently with an outdoor ambient air sample.

To characterize contaminant concentrations trends and potential exposures, indoor air samples are commonly collected:

- From the crawl space area;
- From the basement (where vapor infiltration is suspected, such as near sump pumps or indoor wells, or in a central location);
- From the lowest level living space (in centrally located, high activity use areas);
- From multiple tenant spaces if in a commercial setting.

If the pre-survey (Section 8(a)(i) herein) determines that chemicals of concern for VI are used, handled, or stored in the building being investigated, then those materials should be removed prior to collecting indoor air samples, if possible. The building should be ventilated for at least 24 hours following removal and before sampling. Other lines of evidence may be necessary, such as collocated sub-slab soil gas and indoor air samples, if the materials cannot be removed.

#### **b) Outdoor Ambient Air Sampling**

To understand potential background influences during indoor air sampling, an outdoor ambient air sample is commonly collected. This sample provides background concentrations outside of the building being investigated at the time of the indoor air sampling event. The investigator commonly designates a sample location and the site conditions at the time of sampling. The investigator also should be aware of the weather conditions during the sampling event. The sampler should be placed in a secure outside location.

Atmospheric pressure and temperature data from nearby weather reporting stations or through portable meteorological equipment should be collected in conjunction with the ambient air samples. Two web sites that may be useful to the investigator are the National Oceanic and Atmospheric Administration's National Weather Service and the Weather Underground.

The following actions are commonly taken to document conditions during outdoor air sampling and ultimately to aid in the interpretation of the sampling results:

- Outdoor plot sketches are drawn that include the building site, area streets, outdoor air sampling location(s), the location of potential interferences (e.g., gasoline stations, dry cleaners, factories, lawn mowers, etc.), compass orientation (north), and paved areas;
- Weather conditions (e.g., precipitation and outdoor temperature) are reported;
- Predominant wind direction(s) during the sampling period are reported using wind rose diagrams; and

- Pertinent observations, such as odors, readings from field instrumentation, and significant activities in the vicinity are recorded.

## 6. Sampling Soil Gas for Oxygen Content

*Note: This section of the guidance is intended only for remediators using the vertical proximity distances for petroleum hydrocarbons.*

If the remediator chooses to screen a site using the vertical proximity distances for petroleum hydrocarbons, the acceptable soil or soil-like material should contain greater than 2% oxygen, on a volumetric basis. Oxygen content above this level indicates an aerobic environment that enables biodegradation of petroleum vapors. The investigator can measure the oxygen concentration in the vadose zone at buildings that are potential receptors to demonstrate that the aerobic soil condition is met.

DEP recommends collecting a soil gas sample beneath the building for oxygen content when there is reason to suspect that the soil may be anaerobic (Section E). Only one grab sample collected at a single location is sufficient. A hole should be drilled approximately 12 inches into acceptable soil or soil-like material (i.e., beneath any gravel or similar fill material underlying the slab). Tubing with a probe tip is dropped into the hole, which is then filled with clean sand (e.g., Hawaii DoH, 2014, Section 7.9.3).

When it is not feasible to obtain the soil gas sample beneath the building, a near-slab soil gas sample may be collected. The sample point should be as close to the building as practical, and no farther than 10 feet. It should be located in the area of greatest anticipated soil vapor contamination. The screen depth should be above the top of the soil or groundwater contamination (e.g., smear zone) and below the bottom of the building foundation. The screen should also be at least 5 feet below the ground surface. The investigator may also collect samples at multiple depths to obtain a concentration profile demonstrating biodegradation. The sample probe should be allowed to equilibrate with the subsurface and purged.

In addition to analysis of oxygen (O<sub>2</sub>), additional compounds such as carbon dioxide (CO<sub>2</sub>) and methane (CH<sub>4</sub>) can be measured to document biodegradation. One grab sample is sufficient to demonstrate that the 2% O<sub>2</sub> criterion is satisfied. The sample may be analyzed using a properly calibrated portable instrument. Oxygen should be calibrated at around 2% and 21%. Alternatively, the sample may be collected using a Tedlar bag or a Summa canister and analyzed at a mobile or offsite laboratory using EPA Reference Method 3C.

## 7. Sampling Separate Phase Liquids

When SPL is present, soil and groundwater screening and modeling are not options available for assessing VI. However, the remediator may obtain a sample of the SPL from a monitoring well to determine if VOCs posing a VI risk are present. This section describes how to evaluate the SPL data for VI.

The SPL sample should be analyzed with U.S. EPA Method 8260C. The results may be reported in units of mass per volume (micrograms per liter, µg/L) or mass per mass (micrograms per kilogram, µg/kg). If the data is reported on a volumetric basis, then the SPL density must be estimated or measured to calculate the mass fraction of each volatile component (e.g., ASTM,

2012b). In addition, the molecular weight of the SPL must be estimated from reference values or an analysis to calculate the mole fraction of each component (e.g., ASTM, 2014).

The vapor concentration ( $C_v$ ) of each volatile component over the SPL, in units of micrograms per cubic meter ( $\mu\text{g}/\text{m}^3$ ), equals:

$$C_v = \frac{x_i(\text{VP})(\text{MW})}{RT} \times (10^9)$$

Where  $x_i$  is the calculated liquid phase mole fraction of the component in the SPL, and the other quantities are defined in Table C-2. (The  $10^9$  factor converts from units of g/L to  $\mu\text{g}/\text{m}^3$ .)

**Table C-2. SPL Vapor Phase Parameters**

Symbol	Description	Value	Units
VP	vapor pressure	VISL	mm Hg
MW	molecular weight	Table A-5	g/mol
$R$	universal gas constant	62.4	L (mm Hg) mol <sup>-1</sup> K <sup>-1</sup>
$T$	temperature	Table B-2	K

VISL: U.S. EPA's VISL Calculator spreadsheet (U.S. EPA, 2014a).

The vapor concentrations calculated for each substance of concern in the SPL using the above equation are comparable to near-source soil gas concentrations. Therefore, they may be evaluated with near-source soil gas screening values (Table 3 for the Statewide health standard) to determine if each chemical poses a potential VI risk. Alternatively, the calculated vapor concentrations may be used with a near-source soil gas attenuation factor in a cumulative risk assessment under the site-specific standard (Appendix B, Section 6). If the SPL is less than 5 feet below the building foundation, then one should apply sub-slab soil gas screening values (Table 4) and sub-slab soil gas attenuation factors.

As an example, consider SPL that is inferred to be No. 6 fuel oil present beneath a nonresidential building. Analysis of a sample of the SPL finds that benzene is nondetect, with a quantification limit of 50,000  $\mu\text{g}/\text{L}$ . The density of the SPL is measured, and the result is 8.1 lb/gal (0.97 kg/L). The molecular weight of benzene is 78 g/mol, and the approximate molecular weight of No. 6 fuel oil is 300 g/mol. Therefore, using these values we first estimate an upper bound on the mole fraction of benzene in the SPL, which equals  $x_{\text{benzene}} = 2.0 \times 10^{-4}$ . Next, given a subsurface temperature of 18°C, the estimated maximum vapor concentration of benzene over the SPL, calculated with the above equation, is  $C_v = 82,000 \mu\text{g}/\text{m}^3$ .

The nonresidential Statewide health standard near-source soil gas screening value for benzene is  $\text{SV}_{\text{NS}} = 16,000 \mu\text{g}/\text{m}^3$ . The estimated benzene vapor concentration based on the detection limit in this example exceeds the screening value. Therefore, at this analytical accuracy, sampling the SPL cannot rule out benzene as a contaminant of VI concern. Possible alternative investigative approaches include near-source soil gas, sub-slab soil gas, or indoor air sampling.

## 8. Quality Assurance and Quality Control Procedures and Methods

### a) Sampling Procedures and Methods

#### i) Pre-Sampling Survey

Prior to the installation and construction of indoor air and sub-slab soil gas sampling points and the collection of samples, a pre-sampling survey should be conducted. The survey should include a short interview with a representative of the owner/occupant of the building and a visual review of accessible portions of at least the lowest level of the building (basement or first floor). Results of the survey are documented and supplemented by sketch maps and photographs as necessary. The investigator may also choose to use a photoionization detector (PID) or flame ionization detector (FID) during the survey to screen for the presence of VOCs in the building. (Note: The non-compound specific VOC detection levels of PIDs and FIDs are much higher than compound-specific laboratory reporting limits.) The pre-sampling survey should review building-specific factors that could influence VOC concentrations in indoor air including:

- Building construction characteristics;
- Building features, such as the condition of the floor slab, floor penetrations, and floor cracks;
- Heating and ventilations systems;
- Items within the lowest level of the building that could serve as potential VOC sources (paint cans, solvents, fuel containers, etc.);
- Occupant activities in the building (painting, smoking, etc.); and
- Exterior characteristics and items or occupant activities outside the building that could serve as potential VOC sources (mowing, paving, etc.).

These observations and others should be documented on a building survey form.

For additional information see ITRC (2007), California EPA (2011a), and New Jersey DEP (2013).

#### ii) Sampling Equipment

Near-source soil gas, sub-slab soil gas, and indoor air samples are commonly collected in passivated stainless steel canisters (e.g., Summa) with laboratory-calibrated flow controllers for U.S. EPA Method TO-15, or other appropriate U.S. EPA methods if TO-15 is not applicable. Other types of sampling containers (e.g., Tedlar bags, glass bulbs, syringes) may be used under certain conditions, but stainless steel canisters are preferred.



Canister volumes should be selected to minimize sample volume while still meeting data quality objectives. Minimizing sampling volumes for near-source soil gas and sub-slab soil gas reduces the potential for ambient air entering around the sampling point and limits the potential for migration of soil gas from relatively long distances away from the sampling point during sample collection. Generally, 1-L canisters are used for near-source soil gas and sub-slab soil gas sample collection and 6-L canisters are used for indoor air and ambient sampling.

Canisters should be connected to the soil gas sampling point using small diameter stainless steel, nylon (Nylaflo type LM), polytetrafluoroethylene (PTFE, Teflon), or polyether ether ketone (PEEK) tubing and stainless steel compression-type fittings. (Other appropriate non-reactive materials may be used. Polyethylene, Tygon, and silicone are not acceptable tubing materials.) The number of connections in the sampling system should be minimized to reduce the number of locations where leaks could occur. Minimizing the length and diameter of the tubing reduces the sample residence time and the required purge volume.

### **iii) Sampling Point Construction**

Near-source and sub-slab soil gas sampling point construction materials should be selected to minimize potential interaction with the sample. The probe should be connected to small diameter tubing; the tubing and all fittings should be clean and dry. The tubing is recommended to be capped or plugged at the surface to isolate the sample from the atmosphere or indoor air.

Sub-slab sample points are sealed in the penetration to eliminate short circuiting of air from inside the building through the slab penetration and into the sample. The materials and methods used to create this seal will depend on site-specific factors such as the condition of the slab and the type and volume of traffic in the building as well as the data quality objectives and planned quality assurance and quality control protocols. Temporary points may be sealed in the penetration with silicone sleeves, silicone rubber stoppers, sculpting clay, putty, or wax. Semi-permanent points may involve the drilling of nested holes in the slab and the use of hydraulic cement or epoxy to seal the tubing and possibly additional fittings in the penetration below the finished elevation. All materials used for construction and completion of the sub-slab soil gas sampling point should be clean, dry and free of materials that could affect the sampling or analysis.

The diameter of the floor slab penetration should be minimized (generally between 3/8 and 1 inch). The surface and sidewalls of the penetration should be cleaned with a stiff bristle brush to remove material created by the advancement of the penetration. Removal of this material is important to limit entrainment of dust in the sub-slab soil gas sample and to promote adherence of the sealing materials to the sidewalls of the penetration or the surface of the slab. Care should be taken to limit interaction with the sub-slab soil gas beneath the slab if a vacuum is used to remove dust during/after advancement of the penetration. If a vacuum is used, additional point equilibration time may be necessary.

Some manufacturers offer alternative sub-slab soil gas sampling point equipment that relies on driving (hammering) a specialized barbed-metal fitting into the slab penetration. The metal fitting is sealed inside the slab penetration by the compression of a sleeve of flexible tubing between the fitting's barbs and the sidewalls of the penetration. These "hammer-in" points may be considered for use during VI investigations.

For indoor and outdoor air sampling, the sampling port should be placed in the breathing zone, approximately 3 to 5 feet above the floor. Mount the canister on a stable platform or attach a length of inert tubing to the flow controller inlet and support it such that the sample inlet will be at the proper height.

Ambient air samples should be collected at breathing zone height (if possible) and in close proximity to the building being tested. For nonresidential buildings, the investigator may elect to collect the ambient air sample near representative heating, ventilation and air conditioning (HVAC) intake locations (i.e., on the roof). Other locations for ambient sampling could be upwind of the building to be sampled. The ambient air sample should have the same sample collection time and be analyzed in the same manner as the interior sample collection method.

**iv) Equilibration**

After installation, near-source and sub-slab soil gas points should be allowed to equilibrate to natural conditions. This is commonly a minimum of 2 hours up to 24 hours.

**v) Leak Testing/Detection for Subsurface Sample Collection**

Leakage during soil gas sampling may dilute samples with ambient air resulting in data that underestimates actual site concentrations or causes false negatives. A shut-in check (sampling assembly integrity) and a leak check (surface seal integrity) can be conducted to determine whether leakage is present and then corrected in the field prior to collecting the sample. Recommended resources for leak testing include ASTM (2012a), California EPA (2015), New Jersey DEP (2013), Hawaii DoH (2014), and ITRC (2014).

A shut-in test of the sampling train is recommended to be completed at each location and during each sampling event to verify aboveground fittings do not contain leaks. A shut-in test consists of assembling the above-ground apparatus (valves, lines, and fittings downstream of the top of the probe), and evacuating the lines to a measured vacuum of about 15 inches mercury (200 inches water or 50,000 Pascals), then shutting the vacuum in with closed valves on opposite ends of the sample train. The vacuum gauge is observed for at least 1 min, and if there is a loss of vacuum greater than 0.5 inches mercury (7 inches water or 2,000 Pascals), the fittings should be adjusted as needed to maintain the vacuum.

Leak check tests are recommended for near-source and sub-slab soil gas points after construction and equilibration. One method employs a shroud placed over the point. An inert tracer gas (such as helium) is released into the shroud with a

target concentration of 10–20%. With the canister valve closed, a soil gas sample is collected from the sample point and measured with a portable helium detector. A leak is occurring when the helium concentration is greater than 10% of the concentration within the shroud. In this case, the leak must be fixed and the leak check repeated.

Helium is the preferred tracer as it is readily available, non-toxic, and easily measured in the field provided high methane levels are not present (false positives). Helium may also be analyzed in the Summa canister sample at the laboratory.

*Note: Balloon-grade helium may contain hydrocarbons that could interfere with sample analysis.*

#### **vi) Purging**

Purging occurs after the sampling system has been assembled (i.e., the canister has been connected to the flow controller and the sampling point has been connected to the canister/flow controller). A “T” fitting can be placed in the sampling train to allow for purging of the connected sampling system. The purging leg of the “T” is commonly isolated from the rest of the sampling train using a valve. There are several acceptable methods for purging the system. For example, either a graduated syringe or a personal sampling pump can be used.

Purge rates for near source and sub-slab soil gas samples should be less than 200 mL/min to limit the potential for short-circuiting or desorbing VOCs from soil particles. Purging volumes should be about three times the volume of the total sampling system (i.e., the sampling point and tubing connected to the sampling canister).

If water is encountered in the soil gas sampling point or observed in the sample tubing during purging then sampling of the point should not be performed. Commonly, when water is encountered during purging an effort is made to evacuate the water from the soil gas sampling point and then allow a minimum of 48 hours before reattempting purging and sampling.

#### **vii) Sampling Rates**

Sampling rates for near-source and sub-slab soil gas samples should be less than 200 mL/min. Sample rates are determined by the laboratory-calibrated flow controller attached to the canister.

Vacuum levels during sampling should not exceed 7.5 inches mercury (100 inches water or 25,000 Pascals). If low permeability materials are encountered during point installation or if there are issues during purging or sampling that suggest low permeability, testing should be performed to measure flow rates and vacuum levels in the near-source soil gas sampling point to determine acceptable purging and sampling flow rates.

Indoor air and ambient air samples are typically collected over a 24-hour period; however, in a nonresidential setting an 8-hour sampling period may be used to coincide with the hours of operation and thus the period of exposure. The sampling flow rate should always be less than 200 mL/min.

With near-source or sub-slab soil gas sampling, the sample duration should be determined by sample volume, but it is recommended to be at least 15 minutes.

If water is observed in the sample tubing during sampling, then sampling should be discontinued. Commonly, when water is encountered during sampling an effort is made to evacuate the water from the soil gas sampling point and then allow a minimum of 48 hours before reattempting purging and sampling.

#### **viii) Sample Recordation**

The field sampling team should maintain a sample log sheet summarizing the following:

- Sample identification;
- Date and time of sample collection;
- Sample location;
- Identity of sampler;
- Sampling methods and devices;
- Volume and duration of sample;
- Canister vacuum before and after sample is collected; and
- Chain of custody protocols and records used to track samples from sampling point to analysis.

#### **b) Data Quality Objective (DQO) Process, Sampling and Data Quality Assessment Process**

The DQO process allows a person to define the data requirements and acceptable levels of decision errors prior to data collection. The DQO process should be considered in developing the sampling and analysis plan, including the quality assurance plan. The implementation phase includes sampling execution and sample analysis. The assessment phase includes Data Quality Assessment (DQA). (See § 250.702(a) of the regulations and Technical Guidance Manual Section IV.B.2.)

#### **c) QA/QC Samples**

Canister integrity as a result of shipping should be examined prior to use. The canisters should be received in the field with the laboratory-measured pressure as part of the

documentation. Field check the pressure of the canister before collecting the sample. The field-measured pressure should be within 10% of the laboratory recorded value. If this is not the case, the canister should be rejected and another canister used. There may be some minor difference in measured pressures (for instance with changes in altitude and barometric pressure) of less than 5% that does not reflect a canister integrity problem.

On completion of sample collection, the final pressure reading should be recorded. This should be about 5 inches mercury (70 inches water or 20,000 Pascals). The reading should be recorded on the chain of custody or other field documentation. If the final pressure is zero (atmospheric), it should still be recorded and sent to the laboratory for verification.

A field duplicate sample may be collected by using a “T” fitting at the point of collection to divide the sample stream into two separate sample containers.

Trip blanks for canisters are not typically required.

Dependent on the sampling equipment it may be desirable to perform an equipment blank. The sample collection media should be certified clean. Materials used in setting up a sampling train should be VOC-free and stored and transported in a VOC-free environment.

Field method blanks can be used to verify the effectiveness of decontamination procedures and to detect any possible interference from ambient air. If samples are collected using sorbent media, it is recommended that a blank media sample accompany the batch of sample media to the field and be returned to the laboratory for analysis. This demonstrates the media is free from compounds of concern from preparation through shipping and handling.

**d) Analytical Methods**

A variety of analytical methods are available to measure vapor samples (subsurface vapor, indoor and ambient air), all of which can provide useable data when reported with QA/QC (Table C-3). The laboratory QA/QC will include blanks, calibration, and system performance samples that define and verify the quality of the data reported. The laboratory engaged for air and vapor analysis should have NELAC or similar accreditation for the methods reported. There may be cases where certification for the method that will be used is not available. In this case, a laboratory standard operating procedure should be available and appropriate QA/QC should be reported with the results.

**Table C-3. Analytical Methods for VOCs in Soil Gas, Indoor and Ambient Air Samples**

Parameter	Method	Sample Media/Storage	Description	Method Holding Time	Reporting Limits
Polar & non-polar VOCs	TO-15	canister/ambient temperature	GC/MS	30 days	1–3 µg/m <sup>3</sup>
Low level VOCs	TO-15 SIM	canister/ambient temperature	GC/MS	30 days	0.011–0.5 µg/m <sup>3</sup>
Polar & non-polar VOCs and SVOCs to C-28	TO-17	sorbent tube/ chilled < 4°C	GC/MS	30 days	1–3 µg/m <sup>3</sup>
Fixed gases (methane, helium, nitrogen, oxygen, carbon dioxide, carbon monoxide)	USEPA 3C or ASTM 1946	canister or Tedlar bag/ambient temperature	GC/TCD/FID GC/FID	3 days for Tedlar bag 30 days for canister	1000–2000 µg/m <sup>3</sup>

Communicate with the laboratory during the planning stages of the investigation to ensure the appropriate analytical method is used. For the data assessment process, it is suggested at a minimum for the laboratory to provide summary QA/QC results with the data reported. A full validated data package can be requested if necessary.

Key elements for choosing the appropriate method are:

- The contaminants of concern;
- The concentrations that may be encountered during sampling and source strength;
- Screening levels/detection levels and other DQOs;
- Sampling considerations;
- Cost of sampling and analysis.

For U.S. EPA Method TO-15 VOCs the passivated canister is the only container allowed by the method; any other containers (e.g., Tedlar bags) are considered a modification. There is no standard list for TO-15. As a performance-based method, any compound that has sufficient volatility and recoveries may be validated for accreditation and reporting, provided a demonstration of capability is performed. TO-15 is the preferred method used for vapor intrusion investigations.

Method TO-17 is a sister method to TO-15. Samples are collected with active sampling onto absorbent media. This method offers lower reporting limits and extends the compound list to include semivolatile compounds. However, this media has a limited capacity, which is further limited if screening is done for a broad range of compounds, and sampling with sorbent media requires more field expertise.

Fixed gases, typically defined as O<sub>2</sub>, nitrogen, CH<sub>4</sub>, CO<sub>2</sub>, and CO, can readily be analyzed using laboratory-based methods that use a thermal conductivity detector for

detection, and also using field monitoring devices (landfill gas monitors). ASTM D1946 (ASTM, 2015a) and U.S. EPA Method 3C are two of the more common analytical methods and can typically detect concentrations as low as 0.1%. They can also be used to analyze for helium, which is often used as a tracer gas during leak check procedures in subsurface sampling. Analysis for these gases can be run from the same canister as VOCs.

Contact your laboratory for analyte lists and reporting levels applicable to these methods.

e) **Data Evaluation**

If the project was planned using the DQO process (U.S. EPA, 2006) or another standard project planning process, the quantity and quality of data, including the measurement quality objectives, will have been specified in the sampling and analysis plan. All of the data should be examined for these types of issues to ensure that data are of adequate quality prior to using the data to evaluate the VI pathway.

9. **Active Sub-Slab Depressurization System Testing**

Details regarding the application, design, installation, and performance testing of sub-slab depressurization (SSD) systems and other VI mitigation systems are available in the following references: U.S. EPA (1991, 1993, 1994a, 1994b, 2001, 2008), Massachusetts DEP (1995), Pennsylvania DEP (1997), California EPA (2011b), and ASTM (2008, 2011b, 2013b, 2015b).

a) **Description**

This section applies to recommended performance testing procedures for active sub-slab depressurization systems installed as engineering controls on buildings where the VI pathway is a potential concern. For existing buildings, active SSD systems are the VI mitigation method preferred by DEP. However, the performance and testing requirements described below may also apply for other active VI mitigation technologies such as sub-membrane depressurization, sub-slab pressurization, and building pressurization systems.

Installation of SSD systems includes the sealing of potential soil vapor infiltration points combined with the use of a fan or blower that creates a continuous negative pressure field (vacuum) beneath the concrete floor slab of the lowest level of the building (basement or first floor). The fan or blower pulls the soil vapor from beneath the slab and vents it to the atmosphere at a height well above the outdoor breathing zone (ITRC, 2014, Appendix J). The presence of a continuous negative pressure field beneath the slab results in the movement of indoor air down into the subsurface, thereby eliminating the VI pathway as a potential concern.

Installation of SSD systems in existing buildings should be performed by qualified professionals, and it is generally completed in the following three steps:

**Step 1: Inspection and Design-Support Diagnostic Testing** – This step typically includes visual inspection of the lowest level of the building to assess the condition of the foundation, to identify potential soil vapor entry points that require sealing, and to review

building-specific design considerations such as the location and type of construction of extraction points, possible discharge piping routes, and exhaust fan locations. This step also includes diagnostic testing to support siting of extraction points, sizing of the exhaust fan/blower and piping, and evaluation of stack effects and the potential for back-drafting of heating systems. The results of the diagnostic tests or communication tests are used to confirm the ability of the SSD to depressurize beneath the entire building.

**Step 2: Design and Construction of the SSD System** – The mitigation contractor prepares a design applicable to the building characteristics and results of diagnostic testing. Elements of the construction include installation of extraction point(s), exhaust piping, exhaust fans/blowers, and sealing of potential soil vapor entry points.

**Step 3: Commissioning of the SSD System** – The commissioning step includes post-construction performance testing consisting of pressure differential measurements to demonstrate the system is working as designed. During this step, smoke testing is also performed to confirm operation of the SSD system does not result in back-drafting of combustion appliances (heating systems). Adjustments to or augmentation of the SSD system may be completed during this final installation step. Post-construction performance testing methods completed as part of commissioning of active SSD systems are described below.

**b) Performance Testing Methods**

The remediator should test the mitigation system after its installation. At a minimum, the testing should follow the manufacturer's or vendor's recommendations. The mitigation system should also be tested if a significant modification or repair is made, after a change in ownership, or upon request by the Department.

The primary method of performance testing of active sub-slab depressurization systems consists of differential pressure field extension tests that provide confirmation of a continuous negative pressure field (vacuum) beneath the concrete floor slab of the lowest level of the building. If the differential pressure field extension tests demonstrate the operating SSD system is providing depressurization throughout the sub-slab, the remediator is not required to perform indoor air confirmation sampling.

Differential pressure field extension tests are performed by operating the SSD system and simultaneously measuring the sub-slab pressure at different locations across the floor slab including, if accessible, building corners and building perimeters. The pressure measurements should be performed by drilling a small hole through the slab (e.g., 3/8-inch diameter) and measuring the differential pressure using a digital micromanometer. In general, for active SSD systems a pressure differential of at least 0.01 inches water (2 Pascals) should be achieved when the heating system is operating and 0.025 inches water (6 Pascals) otherwise (U.S. EPA, 1993). As such, a digital micromanometer with sufficient sensitivity is necessary. Smoke testing can be performed as a qualitative test but it may not be as reliable with low vacuums.

As an alternative to differential pressure testing, the remediator may collect one or more indoor air samples.



**Appendix D: OSHA Program Vapor Intrusion Checklist**

List the chemical(s) of concern that the facility uses:

Chemical	CAS Registry Number:
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____

- Facility provided Material Safety Data Sheet(s) (MSDS) or Safety Data Sheet(s) (SDS) for the chemical(s) of concern listed above that they have identified as using.
  
- Facility identified where the chemical(s) are used in the facility and how they are used.
  
- The facility has performed air monitoring (industrial hygiene) of the identified chemical(s) of concern.
  
- The facility has provided the results of the air monitoring to the Department.
  
- The air monitoring has been conducted in all areas of the plant or facility.
  
- The facility has provided documentation showing that all employees in the facility have completed safety training associated with the chemicals of concern.

- Pictures provided by the facility show PPE and signage use associated with the chemicals of concern. (Items shown below are examples of equipment associated with use of PPE, and may not be the exact items used by the facility.)

Dip Tanks



Lab or process hoods with documentation of annual assessments



Canopy Hoods with documentation of annual assessments



Local ventilation with documentation of annual assessments



Use of respirators with employee medical clearances



PPE such as chemical gloves, aprons, Tyvek coverall or clothing



Occupational Exposure Values for Chemicals of Concern

Occupational Safety and Health Administration Permissible Exposure Limits (OSHA PEL) or American Conference of Governmental Industrial Hygienist Threshold Limit Values (ACGIH TLV).

Chemical of Concern	OSHA PEL	ACGIH TLV

OSHA exposure limits are available at: 29 CFR Subpart Z; 29 CFR 1910.1000–1052

<https://www.osha.gov/dsg/annotated-pels/index.html>

ACGIH TLVs are available from the purchased publication. All of these values should be available from the MSDS/SDS.

Status: (All of the above items must be included in order for the facility to qualify to use an OSHA program to address VI.)

- Qualified
- Not Qualified

Consultant or Reviewer:

(Print) \_\_\_\_\_

(Signature) \_\_\_\_\_ Date: \_\_\_\_\_